

Quick Start—NCI & Parameter Reference

What's changed in X4??

- New procedures and examples
- NCI changes
- New & changed parameters
- Agievision reference
- Lathe tool inspection
- Validating parameters with UpdatePost

Reference tables

- NCI Gcodes
- Tool information (20000s parameters)
- Operation & toolpath parameters
- Machine definition parameters
- Control definition parameters
- Machine group parameters

How do I...?

Click on each link to see step-by-step instructions plus sample code.

- ▶ Capturing a string from a 10000s parameter
- ▶ Capturing the value of a single 10000s parameter
- ▶ Building a table of parameter values
- ▶ Capturing a string from a 20000s line
- ▶ Capturing all the parameters in a 20000s line and storing them in an array
- ▶ Capturing a single parameter from a 20000s line
- ▶ Capturing a range of parameters from a 20000s line
- ▶ Implementing tool inspection for lathe grooves
- ▶ Capturing machine definition parameters
- ▶ Getting the entity ID
- ▶ Capturing control definition parameters
- ▶ Capturing machine group parameters
- ▶ Doing a parameter dump: outputting all the parameters
- ▶ Reading operation parameters from any postblock
- ▶ Setting options for transform operation parameters
- ▶ Reading parameters during the NCI pre-read routine



*NCI & Parameter
Reference*

Mastercam X4

NCI & Parameter

Reference

April, 2009

Mastercam® X4 NCI & Parameter Reference

Date: April, 2009

Copyright © 2009 CNC Software, Inc. — All rights reserved.

First Printing: April, 2009

Software: Mastercam X4

Part number: X4-PDF-NC

IMPORTANT NOTICE!

PLEASE READ THIS STATEMENT AND THE SOFTWARE LICENSE AGREEMENT COMPLETELY BEFORE USING THIS SOFTWARE. YOU MUST ACCEPT THE TERMS OF THIS LICENSE BEFORE YOU CAN OPERATE THE SOFTWARE PROGRAM.

BY CONTINUING TO USE THIS SOFTWARE, YOU (EITHER AN INDIVIDUAL OR A SINGLE ENTITY) INDICATE YOUR INTENTION TO BE BOUND BY AND ACCEPT THE TERMS AND CONDITIONS OF THIS SOFTWARE LICENSE. IF YOU DO NOT AGREE TO THESE TERMS AND CONDITIONS, YOU MAY NOT ACCESS OR OTHERWISE USE THIS SOFTWARE AND WILL IN FACT BE PROHIBITED FROM DOING SO. THIS COMPUTER SOFTWARE MAY BE USED ONLY PURSUANT TO THE TERMS AND CONDITIONS SET FORTH BELOW, AND SOLELY IN CONJUNCTION WITH THE ACCOMPANYING SECURITY MECHANISM (UNLESS OTHERWISE SPECIFIED IN THE "EXCEPTIONS TO SECURITY MECHANISM REQUIREMENTS" SECTION OF SUCH TERMS AND CONDITIONS) WHICH MUST BE PRESENT ON YOUR COMPUTER (OR NETWORK AS APPLICABLE) AT ALL TIMES DURING SUCH USE.

Please Note: Your company may have additional restrictions and guidelines in place regarding the use of this Software that are in addition to those found within this Software License. If you have any questions or concerns as to the existence of any such additional restrictions or guidelines, you should consult with your supervisor or your IT Department before using this Software.

Read This If You Have Received This Software From A Third Party: If you received this Software from someone other than an authorized CNC Software, Inc. reseller, you do not have a legal software license. (For example, if you acquired this Software simply by buying a machine or Software from the former owner or from an auction, you do not have a valid license.) You should contact CNC Software, Inc. (860-875-5006) in order to obtain a new and valid license. **Use of this Software without a valid software license is unlawful, a violation of the Copyright Act and may expose you to criminal liability under 17 United States Code Sec. 506, including fines and damages.**

Software License

If you have paid a license fee, CNC Software, Inc. ("CNC") a Connecticut corporation with its principal place of business at 671 Old Post Road, Tolland, Connecticut, 06084 hereby grants to you a non-exclusive, non-transferable license (the "License") to use this software program and its accompanying documentation (and, if applicable, to permit your authorized employees to use them), solely in accordance with the terms and conditions of this Software License Agreement. You may use the Software solely for your internal business purposes and solely in conjunction with the accompanying hardware or software device, method, scheme or other security measure provided by CNC which allows a user to access the Software and prevents unauthorized access to the Software (the "Security Mechanism"). The Software, any updates to the Software through purchase or due to enrollment in an authorized software Maintenance program (including any that you download through the Internet), and the Documentation in printed or electronic form shall hereinafter collectively be referred to as the "Software" and are all governed by this License.

Restrictions

You may not use the Software without a Security Mechanism provided by CNC or CNC's suppliers. When CNC or CNC's resellers provide you with a single-user Security Mechanism, the Software may only be used (in executable code form only) on a single computer to which the Security Mechanism is physically attached. In the event CNC or CNC's resellers provide you with a multiple-user Security Mechanism for use over an internal network (a "Network Security Mechanism"), the Software may be used: (a) in executable code form only; (b) only on end-user computers that are connected to the internal network to which the Network Security Mechanism is attached; and (c) only by the number of users and accessed by the number of end-user computers for which licenses were purchased and as further allowed by the Network Security Mechanism. You may physically transfer the Software from one computer equipped with a single-user Security

Mechanism to another only if the Security Mechanism is included in the transfer and is installed with the new computer.

You shall not: (a) copy (except as provided below), adapt, modify the Software; (b) publish, display, disclose or create a derivative work from the Software or any part thereof; (c) de-compile or translate, disassemble, create or attempt to create, by reverse engineering or otherwise, the source code form of the Software from the executable code of the Software; (d) remove any proprietary notices, labels or marks from the Software; (e) sell, rent, lease, distribute or otherwise transfer or provide all or any part of the Software to any person or entity without the prior written consent of CNC; (f) use the Software to provide outsourcing, service bureau, time sharing or other services to any third party; or (g) sublicense, assign, delegate or otherwise transfer your rights in the Software, under the Software License Agreement or any of the related rights or obligations for any reason without the prior written consent of CNC. You shall not circumvent, bypass, modify, reverse engineer, disassemble, disable, alter, enhance or replicate the function of the Security Mechanism in any manner whatsoever. Any attempt to do so shall result in automatic termination of this License without prejudice to all other legal rights and remedies of CNC.

Copying Restrictions

You may make one (1) copy of the Software for backup or archival purposes, provided that you reproduce all proprietary notices of CNC on any such copy.

Non Transferable

You may not transfer or assign the Software or this Software License Agreement or any rights or obligations hereunder. Any attempt to do so will automatically terminate this License without the need for notice. This termination is without prejudice to all other legal rights and remedies of CNC.

Intellectual Property Rights

The Software is and includes intellectual property of CNC. All associated intellectual property rights, including, without limitation, worldwide patent, trademark, copyright and trade secret rights, are reserved by CNC. CNC retains all right, title and interest in and copyrights to the Software, regardless of the form or media in or on which the original or other copies may subsequently exist. This Software License Agreement shall not constitute a sale of the Software and no title or proprietary rights to the Software are transferred to you hereby. You acknowledge that the Software is a unique, confidential and valuable asset of CNC, and CNC shall have the right to seek all equitable and legal redress which may be available to it for the breach or threatened breach of this Software License Agreement including, without limitation, injunctive relief. Unauthorized copying of the Software or failure to comply with the above restrictions shall result in automatic termination of this License and this Software License Agreement without prejudice to all other legal rights and remedies of CNC.

Confidentiality

You acknowledge that the Software contains proprietary trade secrets of CNC and you hereby agree to maintain the confidentiality of the Software using at least as great a degree of care as you use to maintain the confidentiality of your own most confidential information. You agree to promptly communicate the terms and conditions of this Software License Agreement to those persons employed by you who come into contact with the Software, and to use your best efforts to ensure their compliance with such terms and conditions, including, without limitation, absolutely preventing such persons to use any portion of the Software for the purpose of deriving the source code of the Software or defeating the Security Mechanism.

Enforcement Obligations

In the event you become aware that any person or entity in your employ or under your control is using the Software in a manner not authorized by this Software License Agreement, you shall immediately take all steps necessary to stop such unauthorized use of the Software. You shall promptly notify CNC in writing of any unauthorized use of the Software of which you become aware.

Limited Warranties

CNC WARRANTS THAT THE MEDIA ON WHICH THE SOFTWARE IS DISTRIBUTED WILL BE FREE OF DEFECTS IN MATERIAL OR WORKMANSHIP FOR A PERIOD OF THIRTY (30) DAYS AFTER PURCHASE. THE FOREGOING LIMITED WARRANTY EXCLUDES DEFECTS ARISING OUT OF ACCIDENT, NEGLECT, MISUSE, FAILURE OF ELECTRIC POWER AND CAUSES OTHER THAN ORDINARY AND AUTHORIZED USE. EXCEPT FOR THE FOREGOING LIMITED WARRANTY, THE SOFTWARE IS PROVIDED "AS IS, WITH ALL FAULTS." THIS LIMITED WARRANTY IS THE ONLY WARRANTY PROVIDED BY CNC REGARDING THE SOFTWARE. TO THE MAXIMUM EXTENT PERMITTED BY LAW, CNC DISCLAIMS ALL OTHER WARRANTIES OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF

MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. CNC IS NOT OBLIGATED TO PROVIDE ANY UPDATES TO THE SOFTWARE.

Sole and Exclusive Remedy for Breach of Warranty: YOUR SOLE EXCLUSIVE REMEDY AND CNC'S SOLE OBLIGATION HEREUNDER SHALL BE, AT CNC'S SOLE OPTION (i) REPLACEMENT OF THE DEFECTIVE MEDIA; OR (ii) REFUND OF THE PURCHASE PRICE OF THE SOFTWARE. CNC SHALL HAVE NO OTHER OBLIGATION OR LIABILITY TO YOU ARISING FROM OR RELATED TO THIS LICENSE OR YOUR USE OF THE SOFTWARE. ANY USE BY YOU OF THE SOFTWARE IS AT YOUR OWN RISK.

Note on Documentation: While CNC makes every effort to ensure that its Documentation for the Software is accurate and up-to-date, it cannot guarantee the Documentation at all times represents the latest operation and functionality of the Software. The content of all documentation, in electronic or printed form, for the Software is provided for informational purposes only. The content of the Documentation may be changed without notice to you. **CNC expressly disclaims any warranty or representation that the Documentation is an accurate and/or current reflection of the Software's operation and performance.**

Disclaimer of Consequential Damages and Limitation of Liability

IN NO EVENT WHATSOEVER WILL CNC, OR ITS EMPLOYEES, SHAREHOLDERS, DISTRIBUTORS OR RESELLERS BE LIABLE TO YOU FOR ANY INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES ARISING OUT OF OR IN CONNECTION WITH THIS SOFTWARE LICENSE AGREEMENT OR THE USE OF THE SOFTWARE, EVEN IF CNC HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. WITHOUT LIMITING THE FOREGOING, CONSEQUENTIAL DAMAGES SHALL INCLUDE, WITHOUT LIMITATION, SPECIAL, PUNITIVE OR EXEMPLARY DAMAGES, DAMAGES FOR LOSS OF BUSINESS, LOSS OF PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, AND LOSS OF OR DAMAGE TO ANY PRODUCTS THAT THE SOFTWARE IS USED IN CONJUNCTION WITH.

CNC'S ENTIRE LIABILITY WITH RESPECT TO ITS OBLIGATIONS UNDER THIS SOFTWARE LICENSE AGREEMENT OR OTHERWISE SHALL NOT EXCEED THE AMOUNT OF THE LICENSE FEE PAID BY YOU FOR THE SOFTWARE. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF IMPLIED WARRANTIES OR LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

Indemnification

You shall indemnify and hold harmless CNC, its officers, directors, employees, resellers and agents (the "Indemnified Parties") from and against all losses, settlements, claims, actions, suits, proceedings, judgments, awards, damages, liabilities, costs and expenses including, without limitation, reasonable attorneys' fees (collectively "Losses") which arise out of or are related to any breach of this Software License Agreement by you or your employees, agents, resellers, dealers or sub-dealers, and shall reimburse the Indemnified Parties for any and all legal, accounting and other fees, costs and expenses reasonably incurred by any of them in connection with investigating, mitigating or defending any such Losses.

Educational Pricing

If this Software was obtained through or in accordance with a CNC "Educational Pricing" plan, option, grant, schedule or program, it may not be used by anyone, including you, to conduct any computer aided design, computer aided drafting, computer aided machining, or training activities that, directly or indirectly, generate or otherwise result in monetary revenues for the benefit of any individual or any entity, other than the school that originally received this Software.

Termination

This Software License Agreement is effective until terminated. You may terminate this Software License Agreement at any time by returning to CNC all copies of the Software under your control and by returning the Security Mechanism to CNC. CNC may terminate this Software License Agreement if CNC determines, in its sole discretion, that you have violated the terms of this Software License Agreement. Upon termination of this Software License Agreement, you agree to immediately return to CNC all copies of the Software, return the Security Mechanism to CNC, and certify to CNC in writing that all known copies, including backup copies, have been returned. All provisions relating to confidentiality, proprietary rights, indemnification and non-disclosure shall survive the termination of this Software License Agreement. You may not transfer this Software to the purchaser of any equipment on which the Software may be resident. You may not transfer this Software via liquidation, bankruptcy, auction, close of business, or any other method that does not involve an authorized Mastercam reseller. This License is for you alone. In the event you breach the provisions of this Section, CNC shall be

entitled to liquidated damages in the amount of Fifteen Thousand Dollars (\$15,000), plus its reasonable attorney's fees and court costs.

General

This Software License Agreement shall be governed by and construed in accordance with the laws of the state of Connecticut, USA without regard for Connecticut's conflicts of law principles. The sole and exclusive jurisdiction and venue for any litigation arising from or related to this Software License Agreement or the subject matter hereof shall be in an appropriate state or federal court located in Hartford, Connecticut. You hereby submit to the personal jurisdiction of the US District Court for the District of Connecticut and the Superior Court of the State of Connecticut. This Software License Agreement shall constitute the entire agreement between you and CNC with respect to the subject matter hereof. Any waiver or modification of this Software License Agreement shall be valid only if it is in writing and signed by both parties hereto. If any part of this Agreement is found invalid or unenforceable by a court of competent jurisdiction, the remainder of this Agreement shall be interpreted so as to reasonably affect the intention of the parties.

Attorneys Fees

In the event that CNC is required to take legal action to enforce its rights under this License Agreement and obtains a ruling or settlement in its favor, you shall be liable to CNC for its reasonable attorney's fee incurred in investigating and prosecuting its claim.

U.S. Government Restricted Rights

The Software provided hereunder is a "commercial item," as that term is defined in 48 C.F.R. 2.101, consisting of "commercial computer software" and "commercial computer software documentation," as such terms are used in 48 C.F.R. 12.212. Consistent with 48 C.F.R. 12.212 and 48 C.F.R. 227.7202-1 through 227.7202-4, the Software made available to the United States of America, its agencies and/or instrumentalities, is provided with only those rights set forth in this Agreement. Use, duplication or disclosure of the Software by the government is subject to the restrictions as set forth in subparagraph (c) (1) and (2) of the Commercial Computer Software-Restricted Rights clause at 48 C.F.R. 52.227-19, as amended, or any successor regulations thereto.

Export Restrictions

You represent and warrant that you will not, without obtaining prior written authorization from CNC and, if required, of the Bureau of Export Administration of the United States Department of Commerce or other relevant agency of the United States Government, export or re-export, directly or indirectly, the Software from the United States to (i) any country destination or entity to which export is restricted by the Export Administration Regulations of the United States Department of Commerce; (ii) any country or entity subject to sanctions administered by the Office of Foreign Assets Control, United States Department of the Treasury; or (iii) such other countries or entities to which export is restricted by any other United States government agency. You further agree that you are solely responsible for compliance with any import laws and regulations of the country of destination of a permitted export or re-export, and any other import requirement related to a permitted export or re-export.

Exceptions to Security Mechanism Requirements

CNC software programs Mastercam Design LT and Mastercam Demo as well as printed and electronic documentation do not require the use of Security Mechanisms, and the provisions in this Software License Agreement relating to Security Mechanisms do not apply to your use of such programs, provided, however, that such provisions shall apply to your use of all other Software and documentation provided hereunder.

Survival

All provisions of this Software License Agreement relating to confidentiality, non-disclosure, CNC's proprietary rights, disclaimers, and limits of liability, or indemnification by Customer shall survive termination of this License for any reason.

Reservation of Rights

All rights not expressly granted are reserved by CNC.

Trademarks

Mastercam® is a registered trademark of CNC.

Windows, Windows 2000, Windows XP, and Windows Vista are registered trademarks of Microsoft Corporation. Mastercam Verify is created in conjunction with MachineWorks Ltd. Mastercam Backplot includes Copyrighted intellectual property rights owned by NWD.

Contents

1. Introduction.....	1
Contacting CNC Software	1
▶ Changes for X4	3
2. Working with Parameters and Toolpath Data.....	11
▶ Working with NCI toolpath data	12
▶ Working with operation (10000s) parameters	13
Capturing values for 10000s parameters	14
Capturing a string from a 10000s parameter	15
Capturing numeric values from 10000s parameters	16
Validating parameters with UpdatePost	19
▶ Working with 20000s lines	20
Capturing parameters from 20000s lines	21
Capturing a string from a 20000s line	22
Capturing numeric values from a 20000s line	23
Lathe tool inspection comments	27
▶ Working with machine definition, control definition, and machine group parameters	30
Capturing machine definition parameters.....	31
Getting the entity ID	32
Capturing control definition parameters.....	34
Capturing machine group parameters	35
▶ Advanced techniques for working with operation parameters	37
Reading parameters during the NCI pre-read routine	37
Doing a parameter dump: outputting all the parameters.....	38
Reading operation parameters from any postblock.....	40
Setting options for transform operation parameters	41
3. NCI Reference	43
▶ NCI Gcodes	44
toolop\$ codes	116
Control Flags Parameters.....	133
▶ Tool Information (20000s Parameters)	137
Mill/Router/Generic	138
Lathe.....	144
Wire	149

Parameters for Agievision posts.....	150
Ranges of interface parameters	151
Validating the Agievision post	152
Parameter tables	153
Interface reference	166
Control definition: Control Model page	166
Machine group properties: Piece Setup tab	167
Machine group properties: Piece Details tab	168
Wirepath parameters: Machining page	168
Wirepath parameters: User Tech (Tech. Database) dialog box	169
Wirepath parameters: Cut parameters page	170
Wirepath parameters: Start Point page.....	170
Wirepath parameters: Entry page	171
Wirepath parameters: Exit page	171
Wirepath parameters: Threading page	172
Wirepath parameters: Taper page.....	172
Wirepath parameters: Corners page	173
Wirepath parameters: Attributes page.....	173
Wirepath parameters: Group page	174
Wirepath parameters: Collar page	174
4. Parameter Reference	177
▶ Operation & toolpath parameters.....	178
Common parameters.....	178
Mill & Router parameters.....	194
Lathe parameters	256
Wire parameters.....	278
▶ Machine definition parameters	288
Machine definition: visual reference	288
Machine Definition Manager	289
General machine parameters	290
Op. feed rate limits /axis motion/orientation tab.....	290
Axis feed rate limits tab	291
CPlane, WCS, HTC/VTL tab	292
Coolant/Flushing/Options tab	293
Tool/material libraries tab	294
Machine dynamics tab	295
Component geometry (common)	296
Solid geometry	296
Block geometry	297
Cylinder geometry	298
Extruded geometry	299
Revolved geometry	300
Position/Orientation tab	301
Component properties (individual)	302
Automatic tool changer parameters	302
Chuck parameters.....	303
Chuck geometry (parametric) dialog box	304
Chuck jaws parameters	305
Bar stock parameters.....	306
Turret parameters.....	307
Turret geometry (parametric) dialog box	308

Gang tool parameters	309
Tailstock parameters	310
Tailstock geometry	311
Tailstock center parameters	312
Steady rest parameters	313
Linear axis parameters	314
Linear axis parameters (programmed motion)	315
Rotary axis parameters	316
Tool spindle parameters	317
Tool component parameters	318
Router spindle parameters	319
Router spindle position	320
Router piggyback spindle parameters	321
Router piggyback spindle position	322
Wire guide parameters	323
Machine definition: list of parameters	323
► Control definition parameters	351
Control definition: visual reference	351
Overall parameters	351
Tolerance page	352
Communications page	353
Files page	354
NC Dialog page (Mill–Lathe–Router)	355
NC Output page	356
Misc. Int/Real Values page	357
Work System page	358
Tool page (Mill–Router)	359
Tool page (Lathe)	360
Linear page (Mill–Router)	361
Linear page (Lathe–Mill/Turn–Wire)	362
Arc page (Mill–Router–Wire)	363
Arc page (Lathe)	364
Rotary page (Mill–Router–Lathe)	365
Feed page (Mill–Router)	366
Feed page (Lathe)	367
Feed page (Wire)	368
Cutter Compensation page	369
Machine Cycles page (Mill–Router–Lathe)	370
Drill Cycles page (Mill–Router–Lathe)	371
Lathe Canned Cycles page (Lathe)	372
Subprograms page	373
Start/Leads page (Wire)	374
Cuts page (Wire)	375
Corner page (Wire)	376
Corner page (Wire)	377
Reverse Cuts Contour page (Wire)	378
Reverse Cuts Auxiliary page (Wire)	379
4-Axis Paths page (Wire)	380
Nocore page (Wire)	381
Control definition: list of parameters	381

▶ Machine group parameters	398
Machine group properties: visual reference.....	398
Files tab (Machine Group Properties)	399
Tool Settings tab (Machine Group Properties)	400
Stock Setup tab—Mill/Router (Machine Group Properties)	401
Stock Setup tab—Lathe (Machine Group Properties)	402
Safety Zone tab (Machine Group Properties)	403
Machine group properties: list of parameters	403

chapter 1

Introduction



Welcome to the *Mastercam X4 NCI & Parameter Reference*. This guide documents the NCI Gcodes and operation parameters that together encapsulate Mastercam operations and toolpaths. It serves two main purposes:

- A reference to all the parameters and NCI Gcodes.
- Guidelines and examples for reading operation parameters, including parameters for machine definitions, control definitions, and machine groups.

This edition incorporates new features for Mastercam X4, introduced in April, 2009. It includes the additional parameters used by new toolpaths, as well as new parameter read functions.

Contacting CNC Software

Use the following Web sites to find information on Mastercam X4:

www.emastercam.com	Mastercam global user forum
www.mastercam.com	CNC Software, Inc. corporate Web site
www.mastercamedu.com	CNC Software, Inc. Educational Division Web site

For assistance with installing Mastercam X4, its SIM or NetHASP, or to obtain more information on using Mastercam X4, contact your local Mastercam X4 Reseller. If your Reseller is unavailable, you can call CNC Technical Support Services Monday through Friday, 8:00 a.m.–5:30 p.m., USA Eastern Standard Time.

When calling CNC Software for technical support, please follow these guidelines:

- Be sure you have already tried to contact your Mastercam X4 Reseller.
- Provide the serial number of your SIM HASP or NetHASP.
- Be ready to describe the problem in detail. Write down what happened, particularly if you cannot call immediately after the problem occurs.
- Be in front of your computer when you call.
- If possible, try to duplicate the problem before calling. Our Support Services technician may require you to duplicate the problem while you are on the phone.
- When you call, have ready a complete description of your hardware, including your operating system (OS), central

processing unit (CPU), graphics card and settings, and memory.

You can also leave a message for CNC Support Services twenty-four hours a day, seven days a week via our e-mail or Web site addresses. When sending e-mail, please include:

- The serial number of your SIM HASP or NetHASP
- Telephone number and contact information where you can be reached
- Files required to reproduce an issue, such as .MCX and post files



TIP: Use Mastercam's Zip2Go utility to gather Mastercam part data into a compressed .Z2G file. This utility makes it easy to provide your Reseller or CNC Support Services with a file attachment that contains the information they need. Zip2Go scans the machine groups in your current part file and captures information such as your Mastercam configuration, machine definition, and post files. For more information on using Zip2Go, please refer to the Mastercam Help.



Important Contact Information

Address	CNC Software, Inc. 671 Old Post Road Tolland, Connecticut, 06084-9970 USA
Phone	(860) 875-5006
Fax	(860) 872-1565
FTP Address	ftp://ftp.mastercam.com
Internet Address	http://www.mastercam.com
E-mail	support@mastercam.com

Changes for X4

The following sections summarize the changes that have been made to this document for Mastercam X4. Each section here corresponds to a specific chapter.

See [Working with Parameters and Toolpath Data](#) starting on page 11.

See [NCI Reference](#) starting on page 43.

See [Parameter Reference](#) starting on page 177.

Working with Parameters and Toolpath Data

This chapter has been completely reorganized. Obsolete content has been removed, and new procedures and examples have been added. New technical content includes:

- [Validating parameters with UpdatePost](#) on page 19 has been added.
- [Lathe tool inspection comments](#) on page 27 has been added.



NCI Reference

The following NCI changes were made for Mastercam X4:

- Updated **toolop\$** table: [toolop\\$ codes](#) on page 116.
- Added section for Agie data: [Parameters for Agievision posts](#) on page 151
- Updated **cur_cflg\$** table: [L Lathe Control Flags Parameters](#) on page 135
- Addition of 29999 line: [29999 : Tool inspection comment](#) on page 149



In addition, the following sections in this document were corrected:

- [L M R W 1025 : Canned Text](#)
- [M R L 1016 : Additional Miscellaneous Parameters](#)
- [W 1016 : Additional Miscellaneous Parameters](#)

Parameter Reference

This section lists the new and changed parameters for Mastercam X4. Each table in this section shows only the new/changed parameters; please go to the [Parameter Reference](#) chapter to see the complete tables.

OPERATION

OP_SMOOTHING	(new for X4)
OP_SPAWNED_INFO	(new for X4)
PRM_CIRCLE_5AX	(new for X4)



OP_SMOOTHING

15684	Smoothing tolerance (new for X4)
15685	Segment length (new for X4)
15686	1 = Smoothing is turned on (new for X4)
15687	1 = Use fixed segment length (new for X4)
15688	1 = Shift points randomly along toolpath (try to avoid patterns in neighboring segments (new for X4)
15689	1 = Minimize number of points (enlarge spacing) (new for X4)
15690	1 = Present arcs as line segments (break arcs) (new for X4)

**OP_SPAWNED_INFO**

15691	The operation ID of the parent FBM operation that spawned the current operation (new for X4)
15692	The type of FBM operation that spawned the current operation (new for X4)

OP_FILTER

15693	0 = Use maximum tolerance for both lines and arcs; 1 = Tighten line filtering tolerance; 2 = Tighten arc filtering tolerance (new for X4)
15694	Reduced tolerance value if 15693 = 1 or 2 (new for X4)

PRM_OPEN_POCK

40011	Use Standard pocket for closed chains option: 1 = this option is <i>not</i> selected (allows multiple & non-linear open edges); 0 = this option <i>is</i> selected. (new for X4)
-------	---

PRM_NESTING

15695	Shape is locked (new for X4)
15696	Minimum width for trimming (new for X4)
15697	Trim option is turned on (new for X4)
15698	Combine cuts option is turned on (new for X4)
15699	Trim mode (new for X4)
15700	Group sorting is turned on (new for X4)
15701	Use Name as Label option is turned on (new for X4)

PRM_2D_HMM

12952	Feedrate override (new for X4)
12953	Spindle speed override (new for X4)
12954	1 = Feedrate override on (new for X4)
12955	1 = Spindle speed override on (new for X4)
12956	1 = conventional milling (0 = climb) (new for X4)
12957	Single chain slot for peel mill : 0 = chain is center of slot, 1 = left, 2 = right (new for X4)
12958	1 = Extend exit (new for X4)
12959	Entry extension distance (new for X4)
12960	Exit extension distance (new for X4)

12961	Percentage of stepover to use for a temporary “across” cut. This is used to build the final Along 3D cut. (new for X4)
12962	Cut method: 0 = Zigzag, 1 = One way, 2 = Spiral (new for X4)
12963	Across/along selection: 0 = Across, 1 = Along (new for X4)
12964	If 12963 = Along, 1= Do 2D projection, 0 = Do 3D core mill parameters (new for X4)
12965	1 = use conventional rough cut, 0 = use climb rough cut (new for X4)
12966	1 = Enable adaptive stepdown (new for X4)
12967	1 = Enable profile smoothing (Z constant smooth op) (new for X4)
12968	Maximum Z stepdown distance for core mill (new for X4)
12969	Minimum Z stepdown for use with adaptive step (new for X4)
12970	Maximum step difference between 2 points in adaptive step (new for X4)
12971	Stepover as a % of tool diameter in core mill (new for X4)
12972	Minimum stepover as % of maximum stepover (new for X4)
12973	Maximum stepover for core mill (new for X4)
12974	Minimum stepover for core mill (new for X4)
12975	Maximum radius for smoothing operation (new for X4)
12976	Smoothing tolerance (new for X4)
12977	Tolerance for smoothing op cornering (new for X4)
12978	Length of peel mill microlift (new for X4)
12979	Height of peel mill microlift (new for X4)
12980	1 = Peel mill microlift is enabled (new for X4)
12981	1 = Use feed rate at entry, 0 = Use plunge rate (new for X4)
12982	Entry style: 0 = profile ramp, 1 = helix (new for X4)
12983	Entry motion: 1 = Use 3D arcs (helixes), 0 = Linearize them (new for X4)
12984	1 = Use core mill as raw passes, 0 = Use area mill as raw passes (new for X4)
12985	gap size defined by: 0 = distance, 1 = percent of tool diameter (new for X4)
12986	1 = minimize burial (use trochoidal loop), 0 = Don't (new for X4)





12987	1 = Keep trochoidal loop inside machining region, 0 = Let it move in air outside machining region (new for X4)
12988	Radius of helix (for core/area mill) (new for X4)
12989	Z clearance of helix/profile ramp (core/area mill) (new for X4)
12990	Maximum angle of helix/profile ramp (core/area mill) (new for X4)
12991	Radius of S-shaped stepover (new for X4)
12992	Preferred profile span (new for X4)
12993	Skip pockets with span less than this value (new for X4)
12994	Keep tool down within this gap size (actual distance) (new for X4)
12995	Keep tool down within this gap size (percentage of tool diameter) (new for X4)
12996	2D-blend stepover amount (new for X4)
12997	Initial loop size: % of tool diameter (5–100), 0 = not set (new for X4)
12998	Minimum loop size, % of tool diameter (1–100), 0 = not set (new for X4)
12999	Retry loop size: % of previous loop size (5–95), 0 = not set (new for X4)
40001	Expected material engagement adjustment: % of stepover, (1–100), 0 = not set (new for X4)
40002	Adjust feedrate by this % if trochoidal loop doesn't fit, (5–95), 0 = not set (new for X4)
40003	Maximum cutting distance (retract and load a same shape tool) (new for X4)
40004	Maximum cutting time (retract and load a same shape tool) (new for X4)
40005	Dynamic pocket radius (new for X4)
40006	Dynamic pocket radius percentage (new for X4)
40007	Dynamic pocket approach distance (new for X4)
40008	Dynamic pocket open: 1 = open pocketing, 0 = closed pocketing (new for X4)
40009	Dynamic pocket retract style (new for X4)
40010	Sister tool type: 0 = none, 1 = distance, 2 = time (new for X4)

PRM_SRF_HMM

12673	Total size of the holder (<i>moved for X4</i>)
12674	Number of segments in the tool holder definition (<i>moved for X4</i>)
12675	Counter to indicate changes in holder (<i>moved for X4</i>)
12726	Holder library (<i>moved for X4</i>)
12727	Holder name (<i>moved for X4</i>)

12729	<i>Size of holder library (moved for X4)</i>
12730	<i>Size of holder name (moved for X4)</i>
PRM_TP HOLDER	(new for X4)

**PRM_TP HOLDER**

12673	Total size of the holder (—moved to this group, X4)
12674	Number of segments in the tool holder definition (—moved to this group, X4)
12675	Counter to indicate changes in holder (—moved to this group, X4)
12726	Holder library (—moved to this group, X4)
12727	Holder name (—moved to this group, X4)
12729	Size of holder library (—moved to this group, X4)
12730	Size of holder name (—moved to this group, X4)

PRM_CIRCLE_5AX

12910–12930	Future use (new for X4)
12931	Circle5ax output format: 0 = 3-axis, 1 = 4-axis, 2 = 5-axis (new for X4)
12932	Use points and lines or points (new for X4)
12933	Tool axis option (new for X4)
12934	Tip position control (new for X4)
12935	Project type (to plane or surface) (new for X4)
12936	Future use (new for X4)
12397	Circle 5ax output format 4-axis type axis selected (0 = X, 1 = Y, 2 = Z) (new for X4)
12938	Plane vector for circle5ax plane option (new for X4)
12939	Plane vector for circle5ax plane option (new for X4)
12940	Plane vector for circle5ax plane option (new for X4)
12941–12943	Future use (new for X4)
PRM_5AX_LIMIT	(new for X4)
PRM_CIRCMILL	(new for X4)

ENT_EXIT

12948	Length of entry/exit as % of tool diameter (new for X4)
12949	Thickness of entry/exit as % of tool diameter (new for X4)

ENT_EXIT002

- 12950 Length of entry/exit as % of tool diameter (**new for X4**)
 12951 Thickness of entry/exit as % of tool diameter (**new for X4**)

**PRM_MINTILT**

- 12944 **Minimum Tilt** option is enabled (**new for X4**)
 12945 Minimum tilt type (**new for X4**)
 12946 Maximum tilt angle (**new for X4**)
 12947 Tilt application: minimize tilt motion? (**new for X4**)

PRM_LGROOVE

- 13403 Finish dwell type: 0 = none, 1 = seconds, 2 = revolutions (**new for X4**)
 13404 Finish dwell time (seconds) (**new for X4**)
 13405 Finish dwell (revolutions) (**new for X4**)
 13406 1 = Enable **First Plunge Feed Rate** option (**new for X4**)
 13407 Feed rate of first cut to depth (**new for X4**)
 13408 Feed rate type of first cut to depth: R = feed/rev, M = feed/minute (note: output is the ASCII code for R or M) (**new for X4**)
 13409 1 = Enable **Finish feed rate** option (**new for X4**)
 13410 Finish feed rate (**new for X4**)
 13411 Finish feed type: R = feed/rev, M = feed/minute, S=surface finish (micro-in or micron) (note: output is the ASCII code for R/M/S) (**new for X4**)
 13412 1 = Enable **Finish spindle speed** option (**new for X4**)
 13413 Finish spindle speed (**new for X4**)
 13414 Finish spindle speed mode: 1 = CSS, 0 = RPM (**new for X4**)
 13415 1 = Implement **Tool Inspection** stop (**new for X4**)
 13416 Tool inspection position: 0 = Home position, 1 = User defined (**new for X4**)
 13417 1 = Enable stop after **Each groove** (**new for X4**)
 13418 1 = Enable stop after **Each depth cut** (**new for X4**)
 99999 1 = Enable stop after **First plunge** (**new for X4**)
 13419 1 = Enable stop after specified **Number of plunges** (**new for X4**)



13420	<i>Not implemented</i> (new for X4)
13421	<i>Not implemented</i> (new for X4)
13422	Number of plunges between stops (new for X4)
13423	<i>Not implemented</i> (new for X4)
13424	<i>Not implemented</i> (new for X4)
13425	Finish groove overlap position: 0 = User-selected position, 1 = middle of groove (new for X4)
13426	Overlap distance: used when overlap is in the middle of the groove (new for X4)
13427	1 = Enable tool inspection comment (new for X4)
13428	Text string for tool inspection comment (new for X4)
13429	1 = Enable the Use reference points option on tool inspection retract and approach moves (new for X4)
13430	Type of retract position for tool inspection: 1 = absolute, 0 = incremental (new for X4)
13431	1 = Enable retract move in world X axis (typically this appears in the dialog box as Z) (new for X4)
13432	1 = Enable retract move in world Y axis (typically this appears in the dialog box as X or D). (new for X4)
13433	(not currently used) (new for X4)
13434	World X coordinate of tool inspection coordinates (typically this appears in the dialog box as Z). This could be absolute or incremental (see 13430). (new for X4)
13435	World Y coordinate of tool inspection coordinates (typically this appears in the dialog box as X or D). This is always output as a radius value. This could be absolute or incremental. (see 13430) (new for X4)
13436	(not currently used) (new for X4)

PRM_LCUSTOM

13382	Custom Parameters enabled for lathe misc ops? 1 = Custom Parameters option selected, otherwise 0. (new for X4)
-------	---

13383–13392	Integer custom parameter values. (new for X4)
13393–13402	Real custom parameter values (new for X4)

PRM_WIRE_COMMON

14179	Agie library type (new for X4)
14180	Agie library entity ID (new for X4)
14181	Agie library entity ID (new for X4)

14182	Power library type (new for X4)
14183	Power library entity ID (new for X4)
14184	Power library entity ID (new for X4)
14185	C-Hook assigned to Misc Vals button (new for X4)

**LINEAR_AXIS_COMPONENT_TYPE**

17951	1 = the Define macro-driven axis feed rate option is selected. This enables the feed rate option for axis motion events (MT only). (new for X4)
-------	---

ROTARY_AXIS_COMPONENT_TYPE

17952	1 = the Define macro-driven axis feed rate option is selected. This enables the feed rate option for axis motion events (MT only). (new for X4)
-------	---

PRM_AGIE_GROUP_INFO

19527	Piece details: Name (new for X4)
19528	Piece details: Material (new for X4)
19529	Piece details: Quality target (new for X4)
19530	Piece details: Wire (new for X4)
19531	Piece details: Strategy (new for X4)
19532	Piece reference position, C coordinate (new for X4)
19533	Edge position (X) (new for X4)
19534	Edge position (Y) (new for X4)
19535	Edge position (Z) (new for X4)
19536	Security level (new for X4)

chapter 2

Working with Parameters and Toolpath Data



MP posts get information about your part in two ways:

- Toolpath data. This consists of calculated tool motions, feeds and speeds, and commands such as spindle on/off and coolant on/off.
- Operation parameters. These are the raw values entered in your Mastercam dialog boxes when you create toolpaths.

Toolpath data is by far the most important. This information is stored in a generic machine-neutral format called NCI (NC Intermediate). When you post your operations, Mastercam writes this data to a separate ASCII file with a .NCI extension. It is read from here by your post. Every line in the NCI file is processed automatically.

Operation parameters contain all the data in the actual operation structures associated with each toolpath operation in Mastercam, plus a complete record of machine definition, control definition, and machine group properties. They are used to supplement the information from the NCI file. Operation parameters are only available if you explicitly tell your post to go get them and provide storage for them.

Each piece of NCI data or operation parameter has a unique numbered code. The following table summarizes the types of information that are available and how each is accessed:

Table 1: Where your post gets its data from

Type of data	Codes	How is it processed?	Source of data
Toolpath data (individual tool movements, tool change, planes/orientation)	0–1999	<ul style="list-style-type: none">▪ Multiple parameters for each code, automatically saved to predefined variables.▪ Each code processed by associated entry postblock.	NCI file
Tool parameters, material info, comments, other information about your operation.	20000–29999	<ul style="list-style-type: none">▪ All 20000s codes automatically processed by pparameter\$ postblock.▪ Desired parameters must be individually trapped and saved to user-defined variables.	
Operation parameters	10000–16999; 40000–	With pwrrtparam\$ when pre-read is enabled; otherwise, with pparameter\$.	MCX file
MD/CD/machine group settings	MD: 17000–17999 CD: 18000–18999 Machine grp: 19000–19999	Use individual commands to call pmachineinfo\$.	

Working with NCI toolpath data



See [NCI Gcodes](#) starting on page 44 to see a complete list of all the NCI Gcodes.

The NCI file is organized in two-line groups.

- The first line contains a single value. This is the *NCI Gcode*. It tells Mastercam what type of command this is and how to interpret the second line. [NCI Gcodes](#) on page 44 lists all of the possible NCI Gcodes.
- The second line contains parameters for the NCI Gcode. For example, if the first line is the NCI Gcode for a linear motion command, the second line would contain the X, Y, and Z coordinates, feed rate, and other information that MP needs to successfully process the command.

This example shows an actual NCI line set for a rapid move (G0):

```
0
0 2.375 2.375 2.5 -2. 0
```

Definition:

```
g (NCI Gcode)
1 2 3 4 5 6 (six parameters)
```

Where:

g	0: Linear Move at Rapid Feed Rate (NCI Gcode)
1	Cutter Compensation
2	Final X position
3	Final Y position
4	Final Z position
5	Feed rate settings
6	Contour flag

The post executable stores these parameter values in the appropriate predefined MP variables, performs additional calculations to generate values for other predefined variables that are commonly used for the NCI Gcode type being processed, and performs any routines enabled by the post customization file for the NCI Gcode type—for example, breaking an arc at its quadrants.

NCI Gcodes are automatically processed by your post. MP automatically selects the proper postblock for you. All the parameters are automatically stored in predefined variables, where they can be accessed by any postblock.

Customizing these postblocks is outside the scope of this manual. However, this book includes a complete reference of all the NCI Gcodes and their parameters in [NCI Gcodes](#) starting on page 44.

Working with operation (10000s) parameters



Operation parameters are numbered from 10000–16999, and above 30000. Operation parameters:

See **Operation & toolpath parameters**
starting on page 178 for
lists of all the possible
parameters.

- contain all the data in the actual operation structures associated with each toolpath operation in Mastercam.
- constitute an operation-by-operation record of the NC parameters as they are entered in the toolpath dialog boxes, plus a complete record of machine definition, control definition, and machine group properties.
- values can be integers, real values, or strings.

Beginning with Mastercam X3, operation parameters are directly available to MP. This is a change from earlier versions of Mastercam, in which parameters needed to be written to an .OPS file before they could be read by the post. MP includes a number of functions that you can use to query the value of the parameters that you are interested in.

Beginning with Mastercam X4, operation parameters can also be numbered in the 40000s range. This is necessary to accomodate new parameters as new toolpaths and other functionality is added to Mastercam. In addition, the 30000 series has been reserved for parameters that might be defined and used by C-Hook developers. At present, though, there are still very few such parameters, and the term “10000s parameters” should be understood as including 30000 and 40000 parameters also.

Continue reading **Capturing values for 10000s parameters** to learn how to extract these parameters.



NOTE: The following sections describe how to access parameter values using the **pparameter\$** postblock. These sections apply to operation parameters in the 10000–16999 range, and above 30000s tool parameters. See **Working with machine definition, control definition, and machine group parameters** on page 30 to learn about accessing the 17000–19990 parameters.

Capturing values for 10000s parameters



See [Reading parameters during the NCI pre-read routine](#) on page 37 to learn about using `pwrtparam$` instead of `pparameter$`.

Since most parameters do not have predefined variables associated with them, your post needs to have a routine to extract the parameter values before you can use them. Mastercam provides the following building blocks that you can use to construct these routines:

- a single common postblock `pparameter$`, that cycles through all the parameters and reads their values
- a numeric variable `prmcode$` whose value is automatically set to the current parameter number as it is being read
- a string variable `sparameter$` that holds the parameter value as a single string

For example, if you are creating a feature-based pocket toolpath, parameter 12780 is the number of tools that are used. So `prmcode$` would equal `12780`, while `sparameter$` might equal `3`, if the FBM operation used three tools.

The postblock `pparameter$` is called repeatedly for each set of `prmcode$` and `sparameter$` that is read from the MCX file.

To capture a specific parameter value, then, follow this general outline:

- Use the reference section of this manual to identify the number of the parameter you need to capture.
- Create a user-defined variable to store the value of each parameter. This should be either a numeric variable or string to match the parameter.
- Modify the `pparameter$` postblock to trap each desired `prmcode$` value, and store each value in the proper variable.

The following sections give you step-by-step procedures and examples for accessing each type of parameter:

- [Capturing a string from a 10000s parameter](#)
- [Capturing the value of a single 10000s parameter](#)
- [Building a table of parameter values](#)

Capturing a string from a 10000s parameter

The vast majority of operation parameters are numeric values. Common strings such as “CW” or “CCW” are typically encoded as sets of numeric values, such as 0 or 1. However, a few parameters, such as file names, are true string values.



Quick Start



How do I...?

Capturing a string from a 10000s parameter

See **Operation & toolpath parameters** starting on page 178 for a complete list.

- 1 Find the number of the 10000s parameter with the desired string.

- 2 Define a string variable to store the value.

```
s_my_string : " "      # Stores the string
```

- 3 Find the **pparameter\$** postblock and add a line of the following form:

```
if prmcode$ = 1xxxxx, s_my_string = sparameter$
```

where **1xxxxx** is the actual number of the parameter.

- 4 Create a separate line like this for each individual parameter that you wish to capture.



Example

Example 1: Getting a string from a 10000s parameter

This example shows how to get the name of the NCI file, which is available as parameter 15107.

```
snci_file      # Define a string

pparameter$    # Predefined parameter postblock
    if prmcode$ = 15107, snci_file = sparameter$
```

Capturing numeric values from 10000s parameters

To extract a numeric value from the parameter, first get the string from **sparameter\$**, then use the **rpar** function to convert it to a number. The target of **rpar** is the numeric variable that will store the parameter value. This can be either a user-defined variable or a predefined variable.

You can also use the **fprm** function to build tables of parameters and efficiently populate them. For example, you can define tables of parameters for different operation types, and then only populate the tables for operations that are actually posted.



Quick Start

How do I...?

Capturing the value of a single 10000s parameter

Use the **rpar** function to retrieve all the parameters from a 20000s line. It will store them in an array of user-defined variables.

See **Operation & toolpath parameters** starting on page 178 for a complete list.

- 1 Find the number of the desired 10000s parameter.

- 2 Create a user-defined numeric variables to store the value.

```
# Define a numeric variable to store the parameter value
var1 : 0
```

If you wish, you can also use a pre-defined variable.

- 3 Go to your **pparameter\$** postblock and use the **rpar** function to retrieve the values, pointing it to the variable:

```
if prmcode$ = 1xxxx, var1 = rpar(sparameter$, 1)
```

Example

Example 2: Getting the value of a single 10000s parameter

This example uses **rpar** to get the value of parameter 10042, which is the program number.

```
# Define a numeric variable to store the parameter value
my_prog_num : 0

pparameter$      # Predefined parameter postblock
if prmcode$ = 10042, my_prog_num = rpar(sparameter$, 1)
# Capture the 1st numeric value in the parameter string
```



Quick Start

How do I...?

Building a table of parameter values

MP includes a parameter table function that lets you efficiently extract several parameters and store them in a table. You can then use the **fprm** function to retrieve values for all of the parameters in a single statement. The parameter numbers do not need to be in consecutive order.

In addition to operation parameters, you can also use this technique to build tables of machine definition, control definition, or machine group parameters. The only difference is:

- To get operation parameters, place the **fprm** statement in the **pparameter\$** postblock.
- To get MD/CD/group parameters, place the **fprm** statement in the **pmachineinfo\$** postblock.

Follow these steps:

- 1 Define a set of variables to hold the desired parameter values. These can be either strings or numeric variables, or any combination.
- 2 Define an additional numeric variable to hold the result of the **fprm** function (this is only a success or fail value, not the value of any specific parameter)



Your set of variables should look something like this:

```
string1 : 0      # User-defined string variables
string2 : 0
var1 : 0         # User-defined numeric variables
var2 : 0
var3 : 0
result : 0       # Variable to hold fprm return value
```

- 3 Use the **fprmtbl** function to build the table.
 - a On the first line, place the **fprmtbl** statement followed by a number that identifies the table, and another number that indicates how many parameters are in the table.
 - b On the next lines, list the parameter numbers you want to capture, followed by the name of the variable where the value will be stored. Indent each line.

For example:

```
fprmtbl 2      5      # Table Number, Size
                10000  string1  # Toolpath ID (string)
                10001  string2  # Tool String
                10002  var1     # Tool Number
                10003  var2     # Tool Dia. Offset Number
                10004  var3     # Tool Length Number
```

- 4 In the **pparameter\$** postblock (or **pmachineinfo\$**, for MD/CD/group parameters), place the **fprm** function.

The **fprm** function needs to refer to the number of the table, as defined in the **fprmtbl** statement:

```
pparameter$      # Predefined parameter postblock
result = fprm(2)
```

The function returns **1** if the table is found, and **0** if the table is not found.

Storing parameters by opcode\$ value—A common technique is to define tables of parameters for different operation types, numbering each table with the **opcode\$** of the operation it refers to. You can then use a statement like this:

```
pparameter$      # Predefined parameter postblock
result = fprm(opcode$)
```

to automatically load parameters in the proper table that corresponds to the current operation.

Example

Example 3: Building a table of parameter values (fprmtbl & fprm)

The following example uses the **pmachineinfo\$** postblock to build a table of machine definition parameters.

```
axis_label : 0      # Axis label - 1=X,2=Y,3=Z
rot_zero : 0        # Rotary zero degree position
rot_dir : 0         # Rotary direction
```



```

rot_index : 0          # Index or continuous
rot_angle : 0          # Index step
rot_type : 0           # Rotary type
min_speed : 0          # Minimum spindle speed
maxfrinv : 0           # Maximum feedrate - inverse time - inch
maxfrinv_m : 0         # Maximum feedrate - inverse time - metric
maxfrdeg : 0           # Maximum feedrate deg/min
maxfeedpm : 0           # Limit for feed in inch/min
maxfeedpm_m : 0         # Limit for feed in mm/min
all_cool_off : 0        # First coolant off command shuts off
                        # ALL coolant options
result : 0              # return value for fprm function

# Machine Definition Parameters
fprmtbl 17000 14      # Table Number, Size
# Param   Variable to load value into
17391 axis_label      # Axis label - 1=X,2=Y,3=Z
17401 rot_zero         # Rotary zero degree position
17402 rot_dir          # Rotary direction
17408 rot_index         # Index or continuous
17409 rot_angle         # Index step
17410 rot_type          # Rotary type
17605 min_speed         # Minimum spindle speed
17662 maxfrinv          # Maximum feedrate - inverse time - inch
17670 maxfrinv_m         # Maximum feedrate - inverse time - metric
17665 maxfrdeg          # Maximum feedrate deg/min
17643 maxfeedpm          # Limit for feed in inch/min
17651 maxfeedpm_m         # Limit for feed in mm/min
17101 all_cool_off       # First coolant off command shuts off
                        # ALL coolant options

pmachineinfo$  #Machine information parameters postblock
if prmcode$ >= 17000 & prmcode$ < 18000, result = fprm(17000)

```

Validating parameters with UpdatePost



The UpdatePost C-Hook included with Mastercam X4 includes routines that search for references to specific parameter numbers and validates them against known changes. If your original post tries to read a parameter with a number that has changed, the following line will be written to the **updatepost.log** file:

```
PARAMETER DATA -- Possibly incorrect parameter number detected:  
17665. Please check the parameter number.
```

When you see this message, look up the parameter number in the tables in **Parameter Reference** starting on page 177 and make sure that your post is actually referencing the parameter that you want.



IMPORTANT: UpdatePost only looks at parameter numbers in **frm** tables. Postlines that are inside postblocks—for example:

```
pparameter$  
if prmcode$ = 10068, z_stock = rpar(sparameter$, 1)
```

are not validated. If either **pparameter\$** or **pwrtparam\$** is used, you will be alerted so that you can manually check these postblocks.

Working with 2000s lines



The 2000s parameters are similar to the 10000-series parameters, except that they are written directly to the NCI file. The information is written just prior to the actual tool change NCI Gcodes (1000, 1001 and 1002) as a “two line sets” of NCI lines. The first line gives the parameter number, and the second line gives the value of the parameter. For example:

See **Tool information (2000s parameters)**

starting on page 137 for a list of each 20000-series parameter as well as the type of value(s) it contains.

```

20001
1/4 FLAT ENDMILL
20002
20003
20004
1 10 1 0 0.25 0. 0. 180. 1 1 6.4176 6.4176 6.4176 2139 1 4
20006
0 50. 50. 25. 25. 0. 0. 0.
20007
0. 2. 3. 2.5 0.25 2. 1. 0 100. 25. 0
20008
0. 0. 1. 0 0. 0. 0 0. 0.

```

Traditionally, these are called “tool information parameters” because that was their sole original purpose, but in more recent versions of Mastercam their use has been expanded to include other types of data. In general, they are now used for any information about an operation that MP needs to read from the NCI file, instead of retrieved from the MCX file like other operation parameters.

The 20000 lines include integers, real values, or strings. In the example above, the 20001 parameter contains only a single value, a string that is the tool name. However, the 20004 parameter, which encodes the tool definition, contains a series of 16 values. Each value represents a different tool definition parameter.

Continue reading [Capturing parameters from 2000s lines](#) to learn how to extract these parameters.



NOTE: Beginning with Mastercam X, 2000s lines are also written for null tool changes; in previous versions, these were only written for actual tool changes.

Capturing parameters from 20000s lines



Unlike the 0–1999 NCI Gcodes, parameters written out with a 20000s line do not have predefined variables associated with them. This means that your post needs to have a routine to extract the parameter values before you can use them. You can use many of the same building blocks that are available for extracting 10000s parameters to extract 200000s parameters:

- a single common postblock **pparameter\$**, is automatically called as each 20000s line is read from the NCI file.
- a numeric variable **prncode\$** whose value is automatically set to the 20000s NCI Gcode as it is being read.
- a string variable **sparameter\$** that holds the parameter value(s) as a single string.

To capture a specific parameter value, then, follow this general outline:

- Use the reference section of this manual to identify the specific number of the 20000s line you need to capture.
- Create a user-defined variable to store the value of each parameter. This should be either a numeric variable or string to match the parameter.
- Modify the **pparameter\$** postblock to trap each desired NCI value, and store each parameter value in the proper variable.

Some 20000s lines are accompanied by only a single string value, while others have several numeric variables. The following sections give you step-by-step procedures and examples for capturing each type of parameter:

- [Capturing a string from a 20000s line](#)
- [Capturing numeric values from a 20000s line](#)

Capturing a string from a 20000s line

Use the **pparameter\$** postblock to capture strings that are written out to the NCI file on 20000s lines. Follow these steps:



How do I...?

Capturing a string from a 20000s line

- 1 Find the number of the 20000s line with the desired string.
 - ◆ See [Tool information \(20000s parameters\)](#) starting on page 137 for a complete list.
- 2 Define a string variable to store the value.

```
s_my_string : " "      # Stores the string
```

- 3 Find the **pparameter\$** postblock and add a line of the following form:

```
if prmcode$ = 2xxxxx, s_my_string = sparameter$
```

where **2xxxxx** is the actual number of the 20000s line.

- 4 Create a separate line like this for each individual parameter that you wish to capture.

Example

Example 4: Getting a string from a 20000s line

This example shows how to get the name of the tool plane, which is output on line 20012.

```
stool_plane      # Define a string

pparameter$      # Predefined parameter postblock
if prmcode$ = 20012, stool_plane = sparameter$
# Capture the parameter string
```

Capturing numeric values from a 20000s line

Recall that 20000s lines can contain a series of values, which can be either integer or real values. In this case, the value of **sparameter\$** will be a string that contains a series of values separated by spaces. For example, this is what is written to the NCI file for a 20004 line (20004 contains tool definition parameters):

```
20004
1 10 0 0 0.2 0. 0. 45. 1 1 0. 0. 0. 0 8 4
```

To use these values, you must capture the string and pull out the desired values. There are separate functions for each of the following tasks:

- capturing all of the values from the string
- capturing a single value from the string (X3 or later)
- capturing a range of values from the string (X3 or later)

Each is described in the following examples.



NOTE: The functions to capture a single parameter and a range of parameters were introduced in Mastercam X3. If you are using Mastercam X2 or earlier, you need to capture all of the parameters. Follow the steps in **Capturing all the parameters in a 20000s line and storing them in an array**.

How do I...?

Capturing all the parameters in a 20000s line and storing them in an array

Use the **rpar** function to retrieve all the parameters from a 20000s line. It will store them in an array of user-defined variables.

- 1 Go to **Tool information (20000s parameters)** starting on page 137.
 - a Look up the desired 20000s line number.
 - b See how many values are included in the output string.
- 2 Create a series of unique, user-defined numeric variables to store the results—one variable for each value in the string.

```
# User-defined numeric variables
# (This creates an implied array)
var1 : 0
var2 : 0
var3 : 0
var4 : 0
var5 : 0
```

- 3 Go to your **pparameter\$** postblock and use the **rpar** function to retrieve the values, pointing it to the first variable in the list:

```
if prmcode$ = 2xxxx, var1 = rpar(sparameter$, 5)
```

where:

- **2xxxx** is the actual number of the 20000s line
- **var1** is the first variable in your array
- **5** is the actual number of variables in your array



Quick Start

 **Example**
Example 5: Capturing all the values from a 20000s line (rpar)

This example uses **rpar** to get the aggregate head parameters from the 20008 line. There are 8 values output with this particular line.

```
# Numeric variables to hold '20008' agg head parameters
# Do NOT change the order of these (9) variable definitions !

hd_ax_x    : 0          # Head axis in X
hd_ax_y    : 0          # Head axis in Y
hd_ax_z    : 0          # Head axis in Z
hd_body_typ : 0          # Head body type
hd_body_dia : 0          # Head body diameter
hd_body_len : 0          # Head body length
stat_body_typ : 0        # Station body type
stat_body_dia : 0        # Station body diameter
stat_body_len : 0        # Station body length

pparameter$      #Read operation parameters
if prmcode$ = 20008,  hd_ax_x = rpar(sparameter$, 8)
```


 **How do I...?**
Capturing a single parameter from a 20000s line

Use the **rparsngl** function to retrieve a single parameter from a 20000s line. It will be stored in a user-defined variable.

NOTE: This procedure is used for retrieving a single numeric value from a line with several values. To capture a single string, see [Capturing a string from a 20000s line](#) on page 22.

1 Go to [Tool information \(20000s parameters\)](#) starting on page 137.

- a** Look up the desired 20000s line number.
- b** Identify which parameter in the string contains the desired value.

2 Create a numeric variables to store the value.

```
# User-defined numeric variables
var1 : 0  # parameter value
```

3 Go to your **pparameter\$** postblock and use the **rparsngl** function to retrieve the values, pointing it to the first variable in the list:

```
if prmcode$ = 2xxxx, var1 = rparsngl(sparameter$, 9)
```

where:

- **2xxxx** is the actual number of the 20000s line
- **var1** is the variable where you want to store the value
- **9** is the location of the value in the parameter string

Example

Example 6: Getting a single number from a 20000s line (`rparsngl`)



This example uses the `rparsngl` to get the station body length from the 20008 line of aggregate head parameters. Since it gets the desired value directly, there is no need for the predefined array. You only need to define a single variable for the value you are retrieving.

```
gauge_length : 0      #Station body length

pparameter$          #Read operation parameters
if prmcode$ = 20008, gauge_length = rparsngl(sparameter$, 9)
```

How do I...?

Capturing a range of parameters from a 20000s line

Use the `rparsprm` function to retrieve a range of parameters from a 20000s line—for example, if there are 9 parameters output on a 20000s line, you can use this function to capture parameters 3–7. The values will be stored in an array of user-defined variables. Follow these steps:

- 1 Go to [Tool information \(20000s parameters\)](#) starting on page 137.
 - a Look up the desired 20000s line number.
 - b Identify which parameters in the string contain the desired values. These should be a continuous block of values.
- 2 Create a series of unique, user-defined numeric variables to store the results—one variable for each value in the range that you are capturing.

```
# User-defined numeric variables
# (This creates an implied array)
var1 : 0
var2 : 0
var3 : 0
var4 : 0
var5 : 0
```

- 3 Go to your `pparameter$` postblock and use the `rparsprm` function to retrieve the values, pointing it to the first variable in the list:

```
if prmcode$ = 2xxxx, var1 = rparsprm(x, y)
```

where:

- **2xxxx** is the actual number of the 20000s line.
- **var1** is the variable where you want to store the value.
- **x** is the index position of the first parameter in `sparameter$` that you want to retrieve.
- **y** is the total number of parameters to retrieve. This should equal the number of variables that defined in your array.

Example

Example 7: Getting a range of numbers from a 20000s line (`rparsprm`)

This example uses `rparsprm` to get the fourth through seventh values from the 20007 line. Using `rpar`, you would have needed to define seven variables to store all

seven values. Using **rparsprm**, you only need to define variables for just the four values that you want to retrieve.


```
# User-defined numeric variables
# (This creates an implied array)
tl_shoulder_length : #Shoulder length
tl_arbor_diam       : #Arbor diameter
tl_holder_diam      : #Holder diameter
tl_holder_length    : #Holder length

parameter$          #Read operation parameters
if prmcode$ = 20007, tl_shoulder_length = rparsprm(4, 4)
```



Lathe tool inspection comments

Mastercam X4 introduced a tool inspection feature for lathe grooves. This lets you retract the tool between depth cuts or between grooves to inspect or change the tool. For example, in this toolpath, the tool inspection has been programmed between grooves:



The NCI output for this feature has two components.

- The retract move to the inspection position. This is indicated by the same 70000 **cur_cflag\$ (rpd_typ\$ = 7)** used for the Mill tool inspection feature in the surface high-speed toolpaths.
- A comment that is written to the NCI just before the 70000 move. A new 29999 NCI code has been created for this comment.

To implement this feature in your post, therefore, you need to process both elements.

Unlike other 20000s lines, which are written to the NCI before the tool change line, the 29999 is written in the middle of the toolpath, at the point where the tool inspection is to take place.

The following picture shows the NCI for a lathe groove toolpath, with and without the tool inspection. You can see how the retract move and new codes are implemented.

<pre>c:\mcamx4\lathe\nci\no_tool_inspection.nci* 198 199 1000 200 0 100 2 23 23 5000 1 -200 -0.0025 0 201 202 203 204 205 206 207 208 209 0 210 0 0.85 0. -2.6875 1000. 0 211 1 212 0 0.625 0. -2.6875 -0.0025 3000 213 0</pre>	<pre>c:\mcamx4\lathe\nci\with_tool_inspection.nci* 198 199 1000 200 0 100 2 23 23 5000 1 -200 -0.0025 201 0 202 0 3. 0. -1.3875 1000. 30000 203 29999 204 Your comment here... 205 0 206 0 3. 0. 12. 1000. 70000 207 0 208 0 3. 0. -2.6875 1000. 30000 209 0 210 0 0.85 0. -2.6875 1000. 40000 211 1 212 0 0.625 0. -2.6875 -0.0025 3000 213 0</pre>
---	--

The first step in processing the tool inspection move is to trap the 70000 value. This needs to be done in the entry postblocks for both linear and rapid moves. For posts based

on Mastercam's generic posts, these are typically **prapidout** and **plinout**. The following example shows how this can be done.



Example

Example 8: Modifying plinout/prapidout to trap a tool inspection move

The highlighted lines show the new lines that were added to process the flag for a tool inspection. These lines will trap both mill and lathe tool inspection codes. The tool inspection code triggers a call to a new postblock, **ptool_insp**, that will actually process the move.

```

prapidout      #Output to NC, linear movement - rapid
    pcan1, pbld, n$, psgplane, pexct, psgcode, psccomp, pwcs,
    pxout, pyout, pzout, pcout, pscool, strcantext, e$
    if rpd_typ$ = 7, ptool_insp      #Tool inspection point

plinout       #Output to NC, linear movement - feed
    pcan1, pbld, n$, psgplane, sgfeed, pexct, psgcode, psccomp,
    pwcs, pxout, pyout, pzout, pcout, pfr, pscool, strcantext, e$
    if rpd_typ$ = 7, ptool_insp      #Tool inspection point

```

It is a good practice to create a new postblock to hold the processing logic for the tool inspection. In this example, the new postblock is **ptool_insp**.

The tool inspection postblock needs to do the following:

- Since the lathe tool inspection uses the same 70000 flag as the mill/HST tool inspection, mill-turn posts need to be able to distinguish between a mill and lathe tool inspection.
- Handle the 29999 comment.
- When the tool returns to the part, restore the machine operation mode that was in effect before the inspection. At a minimum, this will include the motion mode and feed rate; coolant state; and work offset.

Example 9 shows how this postblock was implemented in the MPLFAN.PST generic post.

Example

Example 9: Tool inspection postblock

This example outputs an M00 at the inspection point. This should be customized to the proper code for your machine.

It also outputs an additional default comment in addition to the one entered with the tool inspection toolpath. This is only a place holder indicating that this is a generic solution that has not been customized for a specific machine. Remove this comment when you customize this for your customers' machines and replace it with whatever code, if any, is appropriate for your application.

```

ptool_insp      #Tool inspection point
    #Modify following lines to customize output for tool inspection
    if posttype$ = 2, #Lathe tool inspection point
        [
            "(TOOL INSPECTION POINT - POST CUSTOMIZATION
            MAY BE REQUIRED)", e$
            if prmcode$ = 29999, #Only output tool insp comment if one
                was entered with this insp point
        [
            sparameter$ = ucase(sparameter$)

```



```

pbld, n$, *sm00, "(", sparameter$, ")", e$
]
else, pbld, n$, *sm00, e$          #Output just the stop
                                    if no comment
pbld, n$, *sgcode, *toolno, e$    #Restate tool number
pbld, n$, pfsgplane, e$          #Restate plane code
prpm   # Output programmed RPM   #Restate spindle
prv_feed = c9k      #Set prv_values to c9k to force them out
                     with next moves
prv_gcode$ = c9k
prv_workofs$ = c9k
if coolant$, prv_coolant$ = c9k
]
else, #Mill tool inspection point
pbld, n$, *sm00, "(TOOL INSPECTION POINT - POST CUSTOMIZATION
REQUIRED)", e$
```

The following picture shows the before-and-after NC output generated by the post logic in the preceding examples:

<pre> 22 G0 X1.7 23 z-1.375 24 G1 X1.25 25 X1.275 z-1.3875 26 27 28 29 30 31 32 33 34 G0 X1.7 35 z-2.6875 36 G1 X1.25 37 G0 X1.7 38 z-2.75 39 G1 X1.25 40 X1.275 z-2.7375 41 G0 X1.7 </pre>	<pre> 22 G0 X1.7 23 z-1.375 24 G1 X1.25 25 X1.275 z-1.3875 26 G0 X1.7 27 X6. 28 Z12. 29 (TOOL INSPECTION POINT - POST CUSTOMIZATION MAY 30 M00 (YOUR COMMENT HERE...) 31 G0 T2323 32 G18 33 G97 S127 M03 34 G0 G54 z-2.6875 35 X1.7 36 G1 X1.25 F.0025 37 G0 X1.7 38 z-2.75 39 G1 X1.25 40 X1.275 z-2.7375 41 G0 X1.7 </pre>
---	--

Working with machine definition, control definition, and machine group parameters



Machine definition, control definition, and machine group parameters are a special subset of operation parameters. They occupy the following ranges of numbers:

- Machine definition: 17000–17999
- Control definition: 18000–18999
- Machine group properties: 19000–19999

Many of the techniques for reading regular operation parameters also apply to these parameters, but there are a couple of important differences:

- These parameters are read by **pmachineinfo\$** postblock instead of **pparameters\$**.
- Instead of being read automatically, you need to use specific commands to read them. These commands are:
 - **rd_cd\$** is used for the active control definition.
 - **rd_t1pathgrp\$** is used to for the active machine group.
 - **rd_md\$** is used for the active machine definition.

Place one of these command words on an output postline in any postblock to have them automatically call **pmachineinfo\$** and process the desired parameters.

Because of the way that **pmachineinfo\$** is called, you can access the MD/CD/group parameters from essentially any postblock. For example, Mastercam's generic posts use them in the **pprep\$** postblock:

```
pprep$      # Pre-process postblock - Allows post instructions
            # after the post is parsed but before the NC and NCI
            # file are opened.

# DO NOT ATTEMPT TO OUTPUT TO THE NC FILE IN THIS POSTBLOCK
# (OR ANY POSTBLOCKS YOU MAY CALL FROM HERE) BECAUSE THE NC OUTPUT
# FILE IS NOT YET OPENED!
    rd_cd$          # Read CD Parameters
    rd_mch_ent_no$ = 0 # Read only the machine base parameters
    rd_md$          # Read machine definition parameters
```

To capture the parameters, follow this general outline:

- Create and initialize the variables you will use to store the parameter values.
- Use **rd_cd\$**, **rd_md\$**, **rd_t1pathgrp\$**, or **rd_params\$** to call the proper postblock.
- Modify **pmachineinfo\$** to trap the desired parameter value.

Separate sections give you specific step-by-step instructions for each type of parameter:

- **Capturing machine definition parameters**
- **Capturing control definition parameters**
- **Capturing machine group parameters**

Capturing machine definition parameters

The `rd_md$` command relies on a helper variable, `rd_mch_ent_no$`, to specify the scope of the parameters to retrieve. Set the value of `rd_mch_ent_no$` before calling `rd_md$`. Based on its value, `rd_md$` will return parameters for either:

- a specific component
- the current axis combination
- general machine parameters; in other words, parameters that apply to the machine as a whole, instead of a particular component
- the entire machine definition. This might not be very useful unless you implement additional specific processing for whatever your application goals might be, since many of the parameters repeat for each component and each successive component will overwrite the previous component as it is read.

Therefore, to get all the parameters for the entire machine definition, `rd_md$` needs to be called multiple times, once for each distinct entity in the machine definition. Each entity corresponds to an individual component in the machine definition tree, such as a single axis, spindle, chuck, etc.

The value of `rd_mch_ent_no$` is interpreted according to the following table:

Value	Interpretation
-2	Uses the value of <code>sparameter\$</code> to find the axis combination. For example, <code>sparameter\$</code> might equal “Upper Left.” (The value of <code>sparameter\$</code> needs to be set before this call.)
-1	Reads the entire machine definition file. The order is base parameters, axis combinations, and then components.
0	Reads only the parameters for general machine properties. Only those parameters included in the CNC_MACHINE_TYPE group on page 322 are included.
any positive number	Represents the entity ID of the component. First the axis combinations are checked for a match and then the components.



Getting the entity ID

Successfully getting machine definition parameters requires that you first be able to get the entity ID, so that you can point `rd_mch_ent_no$` to the right component. There are several ways to do this.



Learn more:

20600 : Axis combination components NCI line.

Capturing numeric values from a 20000s line to learn more about getting the value.

M R L 950 : Axis combination NCI line.

20601 : Axis combination info NCI line.

- First, if you are only interested in general machine properties, you can simply set `rd_mch_ent_no$` to **0** and not worry about it.
- If you want parameters for a specific component, the entity ID is output with the NCI 20600 line for each component.
 - ◆ Each component in the current axis combination is output on a separate 20600 line.
 - ◆ The entity ID is the first parameter in the line.

These are output before the tool change NCI line, along with the other 20000-series lines. You can use `pparameter$` to query these lines for the component ID just like any other 20000-series parameter.

- If you want the parameters for the axis combination, the entity ID of the axis combination is available via the `syncaxis$` predefined variable. This is passed to MP with the NCI 950 line. The following line will point `rd_md$` to the current axis combination:

```
rd_mch_ent_no$ = syncaxis$
```

The entity ID for the axis combination is also output with the NCI 20601 line. This is similar to the 20600 line that is output for each component, and the entity ID can be extracted from this line if you wish. However, it is typically much easier to get it from `syncaxis$`.



How do I...?

Getting a machine definition parameter

Follow these steps to get a single parameter value. If you want to get many parameters, consider building a table; see **Building a table of parameter values** on page 16.

- 1 Go to **Machine definition parameters** starting on page 287 to look up the desired parameter number.
 - a **Machine definition: visual reference** starting on page 287 shows you pictures of all the dialog boxes with the parameter numbers noted.
 - b **Machine definition: list of parameters** starting on page 322 lists all the parameters in tables.
- 2 Create user-defined variables to store the parameter value.
- 3 Identify the postblock where you want to access the parameters. (Typically, this will be in `pprep$` or `psof$`.) In this postblock, set the value of `rd_mch_ent_no$` to the entity ID of the desired component, or to **0** to access the general machine properties.
- 4 Place the `rd_md$` command after the `rd_mch_ent_no$` line.
- 5 Modify `pmachineinfo$` to trap the desired value. Use a line of the form


```
if prmcode$ = 17xxx, var1 = rpar(sparameter$, 1)
```

where **17xxx** is the number of the parameter and **var1** is the variable where you will store the value.

Example

Example 10: Getting a machine definition parameter

The following example gets the state of the **First coolant off...** option. Since this is part of the **General Machine Parameters**, set **rd_mch_ent_no\$** to 0.



```

all_cool_off : 0      # First coolant off command shuts off
                      # ALL coolant options

pprep$               # Pre-process postblock - Allows post instructions
                      # after the post is parsed but before the NC and NCI
                      # file are opened.
      rd_mch_ent_no$ = 0 # Read only the machine base parameters
      rd_md$             # Read machine definition parameters

pmachineinfo$        #Machine information parameters postblock
      if prmcode$ = 17101, all_cool_off = rpar(sparameter$, 1)

```

Example

Example 11: Getting an axis combination parameter and ID

This example shows how to get the name of the axis combination.

```

my_axis_combo       # Define string variable for axis combo name

psof$              # Start of file postblock
      rd_mch_ent_no$ = syncaxis$ # get entity ID for axis combo
                                  # and point rd_md$ to axis combo
      rd_md$             # Get the machine entity parameters

pmachineinfo$       # Parameter capture postblock
      # Get axis combo name string
      if prmcode$ = 17201, my_axis_combo = sparameter$

```

Capturing control definition parameters

To capture control definition parameters, insert the **rd_cd\$** command on a postline in the postblock where you want to read the parameters. Then, modify the **pmachineinfo\$** postblock to trap the desired parameter numbers.



How do I...?

Getting a control definition parameter

Follow these steps to get a single parameter value. If you want to get many parameters, consider building a table; see [Building a table of parameter values](#) on page 16.

- 1 Go to [Control definition parameters](#) starting on page 350 to look up the desired parameter number.
 - a [Control definition: visual reference](#) starting on page 350 shows you pictures of all the dialog boxes with the parameter numbers noted.
 - b [Control definition: list of parameters](#) starting on page 380 lists all the parameters in tables.
- 2 Create user-defined variables to store the parameter value.
- 3 Identify the postblock where you want to access the parameters and add the **rd_cd\$** command on a postline.
- 4 Modify **pmachineinfo\$** to trap the desired value. Use a line of the form

```
if prmcode$ = 18xxxx, var1 = rpar(sparameter$, 1)
```

where **18xxxx** is the number of the parameter and **var1** is the variable where you will store the value.

Example

Example 12: Capturing control definition parameters

This example gets several parameters from the control definition, both string and numeric.

```
ssetup_sheet      # Define string variable for setup sheet string
cd_mtol_in : 0   # Define numeric variable for mtol - inches
cd_mtol_mm : 0   # Define numeric variable for mtol - metric

psof$            # Start of file postblock
rd_cd$          # Get the control parameters - call pmachineinfo$

pmachineinfo$    # Parameter capture postblock
# Capture string data for the name of the setup sheet
if prmcode$ = 18160, ssetup_sheet = sparameter$

# Capture numeric data for mtol, inch and metric
if prmcode$ = 18055, cd_mtol_in = rpar(sparameter$, 1)
if prmcode$ = 10856, cd_mtol_mm = rpar(sparameter$, 1)
```

Capturing machine group parameters

To capture control definition parameters, insert the `rd_tlpPathgrp$` command on a postline in the postblock where you want to read the parameters. Then, modify the `pmachineinfo$` postblock to trap the desired parameter numbers.



If you are interested in getting parameters for stock, remember that stock models are now considered components in the machine definition. This means that depending on how the stock model is defined—particularly lathe stock models, along with chuck jaws and tailstock centers—some of the parameters that you are interested in might need to be accessed as machine definition component properties, instead of machine group properties.



How do I...?

Getting a machine group parameter

Follow these steps to get a single parameter value. If you want to get many parameters, consider building a table; see [Building a table of parameter values](#) on page 16.

- 1 Go to [Machine group parameters](#) starting on page 397 to look up the desired parameter number.
 - a [Machine group properties: visual reference](#) starting on page 397 shows you pictures of all the dialog boxes with the parameter numbers noted.
 - b [Machine group properties: list of parameters](#) starting on page 402 lists all the parameters in tables.
- 2 Create user-defined variables to store the parameter value.
- 3 Identify the postblock where you want to access the parameters and add the `rd_tlpPathgrp$` command on a postline.
- 4 Modify `pmachineinfo$` to trap the desired value. Use a line of the form

```
if prmcode$ = 19xxxx, var1 = rpar(sparameter$, 1)
```

where `19xxxx` is the number of the parameter and `var1` is the variable where you will store the value.



Example

Example 13: Capturing machine group parameters

This example finds the file name of the machine definition associated with the machine group of the operations being posted, together with the name of the machine group and its number.

```
smd_file_name      # Define string variable for name of
                     # the machine definition file
stp_grp_name       # Define string variable for name of
                     # the machine group
tp_grp_number : 0  # Define numeric variable for the
                     # machine group number

psof$              # Start of file postblock
rd_tlpPathgrp$    # Get the toolpath group parameters -
                     # call pmachineinfo

pmachineinfo$      # Parameter capture postblock
```

```
# Capture numeric data for toolpath group number
if prmcode$ = 18500, tp_grp_number = rpar(sparameter$, 1)

# Capture string data for machine filename and group name
if prmcode$ = 18501, stp_grp_name = sparameter$
if prmcode$ = 18601, smd_file_name = sparameter$
```



Advanced techniques for working with operation parameters



This section discusses several specialized topics and techniques related to reading parameters.

- **Reading parameters during the NCI pre-read routine**
- **Doing a parameter dump: outputting all the parameters**
- **Reading operation parameters from any postblock**
- **Setting options for transform operation parameters**

Reading parameters during the NCI pre-read routine

In addition to reading parameters with **pparameters\$**, you can also read them during the NCI pre-read routine. Set the predefined numeric variable **tooltable\$** to 1 or 3 to activate the pre-read routine for calls to the **pwrtt\$** and **pwrttparam\$** postblocks.

When this happens, the parameters are read by the **pwrttparam\$** postblock instead of **pparameters\$**. This means that your postlines that trap the individual parameter numbers—for example,

```
if prmcode$ = 20007, t1_shoulder_length = rparsprm(4, 4)
```

should be placed in the **pwrttparam\$** postblocks instead of **pparameters\$**.

The the **pwrtt\$** and **pwrttparam\$** postblocks must both be declared in the post customization file. During the pre-read routine, the comment NCI Gcodes (1005, 1006, 1007 and 1008) are read and passed through the numeric variable **prmcode\$** and the string variable **sparameter\$**.

Doing a parameter dump: outputting all the parameters



Sometimes it can be difficult to determine exactly which parameter code contains the parameter that you need for a specific application. Use the techniques described in this section as a “brute force” approach to isolating the parameter code.

The key is to add the following line to the **pparameter\$** postblock:

```
~prmcode$, ~sparameter$, e$
```

This forces out the value of every **prmcode\$** that is available for the posted operations, together with its value.

This line is included in most of Mastercam’s generic posts, including MPFAN.PST and MPLFAN.PST, but is commented out by default:

```
#"pparameter", ~prmcode$, ~sparameter$, e$
```

Simply remove the **#** to activate the line and dump the parameters.

Follow these steps to work through an example.



How do I...?

Dumping all the parameters

- 1 Modify the **pparameter\$** postblock by removing the comment code from the following line:

```
pparameter$ #Information from parameters
"pparameter", ~prmcode$, ~sparameter$, e$
```

Add the line to your **pparameter\$** postblock if it does not already exist.

- 2 If you also want to dump the machine definition, control definition, and machine group parameters, follow these steps:

- a Modify the **pmachineinfo\$** postblock by removing the comment code from the following line:

```
-->pmachineinfo", ~prmcode$, " ", ~sparameter$, e$
```


Add this line to your **pmachineinfo\$** postblock if it does not already exist.

- b Make sure that the following lines are in your **pprep\$** postblock:

```
rd_cd$
rd_mch_ent_no$ : -1
rd_md$
rd_tlpathergrp$
```

- 3 Create a toolpath of the type that has the parameter you are looking for.

This example will demonstrate finding the **prmcode\$** values for the **Stock to leave on walls** and **Stock to leave on floors** for a contour toolpath. For this example, create a 2D contour toolpath with the following settings:



- 4** For the two fields that you are interested in, enter distinctive values that are not likely to be used anywhere else.

When you look at the NC file created by your modified .PST file, that contains a very long list of all the parameters, the distinctive values that were entered for the two fields should make them easy to find.

- 5** Open the NC output file into a text editor and do a search for the “unique” values—in this case, for **Stock to leave on walls** and **Stock to leave on floors**.

The search for **0.01234** finds this line in the NC file:

```
pparameter prmcode$ 10010. 0.01234
```

The search for **0.09876** finds this line in the NC file:

```
pparameter prmcode$ 10068. 0.09876
```

These are most likely the desired **prmcode\$** values.

- 6** To verify that these are the correct **prmcode\$** values, go back to the **Contour parameters tab** in Mastercam and change one of them to a new value. Re-post the operation and search the NC file for the new value.

If you find the new value with the same **prmcode\$**, you can be confident that you have found the correct **prmcode\$** that you can use to retrieve this specific parameter.

Reading operation parameters from any postblock

Recall that the `rd_md$`, `rd_cd$`, and `rd_t1pathgrp$` commands can be placed in any postblock. There is also a similar command, `rd_params$`, that can be used to read operation parameters from any postblock. Typically, this is of little use, since all it does is call `pparameter$` and it is more efficient to do this with the techniques already presented in this chapter, but if you have a pressing application need for this, the `rd_param$` command is available.

The `rd_param$` command relies on a helper variable called `rd_prm_op_no$`. This specifies the `op_id$` of the operation whose parameters are to be read.

Example

Example 14: Reading parameters with the `rd_param$` command

This example captures both string and numeric parameters. The operation type is a string value; the number of rough cuts and their spacing are numeric values.

```
sop_type_name      # Define string variable for the operation type
num_rough_cuts : 0 # Define numeric variable for the
                   # number of rough cuts
spcng_rough_cuts : 0 # Define numeric variable for
                   # the spacing between the rough cuts

psof$              # Start of file postblock
rd_prm_op_no$ = 0  # The number of the operation whose
                   # parameters you want to retrieve
rd_params$         # Get the parameters - call pparameter$

pparameter$         # Parameter capture postblock
# Get operation type string
if prmcode$ = 10000, sop_type_name = sparameter$

# Capture numeric data for component ID and type
if prmcode$ = 10106, num_rough_cuts = rpar(sparameter$, 1)
if prmcode$ = 10107, spcng_rough_cuts = rpar(sparameter$, 1)
```



Quick Start


Setting options for transform operation parameters

The control definition includes an option that lets you specify which parameters to make available when you create transform operations:

- parameters for the transform operation
- parameters for the source operation
- both sets of parameters



You can find this setting on the **Files** page in the **Control Definition Manager**:



The setting itself is available as parameter 18157.



chapter 3

NCI Reference



This chapter lists all of the Gcodes that are output in the NCI file. It is divided into two main sections:

- ❖ **NCI Gcodes**page 44
- ❖ **Tool information (20000s parameters)**page 137

Each parameter that is output on line 2 with the Gcode or parameter is also documented. Typically, these correspond to pre-defined variables.

NCI Gcodes



See [Working with NCI toolpath data](#) on page 12 for more information.

This section lists all of the NCI Gcodes in Mastercam X4. However, it does not include any of the Gcodes that are used specifically for event-based programming for Mastercam MT.

- Each entry is preceded by a lettered code indicating which product(s) the entry applies to.
- The table following each entry lists the predefined post variables used to store each parameter.

[Control Flags Parameters](#) are detailed in a separate section on page 133.

M R 0 : Linear Move at rapid rate

Definition: 0
 1 2 3 4 5 6

1	Cutter compensation	cc\$, ccomp\$	0	Cutter compensation modal (no change)
			40	Cancel cutter compensation in the control
			41	Cutter compensation in the control = left
			42	Cutter compensation in the control = right
			140	Cancel cutter compensation last move in the contour
2	X position	xnci\$, x\$		
3	Y position	ynci\$, y\$		
4	Z position	znci\$, z\$		
5	Feed rate	fr\$	Positive	Feed rate in units per minute
			-1	Unchanged
			-2	Rapid
6	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.

L 0 : Linear Move at rapid rate

Definition: 0
1 2 3 4 5 6



1	Cutter compensation	cc\$, ccomp\$	0	Cutter compensation modal (no change)
			40	Cancel cutter compensation in the control
			41	Cutter compensation in the control = left
			42	Cutter compensation in the control = right
			140	Cancel cutter compensation last move in the contour
2	X position	xnci\$, x\$		
3	Y position	ynci\$, y\$		
4	Z position	znci\$, z\$		
5	Feed rate	fr\$	Positive Negative	Feed rate in units per minute Feed rate in units per revolution
6	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.

W 0 : Linear move at rapid rate

Definition: 0
1 2 3 4 5 6 7 8 9



1	Wire compensation	cc\$, ccomp\$	0	Wire compensation modal (no change)
			40	Cancel wire compensation in the control
			41	Wire compensation in the control = left
			42	Wire compensation in the control = right
			140	Cancel wire compensation last move in the contour
2	X position	xnci\$, x\$		
3	Y position	ynci\$, y\$		
4	Z position	znci\$, z\$		
5	Feed rate	fr\$	Positive	Feed rate in units per minute
			-1	Unchanged
6	Wire taper	wt\$		
7	Corner type	wc\$	0	Conical
			1	Sharp
			2	Constant
			3	Other
			4	Fixed
			5	Fishtail
8	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.
9	Corner type radius	wc_rad\$		

M R 1 : Linear Move at feed rate

Definition: 1
1 2 3 4 5 6



1	Cutter compensation	cc\$, ccomp\$	0	Cutter compensation modal (no change)
			40	Cancel cutter compensation in the control
			41	Cutter compensation in the control = left
			42	Cutter compensation in the control = right
			140	Cancel cutter compensation last move in the contour
2	X position	xnci\$, x\$		
3	Y position	ynci\$, y\$		
4	Z position	znci\$, z\$		
5	Feed rate	fr\$	Positive	Feed rate in units per minute
			-1	Unchanged
			-2	Rapid
6	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.

L 1 : Linear Move at feed rate

Definition: 1
1 2 3 4 5 6



1	Cutter compensation	cc\$, ccomp\$	0	Cutter compensation modal (no change)
			40	Cancel cutter compensation in the control
			41	Cutter compensation in the control = left
			42	Cutter compensation in the control = right
			140	Cancel cutter compensation last move in the contour
2	X position	xnci\$, x\$		
3	Y position	ynci\$, y\$		
4	Z position	znci\$, z\$		
5	Feed rate	fr\$	Positive	Feed rate in units per minute
			Negative	Feed rate in units per revolution
6	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.

W 1 : Linear move at feed rate

Definition: 1
1 2 3 4 5 6 7 8 9



1	Wire compensation	cc\$, ccomp\$	0	Wire compensation modal (no change)
			40	Cancel wire compensation in the control
			41	Wire compensation in the control = left
			42	Wire compensation in the control = right
			140	Cancel wire compensation last move in the contour
2	X position	xnci\$, x\$		
3	Y position	ynci\$, y\$		
4	Z position	znci\$, z\$		
5	Feed rate	fr\$	Positive	Feed rate in units per minute
			-1	Unchanged
6	Wire taper	wt\$		
7	Corner type	wc\$	0	Conical
			1	Sharp
			2	Constant
			3	Other
			4	Fixed
			5	Fishtail
8	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.
9	Corner type radius	wc_rad\$		

M R 2 : Arc Move CW

Definition: 2
 1 2 3 4 5 6 7 8 9 10



1	Plane position	plane\$	0	XY plane
			1	YZ plane
			2	XZ plane
2	Cutter compensation	cc\$, ccomp\$	0	Cutter compensation modal (no change)
			40	Cancel cutter compensation in the control
			41	Cutter compensation in the control = left
			42	Cutter compensation in the control = right
			140	Cancel cutter compensation last move in the contour
3	X position	xnci\$, x\$		
4	Y position	ynci\$, y\$		
5	Absolute X axis arc center	xc\$		(relative to plane)
6	Absolute Y axis arc center	yc\$		(relative to plane)
7	Z position	znci\$, z\$		
8	Feed rate	fr\$	Positive	Feed rate per minute
			Negative	Feed rate per revolution
			-1	Unchanged
			-2	Rapid
9	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.
10	Full arc flag	full_arc_flg\$	0	NOT a full arc move
			1	Full arc move (360-degree sweep)

L 2 : Arc Move CW

Definition: 2
1 2 3 4 5 6 7 8 9 10

1	Plane position	plane\$	(Not used)
2	Cutter compensation	cc\$, ccomp\$	0 Cutter compensation modal
			40 Cancel cutter compensation in the control
			41 Cutter compensation in the control = left
			42 Cutter compensation in the control = right
			140 Cancel cutter compensation last move in the contour
3	X position	xnci\$, x\$	
4	Y position	ynci\$, y\$	
5	Absolute X axis arc center	xc\$	(relative to plane)
6	Absolute Y axis arc center	yc\$	(relative to plane)
7	Z position	znci\$, z\$	
8	Feed rate	fr\$	Positive Feed rate in units per minute
			Negative Feed rate in units per revolution
9	Control flags	cur_cflg\$	See Control Flags Parameters on page 133.
10	Full arc flag	full_arc_flg\$	0 NOT a full arc move
			1 Full arc move (360-degree sweep)

W 2 : Arc move clockwise



Definition: 2

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

1	(Not used)		
2	Wire compensation	cc\$, ccomp\$	0 Wire compensation modal (no change) 40 Cancel wire compensation in the control 41 Wire compensation in the control = left 42 Wire compensation in the control = right 140 Cancel wire compensation last move in the contour
3	X position	xnci\$, x\$	
4	Y position	ynci\$, y\$	
5	Absolute X-axis arc center	xc\$	(relative to plane)
6	Absolute Y-axis arc center	yc\$	(relative to plane)
7	Z position	znci\$, z\$	
8	Feed rate	fr\$	Positive
			-1 Unchanged
9	Wire taper	wt\$	
10	Corner type	wc\$	0 Conical 1 Sharp 2 Constant 3 Other 4 Fixed 5 Fishtail
11	Control flags	cur_cflg\$	See Control Flags Parameters on page 133.
12	Corner type radius	wc_rad\$	
13	Arc type	warc_ctyp\$	0 Conical 1 Sharp 2 Constant 3 Other 4 Fixed 5 Fish Tail
14	Arc type radius	wcor_rad\$	
15	Full arc flag	full_arc_flg\$	0 NOT a full arc move 1 Full arc move (360-degree sweep)

M R 3 : Arc Move CCW

Definition: 3
1 2 3 4 5 6 7 8 9 10

1	Plane position	plane\$	0	XY plane
			1	YZ plane
			2	XZ plane
2	Cutter compensation	cc\$, ccomp\$	0	Cutter compensation modal (no change)
			40	Cancel cutter compensation in the control
			41	Cutter compensation in the control = left
			42	Cutter compensation in the control = right
			140	Cancel cutter compensation last move in the contour
3	X position	xnci\$, x\$		
4	Y position	ynci\$, y\$		
5	Absolute X axis arc center	xc\$		(relative to plane)
6	Absolute Y axis arc center	yc\$		(relative to plane)
7	Z position	znci\$, z\$		
8	Feed rate	fr\$	Positive	Feed rate per minute
			Negative	Feed rate per revolution
			-1	Unchanged
			-2	Rapid
9	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.
10	Full arc flag	full_arc_flg\$	0	NOT a full arc move
			1	Full arc move (360-degree sweep)

L 3 : Arc Move CCW



Definition: 3
1 2 3 4 5 6 7 8 9 10

1	Plane position	plane\$	(Not used)
2	Cutter compensation	cc\$, ccomp\$	0 Cutter compensation modal 40 Cancel cutter compensation in the control 41 Cutter compensation in the control = left 42 Cutter compensation in the control = right
		140	Cancel cutter compensation last move in the contour
3	X position	xnci\$, x\$	
4	Y position	ynci\$, y\$	
5	Absolute X axis arc center	xc\$	
6	Absolute Y axis arc center	yc\$	
7	Z position	znci\$, z\$	
8	Feed rate	fr\$	Positive Feed rate in units per minute Negative Feed rate in units per revolution
9	Control flags	cur_cflg\$	See Control Flags Parameters on page 133.
10	Full arc flag	full_arc_flg\$	0 NOT a full arc move 1 Full arc move (360-degree sweep)

W 3 : Arc move counterclockwise



Definition:

3

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

1	(Not used)		
2	Wire compensation	cc\$, ccomp\$	0 Wire compensation modal (no change) 40 Cancel wire compensation in the control 41 Wire compensation in the control = left 42 Wire compensation in the control = right 140 Cancel wire compensation last move in the contour
3	X position	xnci\$, x\$	
4	Y position	ynci\$, y\$	
5	Absolute X-axis arc center	xc\$	(relative to plane)
6	Absolute Y-axis arc center	yc\$	(relative to plane)
7	Z position	znci\$, z\$	
8	Feed rate	fr\$	Positive Feed rate per minute -1 Unchanged
9	Wire taper	wt\$	
10	Corner type	wc\$	0 Conical 1 Sharp 2 Constant 3 Other 4 Fixed 5 Fishtail
11	Control flags	cur_cflg\$	See Control Flags Parameters on page 133.
12	Corner type radius	wc_rad\$	
13	Arc type	warc_ctyp\$	0 Conical 1 Sharp 2 Constant 3 Other 4 Fixed 5 Fish Tail
14	Arc type radius	wcor_rad\$	
15	Full arc flag	full_arc_flg\$	0 NOT a full arc move 1 Full arc move (360-degree sweep)

L 4 : Dwell and Spindle Change



Definition: **4**
 1 2 3

1	Dwell	dwell\$		Dwell time
2	Spindle speed	ss\$	Positive	Spindle speed in RPM
			0	Spindle stop
			Negative	Spindle speed in surface units per minute
3	(Not used)			

M R 4 : Dwell and Spindle Change

Definition: **4**
 1 2 3



1	Dwell	dwell\$	Dwell time
2	Spindle speed	ss\$	Positive
			0 Negative
3	Spindle direction	spdir\$	

W 4 : Dwell

Definition: **4**
 1 2 3



1	Dwell	dwell\$	Dwell time
2	(Not used)		
3	(Not used)		

M R 11 : 5-Axis Move

Definition: 11
1 2 3 4 5 6 7 8 9 10 11 12

1	X position	xnci\$, x\$		
2	Y position	ynci\$, y\$		
3	Z position	znci\$, z\$		
4	U position	u\$		
5	V position	v\$		
6	W position	w\$		
7	Feed rate	fr\$	Positive -1 -2	Feed rate Unchanged Rapid
8	*Tool parameters = rev5+cutpos+cuttyp	'nnn' rev5\$ cutpos\$ cuttyp\$	000 100 200 300 400 500 10 20 30 40 50 1 2 3 4	Zero angle 5-axis flip (not vertical), same angle as previous Same angle as next 180-degree angle Same angle as previous + 180 degrees Same angle as next + 180 degrees Start Middle End Entry to cut Exit from cut Zigzag One way Circular Swarf
9	Control flags	cur_cflg\$	See Control Flags Parameters on page 133.	
10	Surface normal vector	p_svec\$		
11	Surface normal vector	q_svec\$		
12	Surface normal vector	r_svec\$		

* These are maintained for compatibility only. Use the Control Flags Parameter instead!

W 11 : 4-Axis Taper Move

Definition: 11
1 2 3 4 5 6 7 8 9



1	Wire compensation	cc\$, ccomp\$	0	Wire compensation modal (no change)
			40	Cancel wire compensation in the control
			41	Wire compensation in the control = left
			42	Wire compensation in the control = right
			140	Cancel wire compensation last move in the contour
2	X position	xnci\$, x\$		lower point
3	Y position	ynci\$,y\$		lower point
4	Z position	znci\$,z\$		lower point
5	U position	u\$		upper point
6	V position	v\$		upper point
7	W position	w\$		upper point
8	Feed rate	fr\$		Feed rate
9	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.

W 20 : Direct 4-axis lower guide – linear move at rapid

Definition: 20
1 2 3 4 5 6 7 8 9

1	Wire compensation	cc\$, ccomp\$	0	Wire compensation modal (no change)
			40	Cancel wire compensation in the control
			41	Wire compensation in the control = left
			42	Wire compensation in the control = right
			140	Cancel wire compensation last move in the contour
2	X position	xnci\$, x\$		
3	Y position	ynci\$, y\$		
4	Z position	znci\$, z\$		
5	Feed rate	fr\$	Positive	Feed rate in units per minute
			-1	Unchanged
6	Wire taper	wt\$		
7	Corner type	wc\$	0	Conical
			1	Sharp
			2	Constant
			3	Other
			4	Fixed
			5	Fishtail
8	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.
9	Corner type radius	wc_rad\$		

W 21 : Direct 4-axis lower guide – linear move at feed rate

Definition: **21**
 1 2 3 4 5 6 7 8 9



1	Wire compensation	cc\$, ccomp\$	0	Wire compensation modal (no change)
			40	Cancel wire compensation in the control
			41	Wire compensation in the control = left
			42	Wire compensation in the control = right
			140	Cancel wire compensation last move in the contour
2	X position	xnci\$, x\$		
3	Y position	ynci\$, y\$		
4	Z position	znci\$, z\$		
5	Feed rate	fr\$	Positive	Feed rate in units per minute
			-1	Unchanged
6	Wire taper	wt\$		
7	Corner type	wc\$	0	Conical
			1	Sharp
			2	Constant
			3	Other
			4	Fixed
			5	Fishtail
8	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.
9	Corner type radius	wc_rad\$		

W 22 : Direct 4-axis lower guide – arc move clockwise*Definition:* 22

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

1	(Not used)		
2	Wire compensation	cc\$, ccomp\$	0 Wire compensation modal (no change) 40 Cancel wire compensation in the control 41 Wire compensation in the control = left 42 Wire compensation in the control = right 140 Cancel wire compensation last move in the contour
3	X position	xnci\$, x\$	
4	Y position	ynci\$, y\$	
5	Absolute X-axis arc center	xc\$	(relative to plane)
6	Absolute Y-axis arc center	yc\$	(relative to plane)
7	Z position	znci\$, z\$	
8	Feed rate	fr\$	Positive -1 Feed rate per minute Unchanged
9	Wire taper	wt\$	
10	Corner type	wc\$	0 Conical 1 Sharp 2 Constant 3 Other 4 Fixed 5 Fishtail
11	Control flags	cur_cflg\$	See Control Flags Parameters on page 133.
12	Corner type radius	wc_rad\$	
13	Arc type	warc_ctyp\$	0 Conical 1 Sharp 2 Constant 3 Other 4 Fixed 5 Fish Tail
14	Arc type radius	wcor_rad\$	
15	Full arc flag	full_arc_flg\$	0 NOT a full arc move 1 Full arc move (360-degree sweep)

W 23 : Direct 4-axis lower guide – arc move counterclockwise*Definition:* **23**

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

1	(Not used)		
2	Wire compensation	cc\$, ccomp\$	0 Wire compensation modal (no change) 40 Cancel wire compensation in the control 41 Wire compensation in the control = left 42 Wire compensation in the control = right 140 Cancel wire compensation last move in the contour
3	X position	xnci\$, x\$	
4	Y position	ynci\$, y\$	
5	Absolute X-axis arc center	xc\$	(relative to plane)
6	Absolute Y-axis arc center	yc\$	(relative to plane)
7	Z position	znci\$, z\$	
8	Feed rate	fr\$	Positive -1 Feed rate per minute Unchanged
9	Wire taper	wt\$	
10	Corner type	wc\$	0 Conical 1 Sharp 2 Constant 3 Other 4 Fixed 5 Fishtail
11	Control flags	cur_cfg\$	See Control Flags Parameters on page 133.
12	Corner type radius	wc_rad\$	
13	Arc type	warc_ctyp\$	0 Conical 1 Sharp 2 Constant 3 Other 4 Fixed 5 Fish Tail
14	Arc type radius	wcor_rad\$	
15	Full arc flag	full_arc_flg\$	0 NOT a full arc move 1 Full arc move (360-degree sweep)

W 30 : Direct 4-axis upper guide – linear move at rapid

Definition: **30**
1 2 3 4 5 6 7 8 9

1	Wire compensation	cc\$, ccomp\$	0	Wire compensation modal (no change)
			40	Cancel wire compensation in the control
			41	Wire compensation in the control = left
			42	Wire compensation in the control = right
			140	Cancel wire compensation last move in the contour
2	X position	wx\$		
3	Y position	wy\$		
4	Z position	wz\$		
5	Feed rate	wfr\$	Positive	Feed rate in units per minute
			-1	Unchanged
6	Wire taper	wtp\$		
7	Corner type	wcor\$	0	Conical
			1	Sharp
			2	Constant
			3	Other
			4	Fixed
			5	Fishtail
8	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.
9	Corner type radius	wcor_rad\$		

W 31 : Direct 4-axis upper guide – linear move at feed rate

Definition: 31
1 2 3 4 5 6 7 8 9



1	Wire compensation	cc\$, ccomp\$	0	Wire compensation modal (no change)
			40	Cancel wire compensation in the control
			41	Wire compensation in the control = left
			42	Wire compensation in the control = right
			140	Cancel wire compensation last move in the contour
2	X position	wx\$		
3	Y position	wy\$		
4	Z position	wz\$		
5	Feed rate	wfr\$	Positive -1	Feed rate in units per minute Unchanged
6	Wire taper	wtp\$		
7	Corner type	wcor\$	0 1 2 3 4 5	Conical Sharp Constant Other Fixed Fishtail
8	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.
9	Corner type radius	wcor_rad\$		

W 32 : Direct 4-axis upper guide – arc move clockwise*Definition:* 32

1 2 3 4 5 6 7 8 9 10 11 12 13 14

1	(Not used)		
2	Wire compensation	cc\$, ccomp\$	0 Wire compensation modal (no change) 40 Cancel wire compensation in the control 41 Wire compensation in the control = left 42 Wire compensation in the control = right 140 Cancel wire compensation last move in the contour
3	X position	wx\$	
4	Y position	wy\$	
5	Absolute X-axis arc center	wxc\$	(relative to plane)
6	Absolute Y-axis arc center	wyc\$	(relative to plane)
7	Z position	wz\$	
8	Feed rate	wfr\$	Positive -1 Feed rate per minute Unchanged
9	Wire taper	wtp\$	
10	Corner type	wcor\$	0 Conical 1 Sharp 2 Constant 3 Other 4 Fixed 5 Fishtail
11	Control flags	cur_cflg\$	See Control Flags Parameters on page 133.
12	Corner type radius	wcor_rad\$	
13	Arc type	warc_cortyp\$	0 Conical 1 Sharp 2 Constant 3 Other 4 Fixed 5 Fish tail
14	Arc type radius	wcor_radius\$	

W 33 : Direct 4-axis upper guide – arc move counterclockwise

Definition: **33**
1 2 3 4 5 6 7 8 9 10 11 12 13 14

1	(Not used)		
2	Wire compensation	cc\$, ccomp\$	0 Wire compensation modal (no change) 40 Cancel wire compensation in the control 41 Wire compensation in the control = left 42 Wire compensation in the control = right 140 Cancel wire compensation last move in the contour
3	X position	wx\$	
4	Y position	wy\$	
5	Absolute X-axis arc center	wxc\$	(relative to plane)
6	Absolute Y-axis arc center	wyc\$	(relative to plane)
7	Z position	wz\$	
8	Feed rate	wfr\$	Positive -1 Feed rate per minute Unchanged
9	Wire taper	wtp\$	
10	Corner type	wcor\$	0 Conical 1 Sharp 2 Constant 3 Other 4 Fixed 5 Fishtail
11	Control flags	cur_cflg\$	See Control Flags Parameters on page 133.
12	Corner type radius	wcor_rad\$	
13	Arc type	warc_cortyp\$	0 Conical 1 Sharp 2 Constant 3 Other 4 Fixed 5 Fish tail
14	Arc type radius	wcor_radius\$	

L M R W 80 : Cancel Drill / Canned Cycle

Definition: 80
[blank line]



Note: Even though Gcode 80 has no parameters, a blank line must be output for the second line.

L 81 : Start Canned Cycle



Definition: 81

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19

1	Drill cycle type	drillcyc\$	0	Simple
			1	Peck
			2	Chip break
			3	Tap
			4	Bore #1
			5	Bore #2
			6	Misc #1
			7	Misc #2
			8-19	Custom cycles
2	X position	*drl_depth_x\$, x\$		XYZ is a 3D point that represents the drill point at the bottom of the hole.
3	Y position	*drl_depth_y\$, y\$		XYZ is a 3D point that represents the drill point at the bottom of the hole.
4	Z position	*drl_depth_z\$, z\$, depth\$		XYZ is a 3D point that represents the drill point at the bottom of the hole.
5	Dwell time	dwell\$		
6	Feed rate	frplunge\$		
7	First peck amount	peck1\$		
8	Subsequent peck amount	peck2\$		
9	Peck clearance	peckclr\$		
10	Chip break retract	retr\$		
11	Drill cycle initial height	initht\$		
12	Drill cycle reference height	refht\$		
13	Drill depth	zdrl\$		
14	Boring bar clearance shift amount	shftdrl\$		
15	W position**	w\$		UW is a 2D point that represents the initial height point.
16	U position**	u\$		UW is a 2D point that represents the initial height point.
17	(Not used)			
18	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.
19	Drill depth	rev_drl5\$	1	Indicates reversal of the drill direction from UVW to XYZ.

If **vers_no** is 8 or greater, the following data is calculated and overwrites the parameters passed in the NCI:

- **depth** from **z**
- **zdrl** (calculated) from **w – initht**
- **refht** from **zdrl** (calculated) + **refht**
- **tosz** (top of stock) from **zdrl** (calculated) + **zdrl** (original)
- **initht** from **w**
- **xdrl** from **x**



M R 81 : Start Drill Cycle



Definition:

81

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19

1	Drill cycle type	*drl_cycle\$, drillcyc\$	0	Simple
			1	Peck
			2	Chip break
			3	Tap
			4	Bore #1
			5	Bore #2
			6	Misc #1
			7	Misc #2
			8-	Custom cycles
			19	
2	X position	*drl_depth_x\$, x\$		XYZ is a 3D point that represents the drill point at the bottom of the hole.
3	Y position	*drl_depth_y\$, y\$		XYZ is a 3D point that represents the drill point at the bottom of the hole.
4	Z position	*drl_depth_z\$, z\$, depth\$		XYZ is a 3D point that represents the drill point at the bottom of the hole.
5	Dwell time	*dwell\$		
6	Feed rate	*frplunge\$		
7	First peck amount	*peck1\$		
8	Subsequent peck amount	*peck2\$		
9	Peck clearance	*peckclr\$		
10	Chip break retract	*retr\$		
11	Drill cycle initial height	*drl_sel_ini\$, initht\$		The distance from the selected drill position (zdrl) to the <i>initial</i> height, sign is positive for above selected drill position.
12	Drill cycle reference height	*drl_sel_ref\$, refht\$		The distance from the selected drill position (zdrl) to the <i>reference</i> height, sign is positive for above selected drill position.
13	Drill depth	*drl_sel_tos zdrl\$		The distance from the selected drill position (zdrl) to the <i>top of stock</i> , sign is positive for above selected drill position.
14	Boring bar clearance shift amount	*shftdrl\$		
15	U position	*drl_init_x \$, u\$		UVW is a 3D point that represents the initial height point.

16	V position	*drl_init_y \$, v\$	UVW is a 3D point that represents the initial height point.
17	W position	*drl_init_z \$, w\$	UVW is a 3D point that represents the initial height point.
18	Control flags	cur_cfg\$	See Control Flags Parameters on page 133.
19	Drill depth	*rev_drl5\$	When 1, indicates reversal of the drill direction from UVW to XYZ.

The * prefacing the variable names above indicates that these are the values read from the NCI file data. The other variables are calculated by MP.

Note: If **vers_no** is 8 or greater, the following data is calculated and overwrites the parameter passed in the NCI:

- **depth** from **z**
- **zdrl** (calculated) from **w - initht**
- **refht** from **zdrl** (calculated) + **refht**
- **tosz** (top of stock) from **zdrl** (calculated) + **zdrl** (original)
- **initht** from **w**



Quick Start

W 81 : Start Canned Cycle

Definition: 81

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19



1	Drill cycle type	cancyc\$	0-19	Custom cycles
2	X position*	xnci\$, x\$		XYZ is a 3D point that represents the drill point at the bottom of the hole.
3	Y position*	ynci\$, y\$		XYZ is a 3D point that represents the drill point at the bottom of the hole.
4	Z position*	znci\$, z\$		XYZ is a 3D point that represents the drill point at the bottom of the hole.
5	Entered value	canned1\$		
6	(Not used)	\$		
7	Entered value	canned4\$		
8	Entered value	canned5\$		
9	Entered value	canned6\$		
10	Entered value	canned7\$		
11	Entered value	canned2\$		
12	Entered value	canned3\$		
13	(Not used)			
14	(Not used)			
15	(Not used)			
16	(Not used)			
17	(Not used)			
18	Control flags	cur_cflg\$		See Control Flags Parameters on page 133.
19	(Not used)			

L M R W 82 : Additional Drill / Canned Cycle Parameters

Definition: **82**
1 2 3 4 5 6 7 8 9 10

1	Drill parameter 1	drl prm1\$	
2	Drill parameter 2	drl prm2\$	
3	Drill parameter 3	drl prm3\$	
4	Drill parameter 4	drl prm4\$	
5	Drill parameter 5	drl prm5\$	
6	Drill parameter 6	drl prm6\$	
7	Drill parameter 7	drl prm7\$	
8	Drill parameter 8	drl prm8\$	
9	Drill parameter 9	drl prm9\$	
10	Drill parameter 10	drl prm10\$	

NOTE: The **drl prm** variables do not have a specific meaning; they are values that the post customization file can use for whatever purpose needed for that cycle.

R 83 : Block Drill / Canned Cycle Parameters



Definition: 83
1 2 3 4 5 6 7 8 9 10 11 12

1	Drill point (X) position at depth.	bdrl_x\$	Position of the <i>lead</i> tool
2	Drill point (Y) position at depth.	bdrl_y\$	Position of the <i>lead</i> tool
3	Drill point (Z) position at depth.	bdrl_z\$	Position of the <i>lead</i> tool
4	Offset to lead tool in X	bdrl_ofs_x\$	Distance of drill hole to the lead drill position.
5	Offset to lead tool in Y	bdrl_ofs_y\$	Distance of drill hole to the lead drill position.
6	Offset to lead tool. In Z	bdrl_ofs_z\$	Distance of drill hole to the lead drill position.
7	Tool group number	bdrl_tool_grp\$	
8	Work offset number	bdrl_wrk_ofs\$	
9	Position of lead drill at initial height.	bdrl_u\$	Clearance point position in X
10	Position of lead drill at initial height.	bdrl_v\$	Clearance point position in Y
11	Position of lead drill at initial height.	bdrl_w\$	Clearance point position in Z
12	Bitwise tool number	bdrl_tool_no \$	In this parameter, the data is stored in "bitwise" format.

Note: MP also reads the following variables when block drilling is active: **bdrl_x2**, **bdrl_y2**, and **bdrl_z2**. These three values are actually read from NCI **M R 81 : Start Drill Cycle** and **M R 100 : Canned Cycle Repeat Position** data records. They are the actual drilled location (which may not be the lead tool position) at depth.

M R 100 : Canned Cycle Repeat Position



Definition: 100

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23

1	(Not used)		
2	X position	*drill_depth_x\$, x\$	XYZ is a 3D point that represents the drill point at the bottom of the hole.
3	Y position	*drill_depth_y\$, y\$	XYZ is a 3D point that represents the drill point at the bottom of the hole.
4	Z position	*drill_depth_z z\$	XYZ is a 3D point that represents the drill point at the bottom of the hole.
5	Drill cycle reference height	*drl_sel_ref\$, refht\$	The distance from the selected drill position (zdrl) to the <i>initial</i> height, sign is positive for above selected drill position.
6	Drill depth	*drl_sel_ref\$, zdrl\$	The distance from the selected drill position (zdrl) to the <i>reference</i> height, sign positive for above selected drill position.
7	Dwell time	*dwell\$	
8	Feed rate	*frplunge\$	
9	U position	*drl_init_x\$, u\$	UVW is a 3D point that represents the initial height point.
10	V position	*drl_init_y\$, v\$	UVW is a 3D point that represents the initial height point.
11	W position	*drl_init_z\$, w\$	UVW is a 3D point that represents the initial height point.
12	Control flags	cur_cflg\$	See Control Flags Parameters on page 133.
13	Drill depth	*rev_drl5\$	When 1, indicates reversal of the drill direction from UVW to XYZ.
14	Top of stock	*drl_sel_tos\$	the distance from the selected drill position (zdrl) to the <i>top of stock</i> , sign positive for above zdrl
15	X vector X	*drl_m1\$	Drilling matrix XX (see **note below)
16	X vector Y	*drl_m2\$	Drilling matrix XY
17	X vector Z	*drl_m3\$	Drilling matrix XZ
18	Y vector X	*drl_m4\$	Drilling matrix YX
19	Y vector Y	*drl_m5\$	Drilling matrix YY
20	Y vector Z	*drl_m6\$	Drilling matrix YZ
21	Z vector X	*drl_m7\$	Drilling matrix ZX
22	Z vector Y	*drl_m8\$	Drilling matrix ZY
23	Z vector Z	*drl_m9\$	Drilling matrix ZZ

The * prefacing the variable names above indicates these are the values read from the NCI file data. The other variables are calculated by MP.

**The matrix (m1-m9) from the NCI 1014 tool plane data is copied to this matrix at the Gcode 81.

This matrix (drl_m1-drl_m9) data is copied to the tool plane matrix (m1-m9) at the Gcode 100.



NOTE: The read parameters changed for Mastercam X. (Also see the [M R 81 : Start Drill Cycle](#) on page 72.)

W 100 : Canned Cycle Repeat Position

Definition: 100
 1 2 3 4 5



1	(Not used)	
2	X position	xnci\$, x\$
3	Y position	ynci\$, y\$
4	Z position	znci\$, z\$
5	(Not used)	

L 200 : Threading Parameters One



Definition: 200
1 2 3 4 5 6 7 8

1	Number of spring cuts	nspring\$	
2	Finish allowance	thdfinish\$	
3	Anticipated thread pull-off	thdpulloff\$	
4	Number of starts	nstarts\$	
5	Clearance perpendicular to cuts	thdxclr\$	
6	Thread infeed angle	thdangle\$	Value in radians
7	Equal depth thread cuts	thdequcut\$	0 Determine depth cuts from: Equal area method. 1 Determine depth cuts from: Number of cuts.
8	Number of cuts	thdncuts\$	>0 Determine number of cuts from: Number of cuts.

Always appears together with the **L 201 : Threading Parameters Two**.

L 201 : Threading Parameters Two



Definition: 201
1 2 3 4 5 6 7 8 9 10 11 12

1	X position 1	thdx1\$	Thread major
2	X position 2	thdx2\$	Thread minor
3	Z position 1	thdz1\$	Starting Z position of thread
4	Z position 2	thdz2\$	Ending Z position of thread
5	Lead settings	thdlead\$	Positive Negative
			Lead in units per thread Lead in threads per inch*
6	Amount of first cut	thdfirst\$	Calculated based on thdequcut\$thdeqcut
7	Amount of last cut	thdlast\$	
8	Stock clearance in Z	thdzclr\$	Acceleration clearance
9	Thread angle	thda1\$	Value in radians
10	Thread included angle	thda2\$	Value in radians
11	Thread type settings	thdtype\$	0 Long cycle (pg32) 1 Canned (pg76) 2 Long cycle (pg92)
12	X position 3	thdx3\$	Ending X position of thread

Always appears together with the L 200 : Threading Parameters One.

- **thdlead\$** is always converted to a (positive) units-per-thread value.
- Calculate thread taper by (**thdx2 – thdx3**).

L 900 : Stock Transfer – Misc Ops function



Definition: 900
1 2 3 4 5 6 7 8 9 10 11

1	Active spindle for stock to transfer	stck_spindle\$	0	Main spindle
			1	Sub spindle
2		stck_init_z\$		Z coordinate on stock to be transferred
3		stck_final_z\$		Z coordinate on transferred stock
4		stck_chuk_st_z\$		Source chuck Z axis reference position <i>before</i> transfer
5		stck_chuk_st_x\$		Source chuck X axis reference position <i>before</i> transfer
6		stck_chuk_end_z\$		Source chuck Z axis reference position <i>after</i> transfer
7		stck_chuk_end_x\$		Source chuck X axis reference position <i>after</i> transfer
8		stck_chuk_st_dz\$		Destination chuck Z axis reference position <i>before</i> transfer
9		stck_chuk_st_dx\$		Destination chuck X axis reference position <i>before</i> transfer
10		stck_chuk_end_dz\$		Destination chuck Z axis reference position <i>after</i> transfer
11		stck_chuk_end_dx\$		Destination chuck X axis reference position <i>after</i> transfer

Processed by postblock **pstck_trans\$.**

L 901 : Stock Flip – Misc Ops function

Definition: 901
1 2 3 4 5 6 7



1	Active spindle for stock to transfer	stck_spindle\$	0	Main spindle
			1	Sub spindle
2		stck_init_z\$		Z coordinate on stock <i>before</i> flip
3		stck_final_z\$		Z coordinate on stock <i>after</i> flip
4		stck_chuk_st_z\$		Chuck Z axis position <i>before</i> flip
5		stck_chuk_st_x\$		Chuck X axis position <i>before</i> flip
6		stck_chuk_end_z\$		Chuck Z axis position <i>after</i> flip
7		stck_chuk_end_x\$		Chuck X axis position <i>after</i> flip

Processed by postblock **pstck_flip\$**.

L 902 : Stock Advance – Misc Ops function



Definition:

902

1 2 3 4 5 6 7 8 9 10 11 12

1	Active spindle for stock to transfer	stck_spindle\$	0	Main spindle
			1	Sub spindle
2		stck_op\$	0	Push stock
			1	Push stock with Use Tool Stop option
			2	Pull stock
3		stck_clear\$		Stock clearance (pull stock method)
4		stck_grip\$		Grip length (pull stock method)
5		stck_init_z\$		Z coordinate of stock <i>before</i> advance
6		stck_final_z\$		Z coordinate of stock <i>after</i> advance
7		stck_appr_fr\$		Feed rate that the bar puller uses while moving into position
8		stck_adv_fr\$		Feed rate that the stock advances at
9		stck_chuk_st_z\$		Chuck Z axis position <i>before</i> advance
10		stck_chuk_st_x\$		Chuck X axis position <i>before</i> advance
11		stck_chuk_end_z\$		Chuck Z axis position <i>after</i> advance
12		stck_chuk_end_x\$		Chuck X axis position <i>after</i> advance

Processed by postblock **pstck_bar_fd\$**.

L 903 : Chuck – Misc Ops function

Definition: **903**
1 2 3 4 5 6

1	Active spindle for clamp/unclamp	clmp_spindle\$	0	main spindle
			1	Sub spindle
2	Operation	clmp_op\$	0	Clamp
			1	Un-clamp
			2	Re-position
3		stck_chuk_st_z\$		Original Z axis Chuck Position
4		stck_chuk_st_x\$		Original X axis Chuck Position
5		stck_chuk_end_z\$		Final Z axis Chuck Position
6		stck_chuk_end_x\$		Final X axis Chuck Position

L 904 : TailStock – Misc Ops function

Definition: **904**
 1 2 3



1	Operation	tlstck_on\$	0	Retract tailstock
			1	Engage tailstock
2		stck_init_z\$		Initial Z position of tailstock
3		stck_final_x\$		Final Z position of tailstock

L 905 : SteadyRest – Misc Ops function



Definition: 905
1 2

1	stck_init_z\$	Initial steady rest position
2	stck_final_z\$	Final steady rest position

Processed by postblock **psteadyrest\$**.

L 911 : Define Misc Ops custom parameters — reals

Definition: **911**
1 2 3 4 5 6 7 8 9 10



1	Miscellaneous real 1	miscops_mr1\$	
2	Miscellaneous real 2	miscops_mr2\$	
3	Miscellaneous real 3	miscops_mr3\$	
4	Miscellaneous real 4	miscops_mr4\$	
5	Miscellaneous real 5	miscops_mr5\$	
6	Miscellaneous real 6	miscops_mr6\$	
7	Miscellaneous real 7	miscops_mr7\$	
8	Miscellaneous real 8	miscops_mr8\$	
9	Miscellaneous real 9	miscops_mr9\$	
10	Miscellaneous real 10	miscops_mr10\$	

L 912 : Define Misc Ops custom parameters — integers

Definition: **912**
 1 2 3 4 5 6 7 8 9 10

1	Miscellaneous integer 1	miscops_mi1\$	
2	Miscellaneous integer 2	miscops_mi2\$	
3	Miscellaneous integer 3	miscops_mi3\$	
4	Miscellaneous integer 4	miscops_mi4\$	
5	Miscellaneous integer 5	miscops_mi5\$	
6	Miscellaneous integer 6	miscops_mi6\$	
7	Miscellaneous integer 7	miscops_mi7\$	
8	Miscellaneous integer 8	miscops_mi8\$	
9	Miscellaneous integer 9	miscops_mi9\$	
10	Miscellaneous integer 10	miscops_mi10\$	

M R L 950 : Axis combination

Definition:

950

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22
23 24 25 26



4	syncaxis\$	Component ID of axis combination
[all other parameters]	(Not used)	

M R L W 999 : Start of operation



Definition: 999
 1 2 3

This NCI Gcode is currently only useful for Mastercam MultiTasking.

1	Code for specific operation type	tool_op\$	See the following sections for lists of operation codes: M R L 1016 : Additional Miscellaneous Parameters on page 114 W 1016 : Additional Miscellaneous Parameters on page 115
2	data stream	synchstream\$	
3	Operation ID numbers	op_id\$	

M R 1000 : Null tool change*Definition:* 1000

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18



1	Program number	progno\$	
2	Starting sequence number	seqno\$	
3	Sequence number increment	seqinc\$	
4	Tool number	t\$	
5	Tool diameter offset number	tloffno\$	
6	Tool length offset number	tlnchno\$	
7	Plane position	plane\$	0 XY plane 1 YZ plane 2 XZ plane
8	Spindle speed in RPM	ss\$	Positive Spindle forward 0 Spindle stop Negative Spindle reverse
9	Feed rate	fr\$	
10	Coolant use	coolant\$	0 Off 1 Flood 2 Mist 3 Tool
11	X rapid position	xr\$	
12	Y rapid position	yr\$	
13	Z rapid position	zr\$	
14	X home position	xh\$	
15	Y home position	yh\$	
16	Z home position	zh\$	
17	Axis substitution	rotaxis\$	-2 Axis substitution, substitute Y, CCW -1 Axis substitution, substitute X, CCW 0 None 1 Axis substitution, substitute X, CW 2 Axis substitution, substitute Y, CW 11 Polar conversion, rotate about X 12 Polar conversion, rotate about Y 13 Polar conversion, rotate about Z 21 4-axis, rotate about X 22 4-axis, rotate about Y 23 4-axis, rotate about Z

18	Diameter for axis substitution	rotdia\$	
----	-----------------------------------	-----------------	--



L 1000 : Null tool change

Definition: 1000

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18



1	Program number	progno\$	
2	Starting sequence number	seqno\$	
3	Sequence number increment	seqinc\$	
4	Tool number	t\$	
5	Tool diameter offset number	tloffno\$	
6	Maximum spindle speed	maxss\$	
7	Tool orientation	orient\$	
8	Spindle speed	ss\$	Positive Spindle speed in RPM 0 Spindle stop Negative Spindle speed in surface units per minute
9	Feed rate	fr\$	Positive Feed rate in units per minute Negative Feed rate in units per revolution
10	Coolant use	coolant\$	0 Off 1 Flood 2 Mist 3 Tool
11	X rapid position	xr\$	
12	Y rapid position	yr\$	
13	Z rapid position	zr\$	
14	X home position	xh\$	
15	Y home position	yh\$	
16	Z home position	zh\$	
17	Spindle direction	spdir\$	1 Spindle forward 0 Spindle stop -1 Spindle reverse
18	(Not used)		

W 1000 : Null tool change



Definition: 1000

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22

1	Program number	progno\$		
2	Starting sequence number	seqno\$		
3	Sequence number increment	seqinc\$		
4	Cut pass	pass\$		
5	Condition code	ccode\$		
6	Offset number	offset\$		
7	(Not used)			
8	Initial wire taper	inittaper\$	Positive 0 Negative	Taper, right No taper Taper, left
9	Feed rate	fr\$		
10	Flushing	water\$	0 1 2	Off Flood Other
11	X thread position	threadx\$		
12	Y thread position	thready\$		
13	Z thread position	threadz\$		
14	X start position	startx\$		
15	Y start position	starty\$		
16	Z start position	startz\$		
17	Height of XY plane	xyheight\$		
18	Height of UV plane	uvheight\$		
19	X skewed wire thread	up_st_vecx\$		
20	Y skewed wire thread	up_st_vecy\$		
21	Z skewed wire thread	up_st_vecz\$		
22	Skewed wire thread	up_st_mode\$	0 1 2 3	Off Apply to thread Apply to cut Apply to both thread/cut

M R 1001 : Start-of-file tool change

Definition: 1001

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18



1	Program number	progno\$	
2	Starting sequence number	seqno\$	
3	Sequence number increment	seqinc\$	
4	Tool number	t\$	
5	Tool diameter offset number	tloffno\$	
6	Tool length offset number	tlngno\$	
7	Plane position	plane\$	0 XY plane 1 YZ plane 2 XZ plane
8	Spindle speed in RPM	ss\$	Positive Spindle forward 0 Spindle stop Negative Spindle reverse
9	Feed rate	fr\$	
10	Coolant use	coolant\$	0 Off 1 Flood 2 Mist 3 Tool
11	X rapid position	xr\$	
12	Y rapid position	yr\$	
13	Z rapid position	zr\$	
14	X home position	xh\$	
15	Y home position	yh\$	
16	Z home position	zh\$	
17	Axis substitution	rotaxis\$	-2 Axis substitution, substitute Y, CCW -1 Axis substitution, substitute X, CCW 0 None 1 Axis substitution, substitute X, CW 2 Axis substitution, substitute Y, CW 11 Polar conversion, rotate about X 12 Polar conversion, rotate about Y 13 Polar conversion, rotate about Z 21 4-axis, rotate about X 22 4-axis, rotate about Y 23 4-axis, rotate about Z

18	Diameter for axis substitution	rotdia\$	
----	-----------------------------------	-----------------	--



L 1001 : Start-of-file tool change

Definition: 1001

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18



1	Program number	progno\$	
2	Starting sequence number	seqno\$	
3	Sequence number increment	seqinc\$	
4	Tool number	t\$	
5	Tool diameter offset number	tloffno\$	
6	Maximum spindle speed	maxss\$	
7	Tool orientation	orient\$	
8	Spindle speed	ss\$	Positive Spindle speed in RPM 0 Spindle stop Negative Spindle speed in surface units per minute
9	Feed rate	fr\$	Positive Feed rate in units per minute Negative Feed rate in units per revolution
10	Coolant use	coolant\$	0 Off 1 Flood 2 Mist 3 Tool
11	X rapid position	xr\$	
12	Y rapid position	yr\$	
13	Z rapid position	zr\$	
14	X home position	xh\$	
15	Y home position	yh\$	
16	Z home position	zh\$	
17	Spindle direction	spdri\$	1 Spindle forward 0 Spindle stop -1 Spindle reverse
18	(Not used)		

W 1001 : Start-of-file tool change



Definition: 1001

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22

1	Program number	progno\$		
2	Starting sequence number	seqno\$		
3	Sequence number increment	seqinc\$		
4	Cut pass	pass\$		
5	Condition code	ccode\$		
6	Offset number	offset\$		
7	(Not used)			
8	Initial wire taper	inittaper\$	Positive 0 Negative	Taper, right No taper Taper, left
9	Feed rate	fr\$		
10	Flushing	water\$	0 1 2	Off Flood Other
11	X thread position	threadx\$		
12	Y thread position	thready\$		
13	Z thread position	threadz\$		
14	X start position	startx\$		
15	Y start position	starty\$		
16	Z start position	startz\$		
17	Height of XY plane	xyheight\$		
18	Height of UV plane	uvheight\$		
19	X skewed wire thread	up_st_vecx\$		
20	Y skewed wire thread	up_st_vecy\$		
21	Z skewed wire thread	up_st_vecz\$		
22	Skewed wire thread	up_st_mode\$	0 1 2 3	Off Apply to thread Apply to cut Apply to both thread/cut

M R 1002 : Tool Change

Definition: 1002

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18



1	Program number	progno\$	
2	Starting sequence number	seqno\$	
3	Sequence number increment	seqinc\$	
4	Tool number	t\$	
5	Tool diameter offset number	tloffno\$	
6	Tool length offset number	tlngno\$	
7	Plane position	plane\$	0 XY plane 1 YZ plane 2 XZ plane
8	Spindle speed in RPM	ss\$	Positive Spindle forward 0 Spindle stop Negative Spindle reverse
9	Feed rate	fr\$	
10	Coolant use	coolant\$	0 Off 1 Flood 2 Mist 3 Tool
11	X rapid position	xr\$	
12	Y rapid position	yr\$	
13	Z rapid position	zr\$	
14	X home position	xh\$	
15	Y home position	yh\$	
16	Z home position	zh\$	
17	Axis substitution	rotaxis\$	-2 Axis substitution, substitute Y, CCW -1 Axis substitution, substitute X, CCW 0 None 1 Axis substitution, substitute X, CW 2 Axis substitution, substitute Y, CW 11 Polar conversion, rotate about X 12 Polar conversion, rotate about Y 13 Polar conversion, rotate about Z 21 4-axis, rotate about X 22 4-axis, rotate about Y 23 4-axis, rotate about Z

18	Diameter for axis substitution	rotdia\$	
----	-----------------------------------	-----------------	--



L 1002 : Tool Change

Definition: 1002

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18



1	Program number	progno\$	
2	Starting sequence number	seqno\$	
3	Sequence number increment	seqinc\$	
4	Tool number	t\$	
5	Tool diameter offset number	tloffno\$	
6	Maximum spindle speed	maxss\$	
7	Tool orientation	orient\$	
8	Spindle speed	ss\$	Positive Spindle speed in RPM 0 Spindle stop Negative Spindle speed in surface units per minute
9	Feed rate	fr\$	Positive Feed rate in units per minute Negative Feed rate in units per revolution
10	Coolant use	coolant\$	0 Off 1 Flood 2 Mist 3 Tool
11	X rapid position	xr\$	
12	Y rapid position	yr\$	
13	Z rapid position	zr\$	
14	X home position	xh\$	
15	Y home position	yh\$	
16	Z home position	zh\$	
17	Spindle direction	spdir\$	1 Spindle forward 0 Spindle stop -1 Spindle reverse
18	(Not used)		

W 1002 : Tool Change

Definition: 1002

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22



1	Program number	progno\$		
2	Starting sequence number	seqno\$		
3	Sequence number increment	seqinc\$		
4	Cut pass	pass\$		
5	Condition code	ccode\$		
6	Offset number	offset\$		
7	(Not used)			
8	Initial wire taper	inittaper\$	Positive 0 Negative	Taper, right No taper Taper, left
9	Feed rate	fr\$		
10	Flushing	water\$	0 1 2	Off Flood Other
11	X thread position	threadx\$		
12	Y thread position	thready\$		
13	Z thread position	threadz\$		
14	X start position	startx\$		
15	Y start position	starty\$		
16	Z start position	startz\$		
17	Height of XY plane	xyheight\$		
18	Height of UV plane	uvheight\$		
19	X skewed wire thread	up_st_vecx\$		
20	Y skewed wire thread	up_st_vecy\$		
21	Z skewed wire thread	up_st_vecz\$		
22	Skewed wire thread	up_st_mode\$	0 1 2 3	Off Apply to thread Apply to cut Apply to both thread/cut

M R 1003 : End of File

Definition: 1003
1 2 3



1	X home position	xh\$	
2	Y home position	yh\$	
3	Z home position	zh\$	

L 1003 : End of File

Definition: 1003
1 2 3

1	X home position	xh\$	
2	(Not used)		
3	Z home position	zh\$	

W 1003 : End of File

Definition: 1003
1 2 3

1	X thread position	threadx\$	
2	Y thread position	thready\$	
3	Z thread position	threadz\$	

L M R W 1004 : Cancel Cutter Compensation

Definition: 1004
[blank line]

Note: Even though Gcode 1004 has no parameters, a blank line must be output for the second line.

L M R W 1005 : Manual Entry / Comment before

Definition: 1005
comment



Text to be inserted into the NC program	
--	--

L M R W 1006 : Manual Entry / Comment after

Definition: 1006
comment

Text to be inserted into the NC program	
--	--

L M R W 1007 : Manual Entry / Comment with

Definition: 1007
comment

Text to be inserted into the NC program	
--	--

L M R W 1008 : Manual Entry / Tool operation comment

Definition: 1008
comment

Text to be inserted into the NC program	
--	--

W 1009 : Wire Cut Length (obsolete)

Definition: 1009
1 2 3



1	Wirepath cut length	cutlength\$
2	(Not used)	
3	(Not used)	

Note: This NCI Gcode is no longer output.

W 1010 : Wire Condition Change

Definition: 1010
1 2 3 4 5 6 7 8 9 10 11 12 13 14

1	Wire compensation	cc\$	0	Cutter compensation modal (no change)
			40	Cancel cutter compensation in the control
			41	Cutter compensation in the control = left
			42	Cutter compensation in the control = right
			140	Cancel cutter compensation last move in the contour
2	Condition code	ccode\$		
3	Wire offset	offset\$		
4	Wire diameter	tldia\$		
5	Register value 1	reg1\$		
6	Register value 2	reg2\$		
7	Register value 3	reg3\$		
8	Register value 4	reg4\$		
9	Register value 5	reg5\$		
10	Register value 6	reg6\$		
11	Register value 7	reg7\$		
12	Register value 8	reg8\$		
13	Register value 9	reg9\$		
14	Register value 10	reg10\$		

L M R W 1011 : Define Miscellaneous Reals

Definition: **1011**
 1 2 3 4 5 6 7 8 9 10



1	Miscellaneous real 1	mr1\$	
2	Miscellaneous real 2	mr2\$	
3	Miscellaneous real 3	mr3\$	
4	Miscellaneous real 4	mr4\$	
5	Miscellaneous real 5	mr5\$	
6	Miscellaneous real 6	mr6\$	
7	Miscellaneous real 7	mr7\$	
8	Miscellaneous real 8	mr8\$	
9	Miscellaneous real 9	mr9\$	
10	Miscellaneous real 10	mr10\$	

L M R W 1012 : Define Miscellaneous Integers

Definition: **1012**
 1 2 3 4 5 6 7 8 9 10

1	Miscellaneous integer 1	mi1\$	
2	Miscellaneous integer 2	mi2\$	
3	Miscellaneous integer 3	mi3\$	
4	Miscellaneous integer 4	mi4\$	
5	Miscellaneous integer 5	mi5\$	
6	Miscellaneous integer 6	mi6\$	
7	Miscellaneous integer 7	mi7\$	
8	Miscellaneous integer 8	mi8\$	
9	Miscellaneous integer 9	mi9\$	
10	Miscellaneous integer 10	mi10\$	

M R 1013 : Define Miscellaneous Parameters

Definition: 1013
1 2 3 4 5 6 7 8 9 10



1	Cutter compensation use	cc\$	0	Cutter compensation modal
			40	Cancel cutter compensation in the control
			41	Cutter compensation in the control = left
			42	Cutter compensation in the control = right
			140	Cancel cutter compensation last move in the contour
2	Tool diameter	tldia\$		
3	Tool corner radius	tcr\$		
4	Depth values to center or tip setting	cctotip\$	0	Center
			1	Tip
5	View number	tplinno\$		The number of the view in Mastercam's view catalog. View numbers 1–8 correspond to Mastercam's standard system-defined views. If the view is a user-defined view, this will be a different, higher number.
			0	No matrix
			1	Top
			2	Front
			3	Back
			4	Bottom
			5	Right side
			6	Left side
			7	Isometric
			8	Axonometric
6	X coordinate of tool plane origin	tox\$		(relative to view)
7	Y coordinate of tool plane origin	toy\$		(relative to view)
8	Z coordinate of tool plane origin	toz\$		(relative to view)
9	Operation code	opcode\$	1	2D contour
			2	3D contour
			3	Drill
			4	Pocket



		5 Ruled 6 2D swept 7 3D swept 8 Revolution 9 Loft 10 Coons 11 Fillet 12 Flowline 13 Multisurface finish 14 Multisurface rough 15 Point 16 Drill 5-axis 17 Swarf 5-axis 18 Curve 5-axis 19 Facing
10 Tool reference path and name*	strtool\$, strtoolpath\$	

L 1013 : Define Miscellaneous Parameters

Definition: **1013**
 1 2 3 4 5 6 7 8 9 10



1	Cutter compensation	cc\$	0	Cutter compensation modal
			40	Cancel cutter compensation in the control
			41	Cutter compensation in the control = left
			42	Cutter compensation in the control = right
			140	Cancel cutter compensation last move in the contour
2	Tool corner radius	tcr\$		Tool nose radius or tool radius of drill type tool
3	Tool diameter	tldia\$		Always 0
4	(Not used)			
5	(Not used)			
6	X coordinate of tool plane origin	tox\$		(relative to view)
7	Y coordinate of tool plane origin	toy\$		(relative to view)
8	X coordinate of tool plane origin	toz\$		(relative to view)
9	Operation code	opcode\$	101 102 103 104 105 106	Rough Finish Groove Thread Drill Point
10	Tool library path and name*	strtool\$, strtoolpath\$		

W 1013 : Define Miscellaneous Parameters

Definition: 1013
1 2 3 4 5 6 7 8 9 10



1	Cutter compensation use	cc\$	0	Cutter compensation modal
			40	Cancel cutter compensation in the control
			41	Cutter compensation in the control = left
			42	Cutter compensation in the control = right
			140	Cancel cutter compensation last move in the contour
2	Tool (wire) diameter	tldia\$		
3	Tool (wire) radius	ttrad\$		
4	Overburn amount	overburn\$		
5	Wire status	wire\$	0	Off
			1	On
6	Power status	power\$	0	Off
			1	On
7	Work origin X	wox\$		
8	Work origin y	woy\$		
9	Operation code	opcode\$	201	Contour
			202	Contour
			203	Canned (Drill)
			204	No Core
			205	4-axis taper, no skim
			206	2D reverse skimcut
			207	(Not used)
			208	4-axis direct, reverse skimcuts
			209	4-axis direct, no skimcuts
			210	4-axis taper, reverse skimcuts
			211	4-axis taper, one-way skimcuts
			212	4-axis direct, one-way skimcuts
			213	2D one-way skimcuts
			214	Rapid point
10	Power library path and name	strtool\$, strtoolpath\$		Full 'path and name' of the power library used for the operation

L M R W 1014 : Tool Plane View Matrix

Definition: **1014**
 1 2 3 4 5 6 7 8 9



1	m1\$		
2	m2\$		
3	m3\$		
4	m4\$		
5	m5\$		
6	m6\$		
7	m7\$		
8	m8\$		
9	m9\$		

View	xx	xy	xz	yx	yy	yz	zx	zy	zz
Top (1)	1	0	0	0	1	0	0	0	1
Front (2)	1	0	0	0	0	1	0	-1	0
Back (3)	-1	0	0	0	0	1	0	1	0
Bottom (4)	-1	0	0	0	1	0	0	0	-1
Right Side (5)	0	1	0	0	0	1	1	0	0
Left Side (6)	0	-1	0	0	0	1	-1	0	0
Isometric (7)	0.7071	0.7071	0	-0.4082	0.4082	0.8165	0.5774	-0.5774	0.5773
Axonometric (8)	0.5	-0.8536	0.1464	0.5	0.1464	0.8536	0.7071	0.5	0.5
Variable Name	m1	m2	m3	m4	m5	m6	m7	m8	m9

W 1015 : Subroutine Parameters

Definition: 1015

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20



1	Subroutine type settings	subtyp\$	0 Not a subroutine 1 Write subroutine 2 Call subroutine only
2	Subroutine number	subno\$	
3	Thread/cut flag	td_ct_flg\$	0 No thread or cut 1 Allow thread the wire 2 Allow cut the wire
4	Tab cut	tabcut\$	0 No tab cut 1 Tab cut 2 Contour with tab cut
5	Wire trim (wtrim)		0 Trim in control 1 Trim in computer 2 3D tracking
6	Skimcut options	skimpass\$	0 No skimcut +1 First skim cut pass on a contour -1 Subsequent skim cut pass on a contour -2 Last skim cut pass on a contour
7	Wire cut position X	cutx\$	
8	Wire cut position Y	cuty\$	
9	XY trimming plane	trimplane1\$	
10	UV trimming plane	trimplane2\$	
11	Register value 1	reg1\$	
12	Register value 2	reg2\$	
13	Register value 3	reg3\$	
14	Register value 4	reg4\$	
15	Register value 5	reg5\$	
16	Register value 6	reg6\$	
17	Register value 7	reg7\$	
18	Register value 8	reg8\$	
19	Register value 9	reg9\$	
20	Register value 10	reg10\$	

M R L 1016 : Additional Miscellaneous Parameters

Definition: 1016
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17



1	Operation id	xform_op_id\$	If the operation is a transform operation, this is the operation ID of the transformed operation.
2	Tool type	tool_typ\$	
3	Internal toolpath opcode	tool_op\$	(See toolop\$ codes on page 116 for possible values.)
4	Construction view number	cplnno\$	
5	X coordinate of construction plane origin	corgx\$	(relative to view)
6	Y coordinate of construction plane origin	corgy\$	(relative to view)
7	Z coordinate of construction plane origin	corgz\$	(relative to view)
8	Cutter compensation in computer	cc_computer\$	0 Off 41 Left 42 Right
9	Work offset number	workofs\$	
10	Metric is used	met_tool\$	
11	Number of flutes on cutter	n_flutes\$	
12	Active spindle for lathe	spindle_no\$	
13	Number of threads on tap	n_tap_thds\$	
14	Station number (lathe) or head number (mill)	lstation\$	
15	Upper turret is used	lturret\$	0 Lower turret 1 Upper turret
16	Unique tool ID	ltool_id\$	
17	Operation ID	op_id\$	

W 1016 : Additional Miscellaneous Parameters



Definition: 1016

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20

1	Operation id	xform_op_id\$	If the operation is a transform operation, this is the operation ID of the transformed operation.										
2	Finish spawned from Nocore	nocore_fin\$											
3	Internal toolpath opcode	tool_op\$	(See toolop\$ codes on page 116 for possible values.)										
4	Number of view used for Cplane	cplnno\$	(not used in Wire—always 0)										
5	Cplane origin (X)	corgx\$	(not used in Wire—always 0)										
6	Cplane origin (Y)	corgy\$	(not used in Wire—always 0)										
7	Cplane origin (Z)	corgz\$	(not used in Wire—always 0)										
8	Cutter compensation in computer	cc_computer\$	<table> <tr> <td>0</td><td>Off</td></tr> <tr> <td>41</td><td>Left</td></tr> <tr> <td>42</td><td>Right</td></tr> </table>	0	Off	41	Left	42	Right				
0	Off												
41	Left												
42	Right												
9	Work offset number	workofs\$											
10	Metric is used	met_tool\$											
11	Punch, die, open flag	pdo_type\$	<table> <tr> <td>0</td><td>Punch</td></tr> <tr> <td>1</td><td>Die</td></tr> <tr> <td>2</td><td>Open</td></tr> </table>	0	Punch	1	Die	2	Open				
0	Punch												
1	Die												
2	Open												
12		spindle_no\$	(not used in Wire—always 0)										
13		rpd_hght\$											
14		landheight\$											
15	Taper or slug type	contour_typ\$	<table> <tr> <td>0</td><td>No taper</td></tr> <tr> <td>1</td><td>Taper in</td></tr> <tr> <td>2</td><td>Taper out</td></tr> <tr> <td>3</td><td>Land up</td></tr> <tr> <td>4</td><td>Land down</td></tr> </table>	0	No taper	1	Taper in	2	Taper out	3	Land up	4	Land down
0	No taper												
1	Taper in												
2	Taper out												
3	Land up												
4	Land down												
16	Chain height button selected	contour_pos\$	<table> <tr> <td>0</td><td>XY height</td></tr> <tr> <td>1</td><td>Land height</td></tr> <tr> <td>2</td><td>UV height</td></tr> </table>	0	XY height	1	Land height	2	UV height				
0	XY height												
1	Land height												
2	UV height												
17		wox\$	Work plane origin (X)										
18		woy\$	Work plane origin (Y)										
19		woz\$	Work plane origin (Z)										
20	Operation id	op_id\$											

toolop\$ codes

This table lists the **toolop\$** codes output on the 1016 line:

Table 1: toolop\$ codes



Mill/ Router	Lathe	Wire	toolop\$	Operation
M/R			1	Contour
M/R			2	Drill
M/R			3	Pocket
M/R			4	Transform operation
M/R			5	Multisurface rough parallel
M/R			6	Multisurface rough radial
M/R			7	Multisurface rough project
M/R			8	Multisurface rough flowline
M/R			9	Multisurface rough contour
M/R			10	Multisurface rough pocket
M/R			11	Multisurface finish parallel
M/R			12	Multisurface finish radial
M/R			13	Multisurface finish project
M/R			14	Multisurface finish flowline
M/R			15	Multisurface finish contour
M/R			16	For C-Hook- created operations
M/R			17	Manual entry
M/R			18	Version 8
M/R			19	Point
M/R			20	Trimmed
M/R			21	Ruled
M/R			22	Revolved
M/R			23	Letters
M/R			24	Swept 2D
M/R			25	Swept 3D
M/R			26	Coons
M/R			27	Lofted
M/R			28	5-axis drilling
M/R			29	5-axis curve
M/R			30	Project toolpath onto a plane

Table 1: toolop\$ codes

Mill/ Router	Lathe	Wire	toolop\$	Operation
M/R			31	Project toolpath onto a cylinder
M/R			32	Project toolpath onto a sphere
M/R			33	Project toolpath onto a cone
M/R			34	Project toolpath onto a cross section
M/R			35	Project toolpath onto a surface
M/R			36	Non-associative contour
M/R			37	Non-associative drilling
M/R			38	Non-associative pocketing
M/R			39	Multisurface finish pencil trace
M/R			40	Multisurface finish leftover stock
M/R			41	Multisurface finish steep
M/R			42	Multisurface finish shallow
M/R			43	Multisurface finish constant scallop
M/R			44	Multisurface rough plunge
M/R			45	Multisurface finish 5-axis flowline
M/R			46	Multisurface finish 4-axis
M/R			47	Merged in ASCII NCI
M/R			48	5-axis swarf
M/R			49	5-axis roll die
L			51	face contouring (C axis)
L			52	cross contouring (C axis)
L			53	C axis contouring
L			55	face drilling (C axis)
L			56	cross drilling (C axis)
L			57	C axis drilling
L			60	Rough
L			61	Finish
L			62	Grooving
L			63	Threading
L			64	Drill
L			65	Point
L			66	Facing



Table 1: toolop\$ codes

Mill/ Router	Lathe	Wire	toolop\$	Operation
	L		67	Cutoff
	L		68	Plunge rough
	L		69	Manual entry
	L		70	Merged ASCII
		W	74	Contour
		W	75	Canned
		W	76	No Core
		W	77	Manual entry
		W	78	Point
		W	79	4-axis
		W	80	Transform
		W	81	Associative trimmed
		W	82	Merged in ASCII NCI
		W	83	Collar (new for X4)
M/R			100	Thread mill
M/R			101	Edit common operation parameters
M/R			102	Facing
M/R			103	Associative trimmed
M/R			104	Solid drill control operation
M/R			105	Slot mill
M/R			106	Helix bore
M/R			107	Multi-surface rough restmill
M/R			108	Associative nesting container operation
M/R			109	Multi-surface finish blend
M/R			110	Multi-surface 5axis, rough
M/R			111	Slice 5axis
M/R			112	Port 5axis
M/R			113	5-axis circle (new for X4)
M/R			115	Advanced multiaxis
M/R			130	Tab cutoff
M/R			131	Multi-surface rough pocket, light



Table 1: toolop\$ codes

Mill/ Router	Lathe	Wire	toolop\$	Operation
M/R			132	High-speed surface toolpaths
M/R			133	Nesting onionskin operation
M/R			134	2-D hardmill machining/peel mill
R			135	Saw
M/R			136	FBM drill control operation
M/R			137	FBM mill control operation
	L		201	Canned finish
	L		202	Canned rough
	L		203	Canned rough and finish
	L		204	Canned rough face
	L		205	Canned rough and finish face
	L		206	Canned pattern repeat rough
	L		207	Canned pattern repeat rough and finish
	L		208	Canned groove rough
	L		209	Canned groove finish
	L		210	Quick rough
	L		211	Quick finish
	L		212	Quick groove
	L		213	C-hook generated
	L		214	Stock transfer
	L		215	Stock flip
	L		216	Bar feed
	L		217	Chuck clamp/unclamp
	L		218	Tailstock operation
	L		219	Steadyrest operation
MT			220	Pinch-turn (MultiTasking)
MT			221	Custom operation with tool (MultiTasking/event-driven post)
MT			222	Custom operation without tool (MultiTasking/event-driven post)
MT			223	Reference custom operation (MultiTasking/event-driven post)
R			301	Router contour (<i>obsolete</i>)



Table 1: toolop\$ codes

Mill/ Router	Lathe	Wire	toolop\$	Operation
R			302	Router pocket (<i>obsolete</i>)
R			303	Router circmill (<i>obsolete</i>)
R			304	Router cutoff (<i>obsolete</i>)
R			305	Router surface rough pocket (<i>obsolete</i>)
R			306	Router multi-drill (block drill)
M/R			416	Engraving
Art			439	Art
M/R			440	Advanced multiaxis (Moduleworks)



L M R 1017 : Construction Plane View Matrix

Definition: **1017**
1 2 3 4 5 6 7 8 9



1	X vector X in WCS	cm1\$	
2	X vector Y in WCS	cm2\$	
3	X vector Z in WCS	cm3\$	
4	Y vector X in WCS	cm4\$	
5	Y vector Y in WCS	cm5\$	
6	Y vector Z in WCS	cm6\$	
7	Z vector X in WCS	cm7\$	
8	Z vector Y in WCS	cm8\$	
9	Z vector Z in WCS	cm9\$	

L M R 1018 : Subprogram Start Definition



Definition: 1018

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22
23 24 25 26 27

1	Subprogram number	sub_op_id\$	
2	Actual operation id	sub_grp_id\$	
3	Transform / non-transform indicator	sub_ref_id\$	0 Non-transform >0 Transform
4	Iteration counter	sub_sec_no\$	Transform operations: <0 = Off 0 = Original >0 = Copy Non-transform operations: <1 = Copy in transform 1 = Original >1 = Copy
5	Total number of instances (1-based)	sub_totl_no\$	
6	(Not used)	sub_chn_no\$	
7	Absolute or incremental	sub_inc\$	0 Absolute 1 Incremental
8	Transform type	sub_trnstyp\$	0 Mirror 1 Rotate 2 Scale (not used) 3 Translate
9		sub_trnmthd\$	0 Translate method = Tool plane 1 Translate method = Tool plane with "Tool plane origin ONLY" checked 2 Translate method = Coordinate
10	Transform matrix	sub_m1\$	
11	Transform matrix	sub_m2\$	
12	Transform matrix	sub_m3\$	
13	Transform matrix	sub_m4\$	
14	Transform matrix	sub_m5\$	
15	Transform matrix	sub_m6\$	
16	Transform matrix	sub_m7\$	
17	Transform matrix	sub_m8\$	
18	Transform matrix	sub_m9\$	

19	Transform X data	sub_trnsx\$	Mirrored data: X-axis mirror. Set X-axis intersection. Rotated data: XYZ = center of rotation relative to current view. Translated data: XYZ = translation distance relative to original operation.	 Quick Start
20	Transform Y data	sub_trnsy\$	Mirrored data: Y-axis mirror. Set Y-axis intersection. Rotated data: XYZ = center of rotation relative to current view Translated data: XYZ = translation distance relative to original operation.	
21	Transform Z data	sub_trnsz\$	Rotated data: XYZ = center of rotation relative to current view Translated data: XYZ = translation distance relative to original operation	
22	First tool in the transform group	sub_nxt_t\$		
23	First head number in the transform group	sub_nxt_h\$		
24	(Not used)	sub_nxt_tid\$		
25	More than one tool in transform	sub_mny_t\$	0 Only one tool used in the transform 1 Multiple tools used in the transform	
26	(Internal Use)		1 Source 2 Source path 10 One level call 100 Separate subs 100 All Incremental 0	
27	(Internal Use)		Flags if it is OK to write the 1018 line	

L M R 1019 : Subprogram End Definition

Definition: 1019
1 2 3 4 5 6



1	Subprogram number	esub_op_id\$	
2	Actual operation id	esub_grp_id\$	
3	Transform / non-transform flag	esub_ref_id\$	0 Non-transform >0 Transform
4	Iteration counter	esub_sec_no\$	Transform operations: <0 = Off 0 = Original >0 = Copy Non-transform operations: <1 = Copy in transform 1 = Original >1 = Copy
5	Total number of instances	esub_totl_no\$	
6	(Not used)	esub_chn_no\$	

M R 1020 : Stock Parameters

Definition: 1020
1 2 3 4 5 6 7 8 9 10 11 12 13 14



1	X component, width	stck_ht\$	
2	Y component, height	stck_wdth\$	
3	Z component, thickness	stck_thck\$	
4	X origin of block	stck_x\$	
5	Y origin of block	stck_y\$	
6	Z origin of block	stck_z\$	
7	Origin corner	stck_crnrs\$	0 Origin corner: top - center 1 Origin corner: top – upper left 2 Origin corner: top – upper right 3 Origin corner: top – lower right 4 Origin corner: top – lower left 5 Origin corner: bottom – upper left 6 Origin corner: bottom – upper right 7 Origin corner: bottom – lower right 8 Origin corner: bottom – lower left
8	Rotary axis in terms of Tplane	rotary_vecx\$	
9	Rotary axis in terms of Tplane	rotary_vecy\$	
10	Rotary axis in terms of Tplane	rotary_vecz\$	
11	(Not used)		
12	Parameter file read flag (read internally)		
13	Maximum spindle speed	maxss\$	
14	String with the stock material name	stck_matl\$	

L 1020 : Stock Parameters

Definition: 1020
 1 2 3 4 5 6 7 8 9 10 11 12 13 14



1	Length of stock along Z axis	stck_ht\$	
2	Maximum diameter of stock	stck_wdth\$	
3	Same as 2	stck_thck\$	
4	Center of stock along Z axis	stck_x\$	
5	Center of stock	stck_y\$	Always 0
6	Center of stock	stck_z\$	
7	Origin corner	stck_crnr\$	Always 0
8	Rotary axis in terms of Tplane	rotary_vecx\$	Always 0
9	Rotary axis in terms of Tplane	rotary_vecy\$	Always 0
10	Rotary axis in terms of Tplane	rotary_vecz\$	Always 0
11	(Not used)		
12	Parameter file read flag (read internally)		
13	Maximum spindle speed	maxss\$	
14	Stock material name	stck_matl\$	

W 1020 : Stock Parameters

Definition: 1020
 1 2 3 4 5 6 7 8 9 10 11 12 13 14



1	X component, width	stck_ht\$	
2	Y component, height	stck_wdth\$	
3	Z component, thickness	stck_thck\$	
4	X origin of block	stck_x\$	
5	Y origin of block	stck_y\$	
6	Z origin of block	stck_z\$	
7	Origin corner	stck_crnrs\$	0 Origin corner: top - center 1 Origin corner: top – upper left 2 Origin corner: top – upper right 3 Origin corner: top – lower right 4 Origin corner: top – lower left 5 Origin corner: bottom – upper left 6 Origin corner: bottom – upper right 7 Origin corner: bottom – lower right 8 Origin corner: bottom – lower left
8	(Not used)		
9	(Not used)		
10	(Not used)		
11	Tank fill / empty flag	tank\$	
12	Parameter file read flag (read internally)		
13	(Not used)		
14	String with the stock material name	stck_matl\$	

L M R W 1025 : Canned Text



Each parameter is a 4-digit number where:

- The first digit is the **cant_pos1\$–cant_pos2\$** value. This value ranges from 0–2 and indicates how the canned text is to be output:
 - ◆ 0 = output before the line
 - ◆ 1 = output with the line
 - ◆ 2 = output after the line
- The other three digits are the **cant_val1\$–cant_val20\$** value and indicate which canned text item to output.

Leading zeros are not output; so, for example, **0005** would be output simply as **5**.

Definition:

1025

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20

1	Canned text parameter	cant_pos1\$+cant_val1\$	Output mode + canned text ID
2		cant_pos2\$+cant_val2\$	
3		cant_pos3\$+cant_val3\$	
4		cant_pos4\$+cant_val4\$	
5		cant_pos5\$+cant_val5\$	
6		cant_pos6\$+cant_val6\$	
7		cant_pos7\$+cant_val7\$	
8		cant_pos8\$+cant_val8\$	
9		cant_pos9\$+cant_val9\$	
10		cant_pos10\$+cant_val10\$	
11		cant_pos11\$ cant_val11\$	
12		cant_pos12\$+cant_val12\$	
13		cant_pos13\$+cant_val13\$	
14		cant_pos14\$+cant_val14\$	
15		cant_pos15\$+cant_val15\$	
16		cant_pos16\$+cant_val16\$	
17		cant_pos17\$+cant_val17\$	
18		cant_pos18\$+cant_val18\$	
19		cant_pos19\$+cant_val19\$	
20		cant_pos20\$+cant_val20\$	

L M R W 1027 : Working Coordinate System

Definition: 1027
1 2 3 4 5 6 7 8 9 10 11 12



1	t_wcs_m1\$	
2	t_wcs_m2\$	
3	t_wcs_m3\$	
4	t_wcs_m4\$	
5	t_wcs_m5\$	
6	t_wcs_m6\$	
7	t_wcs_m7\$	
8	t_wcs_m8\$	
9	t_wcs_m9\$	
10	t_origin_x\$	
11	t_origin_y\$	
12	t_origin_z\$	

M R 1028 : Head definition data

Definition: 1028
 1 2 3 4 5 6 7 8 9 10 11 12



1	ra_type\$	0	No special head (std)
		1	Right-angle
		2	Compound
		3	Block drill
		4	UST
2	ra_offset\$		
3	ra_vecx\$		
4	ra_vecy\$		
5	ra_vecz\$		
6	ra_svecx\$		
7	ra_svecy\$		
8	ra_svecz\$		
9	ra_block\$		
10	ra_station\$		
11	ra_head_grp\$		
12	ra_tc_type\$	0	Auto T.C. (default)
		1	Fixed unit
		2	Manual T.C.

M R 1029 : Head shift parameters

Definition: 1029
1 2 3 4 5 6 7 8 9 10 11



1	ra_hvecx\$	
2	ra_hvecy\$	
3	ra_hvecz\$	
4	ra_bvecx\$	
5	ra_bvecy\$	
6	ra_bvecz\$	
7	ra_tvecx\$	
8	ra_tvecy\$	
9	ra_tvecz\$	
10	ra_translated\$	
11	ra_rot_head\$	

L M R W 1050 (Define NCI Version Header)

Definition: 1050
 1 2 3 4 5 6 7 8 9

1	Mastercam major version number	vers_no\$		
2	Mastercam minor version number	m_vers_no\$		
3	MCX file - day stamp	mc_day\$		
4	MCX file - month stamp	mc_mon\$		
5	MCX file - year stamp	mc_year\$		
6	MCX file - hour stamp	mc_hour\$		
7	MCX file - minute stamp	mc_minute\$		
8	MCX file - second stamp	mc_sec\$		
9	MCX file name	smcname\$		

L M R W 1051 : Machine name

Definition: 1051
 string

Text to be inserted into the NC program.	Name of machine definition.
--	-----------------------------

L M R W 1052 : Machine group comment

Definition: 1052
 string

Text to be inserted into the NC program.	Comment recorded in machine group properties.
--	---

L M R W 1053 : Machine group name

Definition: 1053
 string

Text to be inserted into the NC program.	Name of machine group.
--	------------------------

Control Flags Parameters



The control flags (also called “contour flags”) parameter is a single parameter passed from the NCI that carries several pieces of information in a single numeric value. The control flags parameter appears in every motion NCI Gcode (Gcodes 0, 1, 2, 11, 81) to control such values as contour start, stop, and end, coolant, and 5-axis angles (for Mill) or rapid behavior (for Lathe).

Each decimal position in the control flags parameter value represents an individual flag. For example, 1 (first decimal place) is the contour stop flag, 10 (second decimal place) is the contour optional stop flag, 100 (third decimal place) is the contour end flag, and so forth. When added together, the result is a single number that represents multiple flags. Zero is implied when the place fields are empty, but only leading zeros may be omitted.

For example (in Mill), if:

```
cur_cflg$ = 3201001
```

The control flags (reading left to right) set the following:

- 5-axis: 180-degree angle
- Coolant flood
- Contour start on
- Contour optional stop off
- Contour stop on

The flag as read from the NCI is available as the predefined variable **cur_cflg\$**. You should rarely need to use the **cur_cflg\$** variable directly because the post executable sets separate variables for each flag.

The following tables describe the control flag settings for each product.

M R Mill / Router Control Flags Parameters

This is written to the NCI as a six-digit number. Each digit sets the value of a different pre-defined value, as shown in this table. The entire six-digit number is stored in the **cur_cflg\$** variable.



cstop\$	0	Contour stop off
	1	Contour stop on
cgstop\$	00	Contour optional stop off
	10	Contour optional stop on
cend\$	000	Contour end off
	100	Contour end on
	200	Compensation OFF position
	300	Both contour and compensation off See notes below
cstart\$	0000	Contour start off
	1000	Contour start on
	2000	Compensation ON position
	3000	Both contour & compensation start See notes below
rpd_typ\$	70000	Pause for tool inspection (high speed surface toolpaths)
coolant\$	100000	Coolant off
	200000	Coolant flood
	300000	Coolant mist
	400000	Coolant tool
rev5\$	1000000	Five axis, non-vertical tool: flipped Vertical tool: same as previous angle
	2000000	Five axis: same as next angle
	3000000	Five axis: 180 degree angle
	4000000	Five axis: previous + 180 degrees
	5000000	Five axis: next + 180 degrees

The Compensation ON/OFF position flag values are added to **cend\$** and **cstart\$** flag, if they exist at the same location in the NCI file. Example: Contour END (100) and compensation OFF (200) can occur at the same location, so the flag values are added and you will see a value of 300.

The compensation flags (2000 and 200) are independent of the compensation actually being programmed in the toolpath program! They mark where compensation would normally be activated and canceled in the toolpath by Mastercam.

The raw values shown in this chart are not the values set in the individual variables. Example: if **cur_cflg\$ = 1000** (contour start), the variable **cstart\$** is set to 1.

L Lathe Control Flags Parameters



This is written to the NCI as a six-digit number. Each digit sets the value of a different pre-defined value, as shown in this table. The entire six-digit number is stored in the **cur_cflg\$** variable.

cstop\$	0	Contour stop off
	1	Contour stop on
cgstop\$	00	Contour optional stop off
	10	Contour optional stop on
cend\$	000	Contour end off
	100	Contour end on
	200	Compensation OFF position
	300	Both contour and compensation off See notes below
cstart\$	0000	Contour start off
	1000	Contour start on
	2000	Compensation ON position
	3000	Both contour & compensation start See notes below
rpd_typ\$	10000	Clear to home
	20000	Rapid to start
	30000	Rapid around obstruction
	40000	Rapid between points
	50000	Entry / Exit
	60000	Start / End rough turning cycles
	70000	Pause for tool inspection (groove toolpaths)
coolant\$	100000	Coolant off
	200000	Coolant flood
	300000	Coolant mist
	400000	Coolant tool

The Compensation ON/OFF position flag values are added to **cend\$** and **cstart\$** flag, if they exist at the same location in the NCI file. Example: Contour END (100) and compensation OFF (200) can occur at the same location, so the flag values are added and you will see a value of 300.

The compensation flags (2000 and 200) are independent of the compensation actually being programmed in the toolpath program! They mark where compensation would normally be activated and canceled in the toolpath by Mastercam.

The raw values shown in this chart are not the values set in the individual variables. Example: if **cur_cflg\$ = 1000** (contour start), the variable **cstart\$** is set to 1.

W Wire Control Flags Parameters



This is written to the NCI as a six-digit number. Each digit sets the value of a different pre-defined value, as shown in this table. The entire six-digit number is stored in the **cur_cflg\$** variable.

cstop\$	0	Contour stop off
	1	Contour stop on
cgstop\$	00	Contour optional stop off
	10	Contour optional stop on
cend\$	000	Contour end off
	100	Contour end on
	200	Compensation OFF position
	300	Both contour and compensation off
		See notes below
cstart\$	0000	Contour start off
	1000	Contour start on
	2000	Compensation ON position
	3000	Both contour & compensation start
		See notes below
thrd_cut\$	10000	Thread the wire
	20000	Cut the wire
water\$	100000	Water off
	200000	Water on
	300000	Water option 1
power\$	1000000	Power off
	2000000	Power on
tank\$	10000000	Tank empty
	20000000	Tank fill

The Compensation ON/OFF position flag values are added to **cend\$** and **cstart\$** flag, if they exist at the same location in the NCI file. Example: Contour END (100) and compensation OFF (200) can occur at the same location, so the flag values are added and you will see a value of 300.

The compensation flags (2000 and 200) are independent of the compensation actually being programmed in the wirepath! They mark where compensation would normally be activated and canceled in the wirepath by Mastercam.

The raw values shown in this chart are not the values set in the individual variables. Example: if **cur_cflg\$ = 1000** (contour start), the variable **cstart\$** is set to 1.

Tool information (20000s parameters)



Tool information lines are added in the 20000s lines in the NCI file. The data is presented in a two-line format:

See [Capturing parameters from 20000s lines](#) on page 21 to learn more about using the values.

- The first line contains the parameter number.
- The second line contains the value or values.

The second line can be interpreted as either a single string or as a series of numeric values separated by spaces. In the reference sections that follow, for each parameter there is a prototype that describes the data structure of the parameter value, followed a description of the actual values. These are not assigned variable names but can be scanned for the desired values with the function `rpar`. (See [Capturing numeric values from a 20000s line](#) on page 23 to learn more about how to extract numeric values from the parameter string.)

```
g
string
```

The codes are divided into three sections:

- The first section contains codes numbered below 20100 and above 20500. They are either Mill/Router-specific, or are used across multiple products.
- The second section contains Lathe-specific codes, numbered from 20100–20199.
- The third section contains Wire-specific codes. Most of these are numbered above 20200.

Note that some codes might be output for a certain product, but with a blank value if the value isn't used in that product.

See [NCI Gcodes](#) for information about NCI Gcodes numbered below 10000.

Mill/Router/Generic



20001 : Tool name

Used in: Mill Lathe Router

Definition: 20001
string (tool name)

20002 : Tool definition: manufacturer's tool code

Used in: Mill Lathe Router

Definition: 20002
string (manufacturer's tool code)

20003 : Chuck name

Used in: Mill Router

Definition: 20003
string (chuck name)

20004 : Tool definition: tool parameters

Used in: Mill Router

Definition: 20004
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

1	tool number
2	tool type: 1=center drill 2=spot drill 3=drill 4=right hand tap 5=left hand tap 6=reamer 7=boring bar 8=counter bore 9=counter sink 10=end mill - flat 11=end mill - spherical 12=chamfer mill 13=face mill 14=slot mill 15=radius mill 16=dovetail mill 17=tapered mill 18=lollipop mill

	19=end mill – bullnose
3	tool material: 1=high speed steel 2=carbide 3=coated carbide 4=ceramic 5=borzon 6=unknown
4	corner radius type: 0= flat mill 1= bullnose mill 2= spherical mill
5	tool diameter
6	corner radius
7	number of threads/inch or pitch (mm)
8	tool tip included angle
9	diameter offset register #
10	length offset register #
11	linear feed rate
12	plunge feed rate
13	retract feed rate
14	spindle speed
15	coolant type: 0=coolant off 1=flood 2=mist 3=tool (spindle)
16	number of flutes



20005 : Tool definition: tool parameters for drills

Used in: **Mill Router**

Definition: **20005**
1 2 3 4 5 6 7 8 9

1	drill canned cycle type
2	1st peck increment (% of tool dia.)
3	2nd peck increment (% of tool dia.)
4	peck clearance (% of tool dia.)
5	chip break (% of tool dia.)
6	amount of dwell in seconds
7	shoulder angle
8	tap drill diameter
9	amount to shift off wall for fine boring

20006 : Tool definition: tool parameters*Used in:* Mill Router*Definition:* 20006

1 2 3 4 5 6 7 8



- | | |
|---|---|
| 1 | cutter ability:
0=capable of roughing and finishing
1=capable of roughing only
2=capable of finishing only |
| 2 | % of tool dia. for rough XY stepover |
| 3 | % of tool dia. for rough Z step |
| 4 | % of tool dia. for finish XY stepover |
| 5 | % of tool dia. for finish Z step |
| 6 | tool tip diameter |
| 7 | tool minor diameter |
| 8 | thread mill angle |

20007 : Tool definition: holder parameters*Used in:* Mill Router*Definition:* 20007

1 2 3 4 5 6 7 8 9 10 11

- | | |
|----|--|
| 1 | minimum diameter required for tool to plunge |
| 2 | flute length |
| 3 | overall length |
| 4 | shoulder length |
| 5 | arbor diameter |
| 6 | holder diameter |
| 7 | holder length |
| 8 | 0 = cw, 1 = ccw |
| 9 | % of surface ft/mm to be applied against workpiece
matl sfm |
| 10 | % of feed/tooth to be applied against workpiece matl
fpt |
| 11 | 0 = values in inches, 1 = metric |

20008 : Tool definition: aggregate head parameters*Used in:* Mill Router*Definition:* 20008

1 2 3 4 5 6 7 8 9

- | | |
|---|----------------|
| 1 | head axis in X |
| 2 | head axis in Y |



3	head axis in Z
4	head body type: (0 = cylinder, 1 = square)
5	head body diameter
6	head body length
7	station body type (0 = cylinder, 1 = square)
8	station body diameter
9	station body length

20009 : Custom tool geometry

Used in: Mill Router

Definition: 20009
1 2

1	The level on which custom tool geometry is stored.
2	The source of the custom geometry (0=auto, 1=file, 2=level).

20010 : Construction plane name

Used in: Mill Lathe Router Wire

Definition: g = 20010
string (construction plane name)

20011 : Construction plane comment

Used in: Mill Lathe Router Wire

Definition: 20011
string (construction plane comment)

This line has no value in Wire. It will be output, but will always be blank.

20012 : Tool plane name

Used in: Mill Lathe Router Wire

Definition: 20012
string (tool plane name)

20013 : Tool plane comment

Used in: Mill Lathe Router Wire

Definition: 20013
string (tool insert name)

This line has no value in Wire. It will be output, but will always be blank.

20014 : WCS plane name

Used in: **Mill Lathe Router Wire**

Definition: **20014**
string (WCS plane name)

**20015 : WCS plane comment**

Used in: **Mill Lathe Router Wire**

Definition: **20015**
string (WCS plane comment)

This line has no value in Wire. It will be output, but will always be blank.

20016 : Material name

Used in: **Mill Lathe Router**

Definition: **20016**
string (material name)

This line has no value in Wire. It will be output, but will always be blank.

20017 : Material comment

Used in: **Mill Lathe Router**

Definition: **20017**
string (material comment)

This line has no value in Wire. It will be output, but will always be blank.

20018 : Machine group name

Used in: **Mill Lathe Router Wire**

Definition: **20018**
string (machine group name)

20501 : Nested sheet: material name

Used in: **Mill Router**

Definition: **20501**
string (material name)

Sheet information is output for each sheet change notification in the NCI.

20502 : Nested sheet: parameters

Used in: **Mill Router**

Definition: **20502**
1 2 3 4 5 6 7 8 9 10 11 12

Sheet information is output for each sheet change notification in the NCI.

1	sheet length (X dimension)
2	sheet width (Y dimension)



3	Sheet thickness (temporary placeholder)
4	sheet corner (1 = lower left, 2 = lower right, 3 = upper right, 4 = upper left)
5	sheet number
6	sheet instance
7	integer pad
8	integer pad
9	integer pad
10	real pad
11	real pad
12	real pad

20600 : Axis combination components

Used in: Mill Router Lathe Wire

Definition: 20600
1 2 3 4 5

A 20600 line is output for each component in the axis combination.

1	Entity ID for component
2	String ID for component
3	Axis label (absolute)
4	Axis label (incremental)
5	Component name

20601 : Axis combination info

Used in: Mill Router Lathe Wire

Definition: 20601
1 2 3 4

A 20601 line is output for the axis combination itself.

1	Entity ID
2	String ID
3	1=Mapped axis combination, otherwise 0
4	Axis combination name

20700 : Tool change info per data stream

Used in: Mill Router Lathe Wire

Definition: 20700
0 1 2 3 4 5 6 7



Code 20700 summarizes tool usage for each data stream, 0-7. Each parameter value corresponds to one of the data streams.

0–7	For each data stream, the parameter indicates the following: <ul style="list-style-type: none">• 0=No tool change in data stream• 1=One tool change in data stream• 2=More than one tool change in data stream
-----	--

Lathe

20100 : Lathe tool definition : programming parameters



Used in: **Lathe**

Definition: **20100**
1 2 3 4 5 6 7 8 9

1	tool slot number
2	tool type: 0=General Turning Tools 1=Threading Tools 2=Grooving/Parting Tools 3=Boring Bars 4=Drills, Taps, Reamers 5=Custom Geometry Tools
3	use in top turret
4	active spindle
5	tool angle in turret (in degrees)
6	top turret
7	tool number
8	tool offsets for right edge
9	tool offsets for left edge

20101 : Lathe tool definition: general cutting parameters

Used in: **Lathe**

Definition: **20101**
1 2 3 4 5 6 7 8 9 10

1	fast feed rate
2	feed rate type
3	slow feed rate
4	spindle speed
5	spindle speed in css
6	percent of material css to use
7	percent of material feed/rev to use
8	spindle direction
9	coolant status for tool
10	cutting parameters in metric

20102 : Lathe tool definition: geometric parameters*Used in:* **Lathe***Definition:* **20102**

1 2 3 4 5 6 7 8



1	tool orientation
2	tool clearance angle for programming
3	tool rake angle for programming
4	tool width for programming
5	tool height for programming
6	tool center for programming
7	tool center for programming
8	comp to center of insert nose radius

20103 : Lathe tool definition: insert name*Used in:* **Lathe***Definition:* **20103**

string (tool insert name)

20104 : Lathe tool definition: insert general parameters*Used in:* **Lathe***Definition:* **20104**

1 2 3 4 5 6 7 8

1	ASCII code for insert shape
2	IC diameter
3	length
4	corner radius
5	thickness
6	insert material for feed speed calculations
7	insert type (-1 = not used)
8	is insert defined in mm or inches?

20105 : Lathe tool definition: general turning/boring insert parameters*Used in:* **Lathe***Definition:* **20105**

1 2 3 4 5 6 7

1	cross section index ASCII code
2	end relief angle
3	roughing depth of cut



4	finish depth of cut
5	roughing overlap amount
6	facing retraction amount
7	facing x overcut amount

20106 : Lathe tool definition: threading insert parameters

Used in: **Lathe**

Definition: **20106**

1 2 3 4 5 6 7 8 9 10 11 12

1	insert style: 1='TOP NOTCH' Thread Insert 2='LAYDOWN' Thread Insert
2	unified, ACME, buttress, etc.
3	insert for external thread?
4	design thread pitch
5	top notch dist. to insert point from side of insert
6	laydown height of insert (~= thread depth)
7	width of flat for ACME, buttress
8	depth of 1st cut
9	depth of last cut
10	finish pass allowance
11	anticipated pull-off
12	number of spring cuts

20107 : Lathe tool definition: grooving/parting insert parameters

Used in: **Lathe**

Definition: **20107**

1 2 3 4 5 6 7 8 9 10

1	cutting length of insert
2	shank width
3	end length for top notch type P
4	distance to insert point for top notch type V
5	end angle for Sandvik type 5R
6	roughing depth of cut
7	finish depth of cut
8	stock clearance
9	backoff percent
10	roughing overlap amount

20108 : Lathe tool definition: drilling tool parameters (geometry)*Used in:* **Lathe***Definition:* **20108**

1 2 3 4 5 6 7 8 9 10 11 12 13 14



1	drill, tap, reamer, etc: 1=Drill 2=Center Drill 3=Countersink 4=Counterbore 5=End Mill 6=Reamer 7=Right Hand Tap 8=Left Hand Tap
2	tool diameter
3	shank diameter
4	tip included angle
5	flute length
6	length at cutting diameter
7	flute helix angle
8	number of flutes
9	chamfer height for reamers, taps
10	tip diameter for center drills
11	tip length for center drills
12	shoulder angle for center drills
13	thread pitch for taps
14	tap type: 1=Tapered Tap 2=Plug Tap 3=Bottoming Tap

20109 : Lathe tool definition: drilling tool parameters*Used in:* **Lathe***Definition:* **20109**

1 2 3 4 5 6

1	preferred drilling cycle
2	1st peck increment
3	subsequent peck increment
4	peck clearance
5	retraction amount
6	dwell time

20110 : Lathe tool definition: holder name*Used in:* **Lathe***Definition:* **20110**
string (tool holder name)**20111 : Lathe tool definition: holder parameters***Used in:* **Lathe***Definition:* **20111**
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

1	shape index ascii code
2	qualified length
3	maximum width
4	shank width
5	shank height
6	'head' length
7	'head' width
8	corner chamfer width
9	corner chamfer height
10	end cutting edge angle
11	side cutting edge angle
12	True = round shank
13	left hand tool?
14	vertically mounted tool?
15	is holder defined in mm or inches?

20112 : Lathe tool definition: custom tool geometry file name*Used in:* **Lathe***Definition:* **20112**
string (custom tool geometry file name)**29999 : Tool inspection comment**

Note that this line is not output before the tool change, like the other 20000s lines—instead, it is output in the toolpath at the point where the tool inspection occurs. See [Lathe tool inspection comments](#) on page 27 to learn more.

Used in: **Lathe***Definition:* **29999**
string (lathe tool inspection comment)

Wire

20019 : Pass comment from power library

Used in: **Wire**

Definition: **20019**
 string (power library pass comment)

This line has a value in Wire only. It is output for Mill and Router toolpaths, but will be blank.



20200 : Wirepath stock to leave

Used in: **Wire**

Definition: **20200**
 1 2 3

- | | |
|---|---|
| 1 | Stock to leave |
| 2 | Total offset |
| 3 | Apply additional offset to:
(0 = program coordinates, 1 = machine offset registers) |

Parameters for Agievision posts

The Agievision interface introduced with Mastercam X4 includes many new dialog boxes that mimic the look and feel of the Agievision control. A new range of parameters has been established, 22000–22999, to encapsulate these settings and pass them to the post. These are then read and stored during **pparameter\$** like any other 20000-style parameters.



IMPORTANT: This represents a significant change from how Agie data was written out by the Agie C-Hook used in Mastercam X3. The C-Hook wrote the data to a separate .ADT file to be read by the post, instead of the 22000 parameters. Posts written for the new Agievision interface therefore need to be completely different.

Ranges of interface parameters


The Agievision interface is the first Mastercam product to take advantage of a new numbering system for 22xxx parameters. Parameters in this range will be used to support custom interfaces in general, of which the Agievision is just the first.

- Parameter numbers 22001–22050 will be used for generic parameters. These numbers will not be unique and will be reused in multiple interfaces.
- Parameters numbered from 22051 and higher will be reserved in blocks of 50 for each interface.

Validating the Agievision post

Mastercam X4 includes some new validation routines designed to ensure that the post selected for the wire machine definition has been configured to work with the Agievision interface.

The Wire control definition includes a new **Control Model** page:



The **Machine model** sets a new predefined variable, **controldefault\$**.

- Selecting **Generic** sets **controldefault\$** = 0
- The 11 different Agie models set **controldefault\$** equal to a value from 1–11

In the Agievision post, you will see this line:

```
sx_nci_default$ : "1.11" #Enable posting for integrated Agievision
```

MP uses this string to construct a range of valid values (in this case, 1 through 11) that are used to validate **controldefault\$**. So if the **Generic** machine model is selected in the control definition, **controldefault\$** will equal 0 and an error message will be generated, because 0 is not included in the range of valid values.

In this way, the single Agievision post can be used with any of the 11 Agie models.

- You can limit the range of valid models by adjusting the value of **sx_nci_default\$**.
- You can implement model-specific customizations by testing for the value of **controldefault\$**.

Selecting one of the Agie machines from the **Machine model** list is also what activates the Agievision interface in the first place.



NOTE: The text of the **Machine model** string is also available directly as a string parameter, **22001**.

**See Interface**

reference on page 166 for a visual reference. It shows all the Agie dialogs with their parameter numbers.

Parameter tables

22001 : Machine model

Used in: **Wire (Agie interface)**

Definition: **22001**
string (machine model)

From control definition. See **Control definition: Control Model page** on page 166.

22002 : Control version

Used in: **Wire (Agie interface)**

Definition: **22002**
1

From control definition. See **Control definition: Control Model page** on page 166.

Position	Description	Type	SBL command
1	Control version (0–3)	int	none

22003 : Piece name

Used in: **Wire (Agie interface)**

Definition: **22003**
string

See **Machine group properties: Piece Details tab** on page 168.

Position	Description	Type	SBL command
1	Piece name	string	ID_NAMEOBJ

22004 : Piece material

Used in: **Wire (Agie interface)**

Definition: **22004**
string

See **Machine group properties: Piece Details tab** on page 168.

Position	Description	Type	SBL command
1	Material code	string	ID_MATERIAL

This is output as a numeric code, padded with leading zeros to 4 places. The table below lists the possible values.

Table 2: Piece material codes

Value	Material
0001	Cold Die Steel
0011	Electrolytic Cu
0021	Graphite 1 (grain < 5µm)

Table 2: Piece material codes

Value	Material
0031	Tung. carbide 85 WC\15Co
0041	Aluminum
0051	Brass
0061	Sialon
0071	PCD 002 (grain 2µm)
0081	Graphite 2 (grain 5..10µm)
0091	Graphite 3 (grain > 10µm)
0101	PCD 010 (grain 10µm)
0111	PCD 025 (grain 25µm)
0121	PCD-CTC002
0122	PCD-CTB002
0123	PCD-CTB010
0124	PCD-CTB025
0125	PCD-CTH025
0126	PCD-CTM302
0131	PCD-Compx 1300
0132	PCD-Compx 1500
0133	PCD-Compx 1600
0141	PCD C30X
0151	PCB AMB90
0152	PCB DBW85
0153	PCB DBA80
0154	PCB DBC50
0155	PCB DBN45
0161	PCB BZN 8200
0162	PCB BZN 6000
0171	PCB N90
0181	CPM 10V (powder metallurgy steel)



22005 : Piece wire name*Used in:* **Wire (Agie interface)***Definition:* **22005**
stringSee [Machine group properties: Piece Details tab](#) on page 168.

Position	Description	Type	SBL command
1	Piece wire name	string	ID_THREAD

22051 : Piece quality target*Used in:* **Wire (Agie interface)***Definition:* **22051**
string (piece quality target)

This parameter writes the piece quality target as a string (machining quality targets are written in lines 22055–22057). The numeric real values for Ra, Tf, and Tkm that correspond to this setting are written on line 22058, parameters 1–3.

See [Machine group properties: Piece Details tab](#) on page 168.**22052 : Machining strategy***Used in:* **Wire (Agie interface)***Definition:* **22052**
string

A one- or two-letter code is written to the NCI for each strategy. See [Machine group properties: Piece Details tab](#) on page 168.

Position	Description	Type	SBL command
1	Strategy code	string	ID_STATEGY

Table 3: Machining strategy codes

Code Strategy	
A	Machine
E	Early
L	Late
W	Piece
EW	Early Piece
LW	Late Piece
WE	Piece Early
WL	Piece Late

22053 : Piece setup

Used in: **Wire (Agie interface)**

Definition: **22053**
1 2 3 4 5 6 7 8 9



See [Machine group properties: Piece Setup tab](#) on page 167. ([Machine group properties: Piece Setup tab](#) on page 167 also lists the pre-defined variables used for the piece dimensions).

Position	Description	Type	SBL command
1	Piece reference position (X)	real	ID_POSX
2	Piece reference position (Y)	real	ID_POSY
3	Piece reference position (Z)	real	ID_POSZ
4	Piece reference position (C)	real	ID_ROTATION
5	Edge position (X)	real	ID_POSPOSX
6	Edge position (Y)	real	ID_POSPOSY
7	Edge position (Z)	real	ID_POSPOSZ
8	Security level	real	ID_VALSEC
9	Return level	real	ID_VALRETP

22054: Machining name

Used in: **Wire (Agie interface)**

Definition: **22054**
string

See [Wirepath parameters: Machining page](#) on page 168.

Position	Description	Type	SBL command
1	Machining name	string	Create working

22055: Machining quality target (No Core Group, Collar LC1 wirepaths)

Used in: **Wire (Agie interface)**

Definition: **22055**
string (machining quality target)

This parameter outputs the machining quality target as a string. Lines 22055, 22056, and 22057 all output the machining quality target, but for different types of wirepaths.

The numeric real values for Ra, Tf, and Tkm that correspond to this setting are output on line 22058, parameters 6–8.

See [Wirepath parameters: Machining page](#) on page 168.

Position	Description	Type	SBL command
1	Machining quality target	string	ID_QUALITY

22056: Machining quality target (No Core Rough, Collar LC2 wirepaths)

Used in: **Wire (Agie interface)**

Definition: **22056**
string (machining quality target)



This parameter outputs the machining quality target as a string. Lines 22055, 22056, and 22057 all output the machining quality target, but for different types of wirepaths.

The numeric real values for Ra, Tf, and Tkm that correspond to this setting are output on line 22058, parameters 11–13.

See [Wirepath parameters: Machining page](#) on page 168.

Position	Description	Type	SBL command
1	Machining quality target	string	ID_QUALITY

22057: Machining quality target (No Core Finish, Collar LC3, Contour, and 4-axis wirepaths)

Used in: **Wire (Agie interface)**

Definition: **22057**
string (machining quality target)

This parameter outputs the machining quality target as a string. Lines 22055, 22056, and 22057 all output the machining quality target, but for different types of wirepaths.

The numeric real values for Ra, Tf, and Tkm that correspond to this setting are output on line 22058, parameters 16–18.

See [Wirepath parameters: Machining page](#) on page 168.

Position	Description	Type	SBL command
1	Machining quality target	string	ID_QUALITY

22058: Quality info

Used in: **Wire (Agie interface)**

Definition: **22058**
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20

This line has 4 sets of 5 parameters, one for each of 4 quality targets. See [Machine group properties: Piece Details tab](#) on page 168 and [Wirepath parameters: Machining page](#) on page 168.

Position	Description	Type	SBL command
1	Piece quality (22051)—Ra	real	none
2	Piece quality (22051)—Tf	real	none
3	Piece quality (22051)—Tkm	real	none

Position	Description	Type	SBL command
4	Speed/quality options (22051): <ul style="list-style-type: none"> ▪ 0 = neither ▪ 1 = Speed ▪ 2 = Quality ▪ 3 = both 	int	none
5	Create quality checkbox (22051). See Wirepath parameters: User Tech (Technology Database) dialog box for parameters 4 & 5.	int	none
6	Quality LC1 (22055)—Ra	real	none
7	Quality LC1 (22055)—Tf	real	none
8	Quality LC1 (22055)—Tkm	real	none
9	Speed/quality options (Quality LC1 :22055): <ul style="list-style-type: none"> ▪ 0 = neither ▪ 1 = Speed ▪ 2 = Quality ▪ 3 = both 	int	none
10	Create quality checkbox (Quality LC1 : 22055). See Wirepath parameters: User Tech (Technology Database) dialog box for parameters 9 & 10.	int	none
11	Quality LC2 (22056)—Ra	real	none
12	Quality LC2 (22056)—Tf	real	none
13	Quality LC2 (22056)—Tkm	real	none
14	Speed/quality options (Quality LC2 :22056): <ul style="list-style-type: none"> ▪ 0 = neither ▪ 1 = Speed ▪ 2 = Quality ▪ 3 = both 	int	none
15	Create quality checkbox (Quality LC2 : 22056). See Wirepath parameters: User Tech (Technology Database) dialog box for parameters 14 & 15.	int	none
16	Quality LC3 (22057)—Ra	real	none
17	Quality LC3 (22057)—Tf	real	none
18	Quality LC3 (22057)—Tkm	real	none
19	Speed/quality options (Quality LC3: 22057): <ul style="list-style-type: none"> ▪ 0 = neither ▪ 1 = Speed ▪ 2 = Quality ▪ 3 = both 	int	none
20	Create quality checkbox (Quality LC3: 22057). See Wirepath parameters: User Tech (Technology Database) dialog box for parameters 19 & 20.	int	none



22059 : Machining wire name*Used in:* **Wire (Agie interface)***Definition:* **22059**
stringSee [Wirepath parameters: Machining page](#) on page 168.

Position	Description	Type	SBL command
1	Machining wire name	string	ID_THREAD

22060: Machining data*Used in:* **Wire (Agie interface)***Definition:* **22060**
1 2 3 4 5 6 7 8See [Wirepath parameters: Machining page](#) on page 168.

Position	Description	Type	SBL command
1	Priority	int	ID_PRIORITY
2	Technological height	real	ID_HEIGHT
3	Machine reference (X+)	real	ID_POSX
4	Machine reference (Y+)	real	ID_POSY
5	Machine reference (Z)	real	ID_POSZ
6	Machine reference (A)	real	ID_POA
7	Machine reference (B)	real	ID_POSB
8	Machine reference (C)	real	ID_ROTATION

22061: Agie cut data*Used in:* **Wire (Agie interface)***Definition:* **22061**
1 2 3 4 5 6 7 8 9 10 11 12See [Wirepath parameters: Cut parameters page](#) on page 170.

Position	Description	Type	SBL command
1	Compensation: punch vs. die ▪ 0= punch ▪ 1 = die ▪ -1 = disabled (for example, an open chain)	int	ID_PUNCH

Position	Description	Type	SBL command
2	Compensation: left or right ▪ 0= left ▪ 1 = right ▪ -1 = disabled (for example, a closed chain)	int	ID_PUNCH
3	Has minimum Agievision radius been applied to the last cut ?	int	ID_RADIUSMINLA
4	<i>Not used</i>	<i>int</i>	
5	Reverse cut?	int	ID_REV CUT
6	The number of working steps without inversion.	int	ID_ASWITHOUT
7	Separation cut length	real	ID_SEPCUT
8	Separation cut clearance	real	ID_CLEARANCETRENN
9	Clearance distance between punch and die chains	real	ID_CLEARANCE
10	<i>Not used</i>	<i>int</i>	
11	<i>Not used</i>	<i>int</i>	
12	<i>Not used</i>	<i>real</i>	



22062: Start point name

Used in: **Wire (Agie interface)**

Definition: **22062**
string

See [Wirepath parameters: Start Point page](#) on page 170.

Position	Description	Type	SBL command
1	Start point name	string	ID_STP

22063: Start point data

Used in: **Wire (Agie interface)**

Definition: **22063**
1 2 3 4

See [Wirepath parameters: Start Point page](#) on page 170.

Position	Description	Type	SBL command
1	Start point (X)	real	ID_POSX
2	Start point (Y)	real	ID_POSY
3	Start point (Z)	real	ID_POSZ
4	Start point diameter	real	ID_DIAMETER

22064: Entry data*Used in:* **Wire (Agie interface)***Definition:* **22064**
1 2 3 4 5 6 7 8See [Wirepath parameters: Entry page](#) on page 171.

Position	Description	Type	SBL command
1	Entry position: ▪ 0= Beginning of element ▪ 1 = Middle of element ▪ 2 = End of element	int	ID_ENTRYTIPO
2	Type of entry: ▪ 0= Free ▪ 1 = Perpendicular ▪ 2 = Tangential	int	ID_ENTRYMODE
3	Contour separation distance	real	ID_GEOCOMTRENN
4	Entry distance	real	ID_COMMPOINTENTRY
5	Increment entries (increment distance for each working step)	real	ID_SETENTD
6	Entry dislocation (new entry distance from previous entry point)	real	ID_SETENTM
7	Entry "A" distance (deviation distance from start point to contour entry, in Y direction)	real	ID_SETENTA
8	Entry "B" distance (deviation distance from start point to contour entry, in X direction)	real	ID_SETENTB

22065: Exit data*Used in:* **Wire (Agie interface)***Definition:* **22065**
1 2 3 4See [Wirepath parameters: Exit page](#) on page 171.

Position	Description	Type	SBL command
1	Type of exit: ▪ 0= Free ▪ 1 = Perpendicular ▪ 2 = Tangential	int	ID_EXITMODE
2	Exit distance	real	ID_COMMPOINTEXIT
3	Exit "A" distance (deviation distance from contour exit, parallel to exit contour element)	real	ID_SETUSCA

Position	Description	Type	SBL command
4	Exit "B" distance (deviation distance from contour exit, perpendicular to exit contour element)	real	ID_SETUSCB



22066: Taper thread data

Used in: **Wire (Agie interface)**

Definition: **22066**
1 2 3 4 5 6 7

See [Wirepath parameters: Threading page](#) on page 172.

Position	Description	Type	SBL command
1	Taper thread (X)	real	ID_POSX
2	Taper thread (Y)	real	ID_POSY
3	Taper thread (Z)	real	ID_POSZ
4	Taper thread (Xs)	real	ID_POSX_S
5	Taper thread (Ys)	real	ID_POSY_S
6	Taper thread (Zs)	real	ID_POSZ_S
7	Start hole diameter	real	ID_DIAMETER

22067: Taper data

Used in: **Wire (Agie interface)**

Definition: **22067**
1 2 3 4 5 6

These parameters are only used for Contour wirepaths. See [Wirepath parameters: Taper page](#) on page 172.

Position	Description	Type	SBL command
1	Taper type and direction: ▪ 0 = left taper (upper wire guide moves left) ▪ 1 = right taper (upper wire guide moves right) ▪ 2 = fixed taper (defined by the X and Y component fields)	int	ID_TAPERMODE
2	Taper (Z)	real	ID_POSZ
3	Taper angle; if taper type = 0, ID_TAPER is output as negative value, if taper type = 1, ID_TAPER is output as positive value.	real	ID_TAPER
4	Taper (X component)	real	ID_TAPER
5	Taper (Y component)	real	ID_TAPERP

Position	Description	Type	SBL command
6	Isoradius: ▪ 0 = Default (conical) ▪ 1 = Isoradius	int	none



22068: Corner data

Used in: **Wire (Agie interface)**

Definition: **22068**
1 2 3 4

See [Wirepath parameters: Corners page](#) on page 173.

Position	Description	Type	SBL command
1	External corner type: ▪ 0 = Minimum radius ▪ 1 = Sharp-edged ▪ 2 = Fixed radius	int	ID_E_TYPE
2	External corner radius (for fixed-radius corners)	real	ID_E_VALUE
3	Internal corner type: ▪ 0 = Minimum radius ▪ 1 = Sharp-edged ▪ 2 = Fixed radius	int	ID_I_TYPE
4	Internal corner radius (for fixed-radius corners)	real	ID_I_VALUE

22069: Attribute data

Used in: **Wire (Agie interface)**

Definition: **22069**
1 2 3 4

See [Wirepath parameters: Attributes page](#) on page 173.

Position	Description	Type	SBL command
1	Piece difficulty level: ▪ 0 = Normal ▪ 1 = More difficult ▪ 2 = Still more difficult ▪ 3 = Most difficult Note: these are written to the NCI as 0–3, but are written to the SBL file as 1–4.	int	ID_WORKCOND
2	Trim cut security level increment	real	ID_DELTAPS
3	<i>Not used</i>	<i>int</i>	

22070: Collar data*Used in:* **Wire (Agie interface)***Definition:* **22070**
1 2 3 4 5

These parameters are used for collar operations only. Note that the quality setting parameters for LC1, LC2, and LC3 are output on line 22058. See [Wirepath parameters: Collar page](#) on page 174.

Position	Description	Type	SBL command
1	Type of collar: ▪ 0 = Conical section of wirepath opens to the top ▪ 1 = Conical section of wirepath opens to the bottom ▪ 2 = Conical sections of wirepath open to both the top and bottom	int	ID_COLLAR
2	Collar Z1	real	ID_POSZ
3	Collar Alfa 1 (taper angle)	real	ID_TAPER
4	Collar Z2	real	ID_POSZ
5	Collar Alfa 2 (taper angle)	real	ID_TAPER

22071: Group name*Used in:* **Wire (Agie interface)***Definition:* **22071**
string

This is used for No core and collar operations only. See [Wirepath parameters: Group page](#) on page 174.

Position	Description	Type	SBL command
1	Group name	string	CreateGroup

22072: Group wire name*Used in:* **Wire (Agie interface)***Definition:* **22072**
string

This is used for No core and collar operations only. See [Wirepath parameters: Group page](#) on page 174.

Position	Description	Type	SBL command
1	Group wire name	string	ID_THREAD

22073: Group data

Used in: **Wire (Agie interface)**

Definition: **22073**
1 2 3 4 5 6 7



These parameters are used for No core and collar operations only. See [Wirepath parameters: Group page](#) on page 174.

Position	Description	Type	SBL command
1	Erosion sequence priority for group.	int	ID_PRIORITY
2	Group machine reference (X)	real	ID_POSX
3	Group machine reference (Y)	real	ID_POSY
4	Group machine reference (Z)	real	ID_POSZ
5	Group machine reference (A)	real	ID_POA
6	Group machine reference (B)	real	ID_POSB
7	Group machine reference (C)	real	ID_ROTATION

Interface reference

Control definition: Control Model page



Control definition: Wire Machine Group-C:\McamX4\CNC_MACHINES\AGIE GENERIC AGIEVISION_AWF 4X WIRE.WMD

Existing definitions Control type: Wire Manufacturer: Agie/Charmilles

Post processors: C:\McamX4\wire\posts\Agie Generic Agievision_ Description: Generic Agievisions AWF (Agie Work Flow)


Control topics:



- ? Tolerances
- ? Communications
- ? Files
- Control Model
 - Wire
- ? NC Output
- ? Misc. Int/Real Values
- ? Work System
- ? Linear
- ? Arc
- ? Feed
- ? Cutter Compensation
- ? Start/Leads
- ? Cuts

Machine model: Agie Challenge V2 **22001**

Control version: **V4.01** **22002**
Prior V3.04
V3.04
V4.01
V5.0

Machine group properties: Piece Setup tab



Machine group properties: Piece Details tab*Wirepath parameters: Machining page*

Wirepath parameters: User Tech (Technology Database) dialog box

Technology Database

Quality Target (Agie)

- Ra_0.01_
- Ra_0.02_
- Ra_0.03_
- Ra_0.04_
- Ra_0.05_
- Ra_0.06_
- Ra_0.07_
- Ra_0.08_
- Ra_0.09_

Quality Target (User Defined) Check to create Quality on machine

<input checked="" type="checkbox"/> User setting	Add
22058:5 22058:15	Change
22058:10 22058:20	Delete

Quality Name

User setting

Roughness

- 0.05[um]Ra
- 0.06[um]Ra
- 0.07[um]Ra
- 0.08[um]Ra
- 0.09[um]Ra

Tolerance Tf

- 0.5[um]
- 1.0[um]
- 1.5[um]
- 2.0[um]
- 2.5[um]

Tolerance Tkm +/-

1[um]

Speed 22058:4 22058:14 Quality
 22058:9 22058:19



Wirepath parameters: Cut parameters page

Cut Parameters

- Punch **22061:1**
- Die
- Left **22061:2**
- Right
- 22061:3** Minimum Radius last work
- 22061:5** Reverse Cut
- Working st. wo. Inversion **0 22061:6**
- Separation Cut **0.05 22061:7**
- Separation Cut Clearance **0.0 22061:8**
- Clearance **0.0 22061:9**

Quick View Settings
Wire Dia: 0.007874



Quick Start

Wirepath parameters: Start Point page

Start Point

Startpoint name **22062**

X **0.0 22063:1**

Y **0.0 22063:2**

Z **-1.0 22063:3**

Diameter **0.0 22063:4**

Wirepath parameters: Entry page

Wirepath Type
Group
Rough

- Cut Parameters
 - Start Point
 - Entry** (highlighted)
 - Exit
 - Threading
 - Corners
 - Attributes
 - Misc. Values
 - Aux. Registers
- Finish**

Quick View Settings
Wire Dia: 0.009842

Contour Separation
 0.0 **22064:3**

Entry → Contour
 0.0 **22064:4**

Increment of Entries
 0.0 **22064:5**

Entry Dislocation
 0.0 **22064:6**

A:
 0.0 **22064:7**

B:
 0.0 **22064:8**

22064:1

Beginning of Element

Middle of Element

End of Element

22064:2
 Free

Perpendicular

Tangential

Wirepath parameters: Exit page

Wirepath Type
Group
Rough

- Cut Parameters
 - Start Point
 - Entry
 - Exit** (highlighted)
 - Threading
 - Corners
 - Attributes
 - Misc. Values
 - Aux. Registers
- Finish**

Quick View Settings
Wire Dia: 0.009842

Contour → Exit
 0.0 **22065:2**

A:
 0.0 **22065:3**

B:
 0.0 **22065:4**

22065:1
 Free

Perpendicular

Tangential

Wirepath parameters: Threading page



Quick Start

Wirepath Type


- Group
- Rough
- Cut Parameters
- Start Point
- Entry
- Exit
- Threading**
- Corners
- Attributes
- Misc. Values
- Aux. Registers
- Finish

Start Point

X	0.0	22066:1
Y	0.0	22066:2
Z	-1.0	22066:3

Quick View Settings

Wire Dia:	0.009842
-----------	----------



+Z
+Y
+X

X: 0.0 **22066:1**
Y: 0.0 **22066:2**
Z: -1.0 **22066:3**

Xs: 0.0 **22066:4**
Ys: 0.0 **22066:5**
Zs: 0.0 **22066:6**





Starhole Diameter: 0.0 **22066:7**

Wirepath parameters: Taper page



Quick Start

Wirepath Type


- Machining
- Cut Parameters
- Start Point
- Entry
- Exit
- Threading
- Taper**
- Corners
- Attributes
- Misc. Values
- Aux. Registers

Start Point

Z:	0.0	22067:2
Alfa:	0.0	22067:3

Quick View Settings

Wire Dia:	0.007874
-----------	----------



22067:1

Z: 0.0 **22067:2**
Alfa: 0.0 **22067:3**

X Component: 0.0 **22067:4**
Y Component: 0.0 **22067:5**

Default **22067:6**
 Isoradius

Wirepath parameters: Corners page



Wirepath parameters: Attributes page

Wirepath parameters: Group page

Wirepath Type

- Group
- Collar
- Cut Parameters
- Start Point
- Corners
- Attributes
- Misc. Values
- Aux. Registers

Group: 22071

Wire: Cobra Cut A 0.25 22072
[Tp-Gamma, 0.250]

Priority: 1 22073:1

Distance piece/group reference --> Machine reference

X+ 0.0 22073:2	A 0.0 22073:5
Y+ 0.0 22073:3	B 0.0 22073:6
Z 0.0 22073:4	C 0.0 22073:7



Wirepath parameters: Collar page

Wirepath Type

- Group
- Collar**
- Cut Parameters
- Start Point
- Corners
- Attributes
- Misc. Values
- Aux. Registers

22070:1 (value = 0)

22070:1 (value = 1)

22070:1 (value = 2)

Quick View Settings

Wire Dia: 0.009842

Quality LC1: Ra_1.50_ [1.500, 1.000, 1.000] User Tech

Quality LC2: Ra_1.50_ [1.500, 1.000, 1.000] User Tech

Quality LC3: Ra_1.50_ [1.500, 1.000, 1.000] User Tech

Z1: 0.0 22070:2 **Z2:** 0.0 22070:4

Alfa1: 0.0 22070:3 **Alfa2:** 0.0 22070:5





chapter 4

Parameter Reference



See [Capturing values for 10000s parameters](#) on page 14 to learn more about capturing parameter values in your post.

This chapter lists every parameter used in Mastercam X4. It is divided into the following sections:

- ❖ [Operation & toolpath parameters](#)page 178
- ❖ [Machine definition parameters](#)page 287
- ❖ [Control definition parameters](#)page 350
- ❖ [Machine group parameters](#)page 397

Traditionally, operation parameters have been numbered 10000–19999. Recent Mastercam versions have seen this range expand:

- Mastercam X3 introduced 30000s parameters, which are reserved for use by C-hooks; see page 245.
- Mastercam X4 introduced operation parameters numbered in the 40000s. These are no different from the traditional 10000s parameters; we just ran out of numbers in that range.

Throughout these sections, notes and annotations indicate parameters that are only used in previous versions of Mastercam or that are longer used, and where appropriate, their replacements in later versions.

Operation & toolpath parameters



Common parameters

General operation parameters

Information used to write the file (header)

19998	<i>Size of the header (removed for X3)</i>
19997	<i>Size of the operation structure (removed for X3)</i>
19996	<i>Major version number (removed for X3)</i>
19995	<i>Minor version number (removed for X3)</i>
19994	<i>Toolpath Group name for these operations (removed for X3)</i>

OPERATION

15237	Operation ID (op_id\$)
15238	Toolpath operation code (tool_op\$)
15239	Toolpath comment
15240	Slot
OP_DB	
OP_COMMON	
OP_FILTER	
OP_TOOL_INFO	
OP_CC	
OP_CC	
OP_VIEW (Tplane)	
OP_VIEW002 (Cplane)	
OP_VIEW003 (WCS view data)	
OP_MISC	
OP_TOOL_DISPLAY	
OP_AUX_FILE	
OP_CANNED_TEXT	
OP_SMOOTHING	(new for X4)
OP_SPAWNED_INFO	(new for X4)
OP_V8	
OP_DEPTH_CUTS	
OP_MULTI_CUTS	
OP_LEAD_IO	

OP_HOME_POS	
OP_ROTARY	
OP_COMMON_LATHE	
OP_HOME_POS	
15329	Version
15544	Data stream ID
15545	Axis combination ID
	Mill Toolpaths
PRM_DRILL	
PRM_CONTOUR	
PRM_POCKET	
PRM_XFORM	
PRM_SRF_RGH_PARALLEL	
PRM_SRF_RGH_RADIAL	
PRM_SRF_RGH_PROJECT	
PRM_SRF_RGH_FLOWLINE	
PRM_SRF_RGH_CONTOUR	
PRM_SRF_RGH_POCKET	
PRM_SRF_FIN_PARALLEL	
PRM_SRF_FIN_RADIAL	
PRM_SRF_FIN_PROJECT	
PRM_SRF_FIN_FLOWLINE	
PRM_SRF_FIN_CONTOUR	
PRM_C-HOOK	
PRM_CIRCMILL	
PRM RULED	
PRM REVOLVED	
PRM LOFTED	
PRM_SWEEP2D	
PRM_SWEEP3D	
PRM_COONS	
PRM_CURVE_5AX	
PRM_SRF_FIN_PENCIL	
PRM_SRF_FIN_LEFTOVER	
PRM_SRF_FIN_STEEP	
PRM_SRF_FIN_SHALLOW	
PRM_SRF_FIN_CONSCALOP	
PRM_SRF_RGH_PLUNGE	



PRM_SRF_FLOW5AX	
PRM_SRF_4AX	
PRM_SWARF_5AX	
PRM_CIRCLE_5AX	(new for X4)
PRM_LFINISH	
PRM_LROUGH	
PRM_LGROOVE	
PRM_LTHREAD	
PRM_LDRILL	
PRM_LATHE_FACE	
PRM_LCUTOFF	
PRM_WIRE_CONTOUR	
PRM_WCAN_CYCLE	
PRM_WIRE_NOCORE	
PRM_WIRE_POINT	
PRM_WIRE_4AXIS	
PRM_THDMILL	
PRM_TRIMMED	
PRM_SOLID_DRILL	
PRM_SLOTMILL	
PRM_HELIX_BORE	
PRM_SRF_RGH_RESTMILL	
PRM_NESTING	
PRM_SRF_FIN_BLEND (X)	
PRM_MSURF_5AX	(X)
PRM_SLICE_5AX (X)	(X)
PRM_PORT_5AX (X)	(X)
PRM_TAB_CUTOFF	Deleted in X2
PRM_SRF_HMM (X)	
PRM_2D_HMM	(new for X3)
FBM_DRILLPARAMETERS	(new for X3)
PRM_FBM_POCKET	(new for X3)
PRM_LCAN_FINISH	
PRM_LCAN_ROUGH	
PRM_LCAN_PATTERN	
PRM_LGROOVE	
PRM_LROUGH	
PRM_LFINISH	



PRM_LSTOCK_XFER	
PRM_LSTOCK_FLIP	
PRM_LBARFEED	
PRM_LCHUCK_CLAMP	
PRM_LTAILSTOCK	
PRM_LSTEADYREST	
PRM_PINCH_TURN	(new for X3)
PRM_CUSTOM_OP	
PRM_ADV_5AX	(X2)

**OP_DB**

15254	<i>Start of section fpos in binary file, -1 if not yet generated (removed in X3)</i>
15255	<i>End of section fpos in binary file, -1 if not yet generated (removed in X3)</i>
15083	Number of entities in this operation (for alloc)
15084	Number of boundaries in this operation (contour, pocket)
15085	High entity ID # (used to number boundaries)
15086	NCI marked for regeneration (dirty) (True/False)
15087	Selected for editing, deleting and reordering (True/False)
15088	Selection expanded in treeview (True/False)
15089	ASCII NCI has been generated and/or posted (True/False)
15090	Operation imported from library (True/False)
15330	Transform operation ID # that spawned this operation
15497	Aggregate head ID number assigned to this operation
15498	Tool position ID number assigned to this operation
15508	Which app last accessed this operation?: 0=none (the Mastercam .exe) 1=toolpath/contour 2=toolpath/pocket 3=toolpath/face 4=helix bore 5=slotmill 6=circle mill 10=surface machining appmch 20=multipath curve5ax 21=multipath swarf5ax 22=multipath msurf5ax 23=multipath flow5ax 24=multipath rotary4ax 25=multipath drill5ax
15509	Which version of the app
15511	Block id# assigned to this operation
15504	Operation id# that spawned this one

15092	Number of entities to display in Operation Manager
15093	Display toolpath (True/False)
15094	ID # of operation this operation replaced
15095	Binary NCI of operation has been edited (True/False)
15096	System level
<i>15256</i>	<i>Don't ever post this operation (removed for X3)</i>
15097	Operation contains solids toolpath entities (True/False)
15325	Op ID # of trimming operation, null_id for not trimmed
15326	Number of times the operation has been edited
15571	NCI read: true = NCI section has been read in, false = go get it when needed (X) (Used to be 15340 prior to Mastercam X.)
15499	Geometry sub-tree expanded (True/False)
15500	Last tab page in toolpath parameters page (zero-based)
<i>15580</i>	<i>pointer to head of backplot (removed in X3)</i>
<i>15581</i>	<i>pointer to tail of backplot (removed in X3)</i>
15582	source of group's feed rate
15577	Draw regen? (new for X3)
15608	Operation is synched? (new for X3)

OP_COMMON

10042	Program number
10040	Starting sequence number
10041	Sequence number increment
10020	Clearance plane
10021	Clearance: true = incremental, false = absolute
15100	Clearance plane on (True/False)
15374	Retract plane
10023	Retract: true = incremental, false = absolute
15101	Retract plane on (True/False)
10024	Feed plane
10025	Feed plane: true = incremental, false = absolute
10029	Toolpath depth
15103	Depth: true = incremental, false = absolute
10026	Rapid up from bottom depth (True/False)
15105	Calculated cycle time for NCI section
15106	Use reference point(s) (True/False)
10080	Toolpath reference (retraction) point – X
10081	Toolpath reference (retraction) point – Y
10082	Toolpath reference (retraction) point – Z
15107	NCI output destination file name
10010	Amount of stock to leave
10027	Top of stock



10028	Top of stock: true = incremental, false = absolute
15108	Force a tool change in nci (True/False)
15109	Use only entities contained in tp_group group id #'s (True/False)
15110	Use tp_ents from other operations (True/False)
15111	Operation group ID #
10007	For common parameter dialog cmp_to_tip (True/False)
15112	To batch (op's NCI not immediately generated) (True/False)
12258	Use reference point(s) (True/False)
12259	Second reference point – X
12260	Second reference point – Y
12261	Second reference point – Z
15327	Abs/inc, XYZ enabled
15339	Use clearance plane at start/end (True/False)
15601	Use rotation tool center point (X2)



OP_COMMON001

10701	<i>Clearance plane (removed for X3)</i>
10702	<i>Clearance: true = incremental, false = absolute (removed for X3)</i>
10700	<i>Clearance plane on (True/False) (removed for X3)</i>
10704	<i>Retract plane (removed for X3)</i>
10705	<i>Retract: true = incremental, false = absolute (removed for X3)</i>
10703	<i>Retract plane on (True/False) (removed for X3)</i>
10706	<i>Feed plane (removed for X3)</i>
10707	<i>Feed plane: true = incremental, false = absolute (removed for X3)</i>
15102	<i>Depth in Z of toolpath (removed for X3)</i>
10708	<i>Rapid up from bottom depth (True/False) (removed for X3)</i>

OP_COMMON002

10105	<i>Feed plane (removed for X3)</i>
10104	<i>Feed plane: true = incremental, false = absolute (removed for X3)</i>
10107	<i>Depth in Z of toolpath (removed for X3)</i>
10106	<i>Depth: true = incremental, false = absolute (removed for X3)</i>

OP_COMMON003

15098	<i>Clearance plane (removed for X3)</i>
15099	<i>Clearance: true = incremental, false = absolute (removed for X3)</i>

10505	<i>Retract plane (removed for X3)</i>
10516	<i>Retract: true = incremental, false = absolute (removed for X3)</i>
10504	<i>Feed plane (removed for X3)</i>
10514	<i>Feed plane: true = incremental, false = absolute (removed for X3)</i>
10506	<i>Depth in Z of toolpath (removed for X3)</i>
10518	<i>Depth: true = incremental, false = absolute (removed for X3)</i>
15104	<i>Rapid up from bottom depth (True/False) (removed for X3)</i>
15257	<i>For common parameter dialog (removed for X3)</i>

**OP_FILTER**

15134	Arc filter on (True/False)
15135	<i>Create arcs: true = use arcs, false = lines (removed in X3)</i>
15136	Maximum tolerance error
15137	Minimum arc radius
15138	Maximum arc radius
15082	Amount of look ahead
15340	Create arcs in XY plane (True/False)
15341	Create arcs in XZ plane (True/False)
15342	Create arcs in YZ plane (True/False)
15343	One way (True/False)
15693	0 = Use maximum tolerance for both lines and arcs; 1 = Tighten line filtering tolerance; 2 = Tighten arc filtering tolerance (new for X4)
15694	Reduced tolerance value if 15693 = 1 or 2 (new for X4)

OP_SMOOTHING

15684	Smoothing tolerance (new for X4)
15685	Segment length (new for X4)
15686	1 = Smoothing is turned on (new for X4)
15687	1 = Use fixed segment length (new for X4)
15688	1 = Shift points randomly along toolpath (try to avoid patterns in neighboring segments (new for X4)
15689	1 = Minimize number of points (enlarge spacing) (new for X4)

15690	1 = Present arcs as line segments (break arcs) (new for X4)
-------	--

**OP_SPAWNED_INFO**

15691	The operation ID of the parent FBM operation that spawned the current operation (new for X4)
15692	The type of FBM operation that spawned the current operation (new for X4)

OP_MISC

15182	True = on
15190	Misc ints 1-10
15191	Misc ints 1-10
15192	Misc ints 1-10
15193	Misc ints 1-10
15194	Misc ints 1-10
15195	Misc ints 1-10
15196	Misc ints 1-10
15197	Misc ints 1-10
15198	Misc ints 1-10
15199	Misc ints 1-10
15200	Misc reals 1-10
15201	Misc reals 1-10
15202	Misc reals 1-10
15203	Misc reals 1-10
15204	Misc reals 1-10
15205	Misc reals 1-10
15206	Misc reals 1-10
15207	Misc reals 1-10
15208	Misc reals 1-10
15209	Misc reals 1-10

OP_TOOL_DISPLAY

15235	Use tool display (True/False)
10085	Mode: true = step, false = run
10086	Delay in seconds
10087	Step mode: true = step, false = endpoints
10088	Amount of step increment
10089	Tool motion:True = animate, false = static

OP_ROTARY

15236	Rotary axis: true = on
-------	------------------------

15351	Rotation type: 1 = axis substitution, 2 = rotary axis positioning, 3 = 3-axis
15352	Rotary axis to rotate about: 1 = about X, 2= about Y, 3 = about Z
15258	Axis of rotation line (endpoint)
15259	Axis of rotation line (endpoint)
15260	Axis of rotation line (endpoint)
15261	Axis of rotation line (endpoint)
15262	Axis of rotation line (endpoint)
15263	Axis of rotation line (endpoint)
15558	Rotary diameter (was 10072) (X)
15371	Direction: CW or CCW
15372	Axis to substitute, relative to view: 1 = X, 2 = Y
15373	Angle point 0,0 rolls to
10073	Unroll enabled (True/False)
10074	Unroll tolerance

**OP_COMMON_LATHE**

13150	Use toolpath entry point (True/False)
13151	Toolpath start point
13152	Toolpath start point
13153	Toolpath start point
13154	Use toolpath retraction point (True/False)
13155	Update boundaries for current operation (True/False)
13156	Update boundaries for subsequent operations (True/False)
13157	Stock boundaries are valid for operation (True/False)
13158	Regenerate toolpath for tool collision (True/False)
13159	Entity ID for left stock boundary
13160	Entity ID for right stock boundary
13161	Entity ID for left chuck boundary
13162	Entity ID for right chuck boundary
13163	Entity ID for tailstock boundary
13173	Entry angle for remaining stock (in radians)
13174	Exit angle for remaining stock (in radians)
13175	Do remaining stock analysis for operation (True/False)
13196	Tool clearance: true = use clearance from operation, false = from job setup
13197	Boundary avoidance clearance for lathe tools
13198	Entry/exit vector clearance
13199	Keep uncut stock (True/False)
13204	Entity ID for steadyrest boundary

OP_AUX_FILE

15113	On (True/False)
15114	File name
15115	File date
15253	Aux file marked for regeneration (dirty) (True/False)

**OP_CANNED_TEXT**

15120	On (True/False)
15121	Canned text 0-99, 1000-1099, 2000-2099
15122	Canned text 0-99, 1000-1099, 2000-2099
15123	Canned text 0-99, 1000-1099, 2000-2099
15124	Canned text 0-99, 1000-1099, 2000-2099
15125	Canned text 0-99, 1000-1099, 2000-2099
15126	Canned text 0-99, 1000-1099, 2000-2099
15127	Canned text 0-99, 1000-1099, 2000-2099
15128	Canned text 0-99, 1000-1099, 2000-2099
15129	Canned text 0-99, 1000-1099, 2000-2099
15130	Canned text 0-99, 1000-1099, 2000-2099
15531	Additional canned text/events (X)
15532	Additional canned text/events (X)
15533	Additional canned text/events (X)
15534	Additional canned text/events (X)
15535	Additional canned text/events (X)
15536	Additional canned text/events (X)
15537	Additional canned text/events (X)
15538	Additional canned text/events (X)
15539	Additional canned text/events (X)
15540	Additional canned text/events (X)

OP_V8

15131	The 'from pt' used when translating – X
15132	The 'from pt' used when translating – Y
15133	The 'from pt' used when translating – Z
15602	<i>Tool change type (removed for X3)</i>
15603	Tool change approach event list (X2)
15604	Tool change approach event list (X2)
15609	Tool change state (new for X3)
15610	UID for tool change event list, approach (new for X3)
15634	UID for tool change event list, retract (new for X3)
15658	UID for tool change event list, null tool change (new for X3)
15682	Tool change event list, null tool change (new for X3)

OP_DEPTH_CUTS

15211	Depth cuts: true = on
10065	Max rough step size
10066	Number of finish cuts
10067	Z depth of finish cuts
10068	Stock to leave
15378	Output subprogram labels (True/False)
10069	Keep tool down (True/False)
10064	Use island depths (True/False)
15379	Depth cut order: true = by depth, false = by contour
15452	Subprogram output mode: true = incremental, false = absolute

**OP_MULTI_CUTS**

15214	Multi passes: true = on
15560	Number of roughing cuts (was 10106) (X)
15561	Depth of roughing cuts (was 10107) (X)
15380	Number of finish cuts
15381	Depth of finish cuts
15385	Keep tool down (True/False)

Tool settings**OP_TOOL_INFO**

10002	Tool number
10090	Tool type ID number
10091	Radius type: None, corner or full
10005	Tool diameter
10006	Tool corner radius
15139	Threads per inch or thread pitch (mm)
10092	Tool tip angle
10003	Diameter offset number
10004	Length offset number
10030	Feed rate
10031	Plunge rate
15140	Retract rate
10034	Spindle speed
15141	Merged from ASCII NCI file (True/False)
10035	Spindle speed is CSS (True/False)
15345	Feed rate is actually a surface finish (True/False)



15375	Plunge feed rate is actually a surface finish (True/False)
10022	Coolant: 0 = off, 1 = flood, 2 = mist, 3 = tool (spindle)
15143	Number of flutes
10093	Tool material: HSS, CAR, etc.
10094	Tool description
15144	Mastercam tool reference geometry filename
LTOOL_REC	
15145	Values in metric (True/False)
15146	Station number for mill-turn
15147	Active turret (for mill-turn)
15148	Active spindle (for mill-turn)
15149	Internal tool ID #
10036	Maximum spindle speed (lathe)
15376	Custom tool display comes from: auto(0), file (1) or level (2)
15377	Tool reference level
15541	Which machine group it belongs to (X)
15542	0 = not a virtual turret, 1+ = virtual turret number, use with MATTs (X) Deleted in (X2)
15543	Component group to which tool belongs (X)
OP_TOOL_INFO002	
13165	<i>Tool diameter (removed for X3)</i>
13166	<i>Tool corner radius (removed for X3)</i>
15139	<i>Threads per inch or thread pitch (mm) (removed for X3)</i>
10512	<i>Tool tip angle (removed for X3)</i>
13167	<i>Diameter offset number (removed for X3)</i>
15377	<i>Tool reference level (removed for X3)</i>
OP_TOOL_INFO003	
14050	<i>Tool corner radius (removed for X3)</i>
14051	<i>Threads per inch or thread pitch (mm) (removed for X3)</i>
14052	<i>Tool tip angle (removed for X3)</i>
14053	<i>Plunge rate (removed for X3)</i>
14054	<i>Retract rate (removed for X3)</i>
14055	<i>Spindle speed (removed for X3)</i>
14056	<i>Spindle speed is CSS (True/False) (removed for X3)</i>
14124	<i>Feed rate is actually a surface finish (True/False) (removed for X3)</i>
14125	<i>Plunge rate is actually a surface finish (True/False) (removed for X3)</i>
14058	<i>Coolant: 0 = off, 1 = flood, 2 = mist, 3 = tool (spindle) (removed for X3)</i>
14059	<i>Number of flutes (removed for X3)</i>
14060	<i>Station number (for mill-turn) (removed for X3)</i>

14061	<i>Active turret (for mill-turn) (removed for X3)</i>
14062	<i>Active spindle (for mill-turn) (removed for X3)</i>
14063	<i>Internal tool ID # (removed for X3)</i>
14064	<i>Maximum spindle speed (lathe) (removed for X3)</i>

**OP_CC**

15346	Compensation type: 0 = computer 1 = control 2 = wear 3 = reverse wear 4 = off
15347	Compensation direction: 0 = left, 1 = right
10070	Roll around sharp corners
15563	Optimize: (applicable only when type = COMP_CONTROL) (True/False) (X) (was 10124 before X)

OP_CC001 (for Pocket paths)

10426	<i>Optimize: (applicable only when type = COMP_CONTROL) (True/False) (removed for X3)</i>
-------	---

OP_CC002 (for Lathe and Wire operations)

15151	<i>Optimize: (applicable only when type = COMP_CONTROL) (True/False) (removed for X3)</i>
-------	---

LTOOL_REC

13200	Tool orientation number
13201	Corner radius
13202	Width (tool clearance data)
15241	Height (tool clearance data)
15242	Angle (in radians)
15243	Rake angle (in radians)
15244	Tool center position
15245	Tool center position
15246	back_v
15247	back_v
15248	front_v
15249	front_v
15250	Back used (True/False)
15251	Front used (True/False)
15552	Tool Angle
15553	Spindle orient angle

View information



OP_VIEW (Tplane)

15152	Tool plane is on
15153	Tool plane view number at time of creation
15154	Tool plane view matrix
15155	Tool plane view matrix
15156	Tool plane view matrix
15157	Tool plane view matrix
15158	Tool plane view matrix
15159	Tool plane view matrix
15160	Tool plane view matrix
15161	Tool plane view matrix
15162	Tool plane view matrix
15163	Tool plane origin (world coordinates)
15164	Tool plane origin (world coordinates)
15165	Tool plane origin (world coordinates)
15348	Named view ID #
15166	User defined work offset number

OP_VIEW002 (Cplane)

15167	Construction plane is on
15168	Construction plane view number at time of creation
15169	Construction plane view matrix
15170	Construction plane view matrix
15171	Construction plane view matrix
15172	Construction plane view matrix
15173	Construction plane view matrix
15174	Construction plane view matrix
15175	Construction plane view matrix
15176	Construction plane view matrix
15177	Construction plane view matrix
15178	Construction plane origin (world coordinates)
15179	Construction plane origin (world coordinates)
15180	Construction plane origin (world coordinates)
15349	Named view ID #
15181	User-defined work offset number

OP_VIEW003 (WCS view data)

15355	WCS is on
15356	WCS plane view number at time of creation
15357	WCS plane view matrix
15358	WCS plane view matrix



15359	WCS plane view matrix
15360	WCS plane view matrix
15361	WCS plane view matrix
15362	WCS plane view matrix
15363	WCS plane view matrix
15364	WCS plane view matrix
15365	WCS plane view matrix
15366	WCS plane origin (world coordinates)
15367	WCS plane origin (world coordinates)
15368	WCS plane origin (world coordinates)
15369	Named view ID #
15370	User-defined work offset number

Lead in/out, entry/exit

OP_LEAD_IO

15233	Lead in/out: true = on
OP_ENTRY_EXIT	
15562	Overlap amount (was 10117) (X)
15234	Enter at midpoint of first entity for closed contours (True/False)
15328	Check entry/exit motion for gouges (True/False)
15449	Output first move before plunge (True/False)
15450	Output last move after plunge (True/False)

OP_LEAD_IO001

10420 | *Overlap amount (removed for X3)*

OP_ENTRY_EXIT

15219	Use entry / exit entities (True/False)
15386	Line: true = perpendicular, false = tangent (was 10102) (X)
15387	Length of entry/exit line (was 10103) (X)
15220	Line ramp height
15388	Radius of entry/exit arc (was 10104) (X)
15559	Sweep angle of entry arc (in radians) (was 10105) (X)
15221	Arc helix height
15382	Output entry/exit on only first/last depth cut (True/ False)
15222	Use entry/exit point (True/False)
15223	Use entry/exit point depth (True/False)
15224	Length of entry/exit line as % of tool diameter

15225 | Radius of entry/exit arc as % of tool diameter

OP_ENTRY_EXIT001

15565	<i>Line: true = perpendicular, false = tangent (was 10307)</i> (X) (removed for X3)
15566	<i>Length of entry/exit line (was 10310)</i> (X) (removed for X3)
15567	<i>Radius of entry/exit arc (was 10311)</i> (X) (removed for X3)
15568	<i>Sweep angle of entry arc (in radians) (was 10312)</i> (X) (removed for X3)
10419	<i>Output entry/exit on only first/last depth cut (True/False) (removed for X3)</i>
15226	Use entry exit entities (True/False)
15383	Line: true = perpendicular, false = tangent (was 10118) (X)
10119	Length of entry/exit line
15227	Line ramp height
10120	Radius of entry/exit arc
10121	Sweep angle of entry arc (in radians)
15228	Arc helix height
15389	Output entry/exit on only first/last depth cut (True/False)
15229	Use entry/exit point (True/False)
15230	Use entry/exit point depth (True/False)
15231	Length of entry/exit line as % of tool diameter
15232	Radius of entry/exit arc as % of tool diameter



OP_ENTRY_EXIT_PK001

10421	<i>Line: true = perpendicular, false = tangent (removed for X3)</i>
10422	<i>Length of entry/exit line (removed for X3)</i>
10423	<i>Radius of entry/exit arc (removed for X3)</i>
10424	<i>Sweep angle of entry arc (in radians) (removed for X3)</i>
10425	<i>Output entry/exit on only first/last depth cut (True/False) (removed for X3)</i>

OP_HOME_POS

15215	Home pos: true = on
15216	Tool home position X
15217	Tool home position Y
15218	Tool home position Z

OP_HOME_POS001

10008	<i>Tool home position X (was 10007)</i> (X) (removed for X3)
10009	<i>Tool home position Y (was 10008)</i> (X) (removed for X3)

13168 | Tool home position Z (removed for X3)



Mill & Router parameters

Contour toolpaths

PRM_CONTOUR

PRM_CTOURPOCK	
10101	Infinite look-ahead is enabled (True/False) (Pre-X)
10071	Infinite look-ahead is enabled (True/False) (X)
10113	Maximum depth variance
PRM_REMACH_CTOUR	
PRM_CHAMFER_CTOUR	
12014	Contour type: 0 = 2D Contour 1 = 3D Contour 2 = 2D Chamfer 3 = 3D Chamfer 4 = Ramp 5 = Remaching
12015	Tapered wall contour enabled (True/False)
12016	Taper angle (in radians)
12017	Depth cut order: true = by depth, false = by contour
PRM_EXT_SHORT	Start extend/shorten
PRM_EXT_SHORT002	End extend/shorten
15485	Entry feed rate override
15486	Entry feed rate override is enabled (True/False)
15487	Exit feed rate override
15488	Exit feed rate override is enabled (True/False)
PRM_TP_COMMON	(X)
PRM_TAB	(X)
PRM_CHAIN_SORT	(X)
PRM_OSCILLATE_CTOUR	(new for X3)
12709	Position tabs automatically, based on distance between tabs (new for X3)
12710	Max distance between tabs (used in conjunction with 12709) (new for X3)
PRM_ROUT_COMMON	<i>(Pre-X)</i>
PRM_ROUT_TAB	<i>(Pre-X)</i>

**PRM_REMACH_CTOUR**

10431	Remaining stock mode: 0 = all previous operations, 1 = the previous operation, 2 = rough tool diameter
10432	Roughing tool diameter
12000	Clearance as a percentage of the tool diameter
10433	Clearance to unmachined stock
10434	Machine complete finish passes (True/False)
10410	Remachining tolerance percentage
10411	Remachining tolerance
12002	Display stock for remachining (True/False)

PRM_CTOURPOCK

12253	Linearization tolerance (used to be 10110) (X)
10314	Finish all (True/False) (used to be 10114) (X)
12004	Tip comp: true = tool tip, false = tool center

PRM_CTOURPOCK001

(this entire group removed for X3)

PRM_CHAMFER_CTOUR

12005	Chamfer width
12006	Chamfer tip offset
12007	Chamfer depth

PRM_RAMP_CTOUR

12008	Ramp contour option: 0 = angle, 1 = depth, 2 = plunge
12009	Ramp angle
12010	Ramp/plunge depth
12011	Ramp one way on open contours (True/False)
12012	Linearize ramp contour helixes (True/False)
12013	Ramp contour helix linearization tolerance
15507	True = output pass at final depth

PRM_EXT_SHORT

15489	Extend/shorten is enabled (True/False)
15490	Extend / shorten: true = extend, false = shorten
15491	Distance to extend / shorten
15492	Percentage of tool diameter

PRM_EXT_SHORT002

15493	Extend / shorten is enabled (True/False)
15494	Extend / shorten: true = extend, false = shorten
15495	Distance to extend / shorten
15496	Percentage of tool diameter

**PRM_ROUT_COMMON**(This group was replaced by **PRM_TP_COMMON** for Mastercam X.)**PRM_TP_COMMON**

16000	Breakthrough enabled (True/False)
16001	Breakthrough amount

PRM_ROUT_TAB(This group was replaced by **PRM_TAB** for Mastercam X.)**PRM_TAB**

16002	Tabs enabled (True/False)
16003	Automatically calculate tab positions (True/False)
16004	Number of tabs (for auto tab)
16005	Tab width
16006	Tab thickness
16007	Full thickness tab (True/False)
16008	Tab point: (0 = start, 1 = midpoint, 2 = end) of tab
16009	Tab entry/exit (0 = vertical, 1 = arc, 2 = ramp)
16010	Arc radius
16011	Percentage of tab thickness (arc radius)
16012	Ramp angle
16013	Use advanced auto tab positioning (True/False)
16014	Use feed plane for full height tabs (True/False)
16015	Use points on chain for start & tab positions (True/False)
16016	Minimum distance from endpoint
16017	Minimum distance between tabs
16018	Minimum distance from sharp corner
16019	Sharp corner angle
16020	X dimension of maximum size shape to tab
16021	Y dimension of maximum size shape to tab
16022	Tab all shapes
16053	Overwrite tab edit (True/False)
16054	Cutoff type (0 = none, 1 = after)
16055	Do tab cutoff pass on finish (True/False)

PRM_WIRE_WSORT(This group was replaced by **PRM_CHAIN_SORT** for Mastercam X.)

PRM_CHAIN_SORT

14072	Sort method
14073	Sort start angle for rotary sort

**PRM_OSCILLATE_CTOUR**

12706	Oscillation strategy (linear or highspeed) (new for X3)
12707	Distance along contour (new for X3)
12708	Maximum depth (new for X3)

Drill toolpaths

PRM_DRILL

10100	Drill cycle
10108	First peck increment
10109	Subsequent peck increment
10110	Peck clearance
10111	Retraction distance for chip break
10112	Dwell
10118	Pre-defined bore shift
10117	Add this amount to total depth
10115	Adjust depth per drill tip (True/False)
12018	Drill point sorting method used
15071	Custom drill cycle parameters
15072	Custom drill cycle parameters
15073	Custom drill cycle parameters
15074	Custom drill cycle parameters
15075	Custom drill cycle parameters
15076	Custom drill cycle parameters
15077	Custom drill cycle parameters
15078	Custom drill cycle parameters
15079	Custom drill cycle parameters
15080	Custom drill cycle parameters
15081	Use custom parameters is checked (True/False)
12019	Drill5ax output format axis type selected: 0=3 axis, 1=4 axis, 2=5 axis
12020	Use points and lines or points
12021	Tool axis option
12022	Tip position control
12023	Project type (to plane or surface)
12024	5-axis tool display length

	12025	Drill5ax output format 4-axis type axis selected (0 = X, 1 = Y, 2 = Z)
	12254	Plane vector for drill5ax plane option
	12255	Plane vector for drill5ax plane option
	12256	Plane vector for drill5ax plane option
	15212	Output 1018 NCI (sub program) line in drill cycle (True/False)
	15213	Subprogram output mode: true = incremental, false = absolute
	15277	Operation was created as a automatic start hole operation (True/False)
PRM_5AX_LIMIT		(new for X3)



Pocket toolpaths

PRM_POCKET

	PRM_CTOURPOCK	(new for X3)
	12045	Roughing enabled (True/False)
	12046	Finishing enabled (True/False)
	15564	Machining direction: true = climb mill, false = conventional (was 10401) (X)
	10315	Create additional finish operation (True/False)
	10208	Cutting method: 0 = zigzag, 1 = spiral inside out, 2 = spiral outside in (was 10300) (X)
	10302	Roughing step size
	10414	Roughing step size (percentage)
	10301	Roughing angle
	10416	Spiral inside to outside (True/False)
	10427	Minimize tool burial (True/False) (was 10415) (X)
	10304	Number of finish passes
	10305	Finish pass step size
	10417	Finish outer boundary (True/False)
	15569	Optimize finish passes (True/False) (was 10321) (X)
	10418	Keep tool down (True/False)
	10313	Output finish passes with rough pass (True/False)
	10410	Remachining tolerance (percentage)
	10411	Remachining tolerance
	10412	Display stock for remachining (True/False)
	10413	Display stock for constant overlap spiral (True/False)



PRM_TAPER	
PRM_RGH_ENTRY	
PRM_POCK_FACING	
15570	Compensation for finish passes (was 10350) (X)
15524	True = display stepover (X)
PRM_REMACH_POC K	
PRM_OPEN_POCK	
12017	Depth cut order: true = by depth, false = by pocket
10450	Pocket type: 0 = standard, 1 = facing, 2 = island facing, 3 = remachining, 4 = open
PRM_PKT_HSOPTS	
15474	Number of finish spring cuts
15475	Feed rate override
15476	Spindle speed override
15477	Feed rate override enabled (True/False)
15478	Spindle speed override enabled (True/False)
PRM_THINWALL	
15479	Entry feed rate override
15480	Entry feed rate override enabled (True/False)
15481	Exit feed rate override
15482	Exit feed rate override enabled (True/False)
PRM_CHAIN_SORT	
PRM_TP_COMMON	
PRM_ROUT_POCK	
16030	This parameter group replaced by PRM_POCKET . <i>Roughing enabled (True/False) (removed for X3)</i>
16031	<i>Finishing enabled (True/False) (removed for X3)</i>
16032	<i>Machining direction: true = climb mill, false = conventional (removed for X3)</i>
16033	<i>Create additional finish operation (True/False) (removed for X3)</i>
16034	<i>Cutting method: 0 = zigzag, 1 = spiral inside out, 2 = spiral outside in (removed for X3)</i>
16035	<i>Roughing step size (removed for X3)</i>
16036	<i>Roughing step size (percentage) (removed for X3)</i>
16037	<i>Roughing angle (removed for X3)</i>
16038	<i>Spiral inside to outside (True/False) (removed for X3)</i>
16039	<i>Minimize tool burial (True/False) (removed for X3)</i>
16040	<i>Number of finish passes (removed for X3)</i>
16041	<i>Finish pass step size (removed for X3)</i>

16042	<i>Finish outer boundary (True/False) (removed for X3)</i>
16043	<i>Optimize finish passes (True/False) (removed for X3)</i>
16044	<i>Keep tool down (True/False) (removed for X3)</i>
16045	<i>Output finish passes with rough pass (True/False) (removed for X3)</i>
16046	<i>Remachining tolerance percentage (removed for X3)</i>
16047	<i>Remachining tolerance (removed for X3)</i>
16048	<i>Display stock for remachining (True/False) (removed for X3) (removed for X3)</i>
16049	<i>Display stock for constant overlap spiral (True/False) (removed for X3)</i>
16050	<i>Compensation for finish passes (removed for X3)</i>
16028	<i>Depth cut order: true = by depth, false = by pocket (removed for X3)</i>
16051	<i>Pocket type: 0 = standard, 1 = facing, 2 = island facing, 3 = remachining, 4 = open (removed for X3)</i>

**PRM_TAPER**

12026	Tapered wall pocketing enabled (True/False)
12567	Tapered wall pocketing: Base taper angle (in radians) (was 10331) (X)
12568	Tapered wall pocketing: Island taper angle (in radians) (was 10332) (X)

PRM_RGH_ENTRY

12042	Rough entry on (True/False)
12569	Entry type: 0 = helix, 1 = ramp, 2 = entry point (was 10380) (X)

PRM_HELIX**PRM_RAMP****PRM_RAMP**

12030	Minimum length
12031	Maximum length
12032	Z clearance (relative to top of stock / previous depth)
12033	Zig plunge angle
10390	Zag plunge angle
12034	XY clearance
10388	Ramp direction
10391	Calculate ramp direction automatically (True/False)
12035	Direction: true = CCW, false = CW
12036	Entry attempts fail: true = skip, false = plunge
12037	Save boundary (True/False)



10392	Additional slot width
12038	Use entry point (True/False)
12555	Use entry point depth (True/False) (was 10400) (X)
12039	Minimum length % (of tool dia.)
12040	Maximum length % (of tool dia.)
12041	Entry feed rate: true = feed rate, false = plunge rate

PRM_POCK_FACING

12560	Overlap percentage (was 10406) (X)
10407	Overlap amount
12562	Approach distance (was 10408) (X)
12563	Stock above islands (was 10409) (X)
12043	Exit distance

PRM_REMACH_POCK

10431	Mode: 0 = all previous operations, 1 = previous operation, 2 = rough tool diameter
10432	Roughing tool diameter
12000	Clearance as a percentage of the tool diameter
10433	Clearance to unmachined stock
12001	Apply entry/exit curves to the rough pass (True/False)
10434	Machine complete finish passes (True/False)

PRM_OPEN_POCK

10441	Overlap as a percentage of tool diameter
12413	Overlap distance on the open side
12044	Use a specialized open cutting method (True/False)
40011	Use Standard pocket for closed chains option: 1 = this option is <i>not</i> selected (allows multiple & non-linear open edges); 0 = this option <i>is</i> selected. (new for X4)

PRM_PKT_HSOPTS

12419	Sharp corner smoothing length
12420	Channel mode: 0 = off, 1 = full material, 2 = everywhere (for deep Z cuts)
12309	Distance between channel loops (high speed)
12305	Channel radius (for high speed pocket)

PRM_THINWALL


15483	Thinwall on (True/False)
15484	Number of thinwall cuts
15503	Finish direction: true = climb cut, false = conventional cutting

Wireframe toolpaths



PRM_RULED

10208	Cutting method: 0 = zigzag, 1 = one way, 2 = circular, 3 = 5ax swarf
12212	5-axis swarf angle
12213	Constant Z cutting enabled (True/False)
12214	Constant Z cutting - initial
12215	Constant Z cutting - final
12216	Constant Z cutting - step
12217	Stepover amount (across cut distance)
12218	Trimming plane 1: 0 = X, 1 = Y, 2 = Z, 3 = none
12219	Trimming plane 1 coordinate
12220	Trimming plane 2 : 0 = X, 1 = Y, 2 = Z, 3 = none
12221	Trimming plane 2 coordinate
12222	Trimming plane control: true = trim the toolpath, false = trim the tool
12223	Gouge check: true = perp to machining angle, false = off
12004	Tip comp: true = tool tip, false = tool center
12224	Sync option setting: 0 = None , 1 = by Entity , ... 6 = Manual/Density



PRM_CHAIN_SORT

(X)

PRM_REVOLVED

12225	Axis: X, Y or L: L = toolpath point entity points to the axis
12226	Trim: N = nothing, H = height, W = width
12227	Shape: True = concave, false = convex
12228	Retract to reference plane (True/False)
12229	Retract amount (absolute)
12054	Stepover amount
12230	Center
12231	Axis Depth (abs)
12232	Height (under 'Trim toolpath to')
12233	Width – From (under 'Trim toolpath to')
12234	Width – To (under 'Trim toolpath to')



12235	Trim sign
12236	Trim sign
12004	True = comp to tool tip, false = tool center
12237	True = rapid between passes, false = feed (X)

PRM_CHAIN_SORT**PRM_SWEPT2D**


12239	Across cut distance
12241	Across: roll cutter around corners (0 = none, 1 = sharp, 2 = all)
12242	Across: cutter comp in computer (0 = right, 1 = left)
12243	Along: roll cutter around corners (0 = none, 1 = sharp, 2 = all)
12244	Along: cutter comp in computer (0 = right, 1 = left)
12004	Tip comp: true = tool tip, false = tool center
12224	Sync option setting: 0 = none, 1 = by entity, ... 6 = manual/density
12409	Infinite look ahead enabled (True/False)

PRM_CHAIN_SORT**PRM_SWEPT3D**

10208	Cut direction: 0 = zigzag, 1 = one way, 2 = circular, 3 = 5ax swarf
12238	Along cut distance
12239	Across cut distance
12004	Tip comp: true = tool tip, false = tool center
12224	Sync option setting: 0 = none, 1 = by entity, ... 6 = manual/density
12240	Direction: 0 = along, 1 = across
12245	Rotate/translate: 0 = rotate the across contour, 1 = translate
12246	Number of across contours: 1 or 2

PRM_CHAIN_SORT**PRM_COONS**

10208	Cut method: 0 = zigzag, 1 = one way, 2 = circular, 3 = 5ax swarf
12247	Blending: 0 = linear, 1 = parabolic, 2 = cubic, 3 = cubic with slope matching
12238	Along cut distance
12239	Across cut distance
12004	Tip comp: true = tool tip, false = tool center
12224	Sync option setting: 0 = none, 1 = by entity, ... 6 = manual/density

12240	Direction: 0 = along, 1 = across	 Quick Start
12248	Number of patches in across direction	
12249	Number of patches in along direction	
PRM_CHAIN_SORT	(X)	
PRM_LOFTED		
10208	Cut method: 0 = zigzag, 1 = one way, 2 = circular, 3 = 5ax swarf	
12238	Cutting direction: Along (True/False)	
12239	Cutting direction: Across (True/False)	
12004	Tip comp: true = tool tip, false = tool center	
12224	Sync option setting: 0 = None , 1 = by Entity , ... 6 = Manual/Density	
		
12240	Direction: 0 = along, 1 = across (X)	
PRM_CHAIN_SORT		

Circle toolpaths

PRM_CIRCMILL

PRM_TP_COMMON	(X)
12004	Comp to tip (True/False)
12107	Thread start angle
12206	Entry/exit arc sweep
10407	Overlap between entry and exit arcs
12207	Circle diameter (used when circles are defined by points)
12208	Start at center of circle (True/False)
12209	Enter along a line that is perpendicular to the entry arc (True/False)
12210	Enable roughing (True/False)
12055	Stepover as a percentage of the tool diameter
12054	Stepover
12211	Enable helical entry (True/False)

**PRM_HELIX**

12265

Machine finish passes at: true = all depths, false = final depth

PRM_ROUT_CIRC(This group deleted, replaced by **PRM_CIRCMILL**.)**PRM_HELIX**

10389

Minimum radius

10381

Maximum radius

10386

Z clearance (relative to top of stock / previous depth)

10382

Plunge angle (in radians)

10385

XY clearance

10384

Direction: true = CCW, false = CW

10397

Entry attempts fail: true = skip, false = plunge

10394

Follow boundary (True/False)

10395

Follow boundary on failure only (True/False)

10396

Minimum boundary length (for follow boundary)

10398

Save boundary (True/False)

10393

Output arc move(s) (True/False)

10383

Maximum error tolerance

10399

Use entry point (True/False)

12027

Minimum radius %

12028

Maximum radius %

12029

Entry feed rate: true = feed rate, false = plunge rate

PRM_THDMILL

12188

Number of active teeth

12189

Clearance plane depth

12190

Feed plane

12191

Top of thread

12192

Thread depth

12193

Values: 0 = absolute, 1 = incremental

12194

Thread pitch

12107

Thread start angle

12195

Overcut

12196

Entry/exit arc clearance

12197

Entry/exit line length

12198

Helical entry/exit at top of thread (True/False)

12199

Helical entry/exit at bottom of thread (True/False)

12200

Linearize helixes (True/False)

12201

Helix linearization tolerance

12202

Thread type: 0 = ID, 1 = OD

12203

Thread diameter

12204	Thread type: 0 = right hand, 1 = left hand
12571	Start at center (True/False) (was 12290) (X)
12205	Machining direction: 0 = top to bottom, 1 = bottom to top
12572	Perpendicular entry (True/False) (was 12291) (X)
12385	Taper angle (to centerline)
12657	Number of spring passes (new for X3)
12658	Feed rate to use when overriding programmed feed rate (new for X3)
12659	Spindle speed to use when overriding programmed spindle speed (new for X3)
12660	Override programmed feed rate? (Yes/No) (new for X3)
12661	Override programmed spindle speed? (Yes/No) (new for X3)

**PRM_SLOTMILL****PRM_CTOURPOCK**

12004	Comp to tip (True/False)
12107	Start angle
12206	Entry/exit sweep
10407	Overlap between entry and exit arcs
12207	Circle diameter (used when circles are defined by points)
12208	Start at center of circle (True/False)
12209	Enter along a line that is perpendicular to the entry arc
12386	Enable ramp entry (True/False)
12387	Ramp stepover as a percentage of the tool diameter
12388	Ramp stepover
12389	Ramp plunge angle
12390	Output helixes as arcs (True/False)
12391	Helix linearization tolerance
12392	Number of finish passes
12393	Finish pass stepover
12394	Number of rough passes
12395	Rough pass stepover
12396	Machine finish passes at: true = all depths, false = final depth
12397	Keep tool down (True/False) (X)

PRM_CHAIN_SORT**PRM_TP_COMMON****(new for X3)****PRM_HELIX_BORE**

12107	Start angle
12206	Entry/exit sweep

10407	Overlap
12207	Circle diameter
12208	Start at center of circle (True/False)
12209	Enter along a line
13298	Z step per revolution for roughing
12399	Number of roughing passes
12400	Roughing stepover
12401	Feed rate at final depth as a percentage
12402	Feed rate at final depth
12403	Output a finish pass (True/False)
12404	Z step per revolution for finishing
12393	Finish stepover
12405	Finish pass spindle speed as a percentage
12406	Finish pass spindle speed
12407	Finish pass feed rate as a percentage
12408	Finish pass feed rate
10393	Output arc move(s) (True/False)
12391	Helix linearization tolerance



Solid drill / autodrill toolpaths

PRM_SOLID_DRILL

AUTODRILLPRM	
SDETECT_DRILL_PARAMS	
15319	Delete dependants
15320	Basic
15321	Solid operation ID
15322	<i>Solid pointer (removed for X3)</i>
15323	Redetect on regen (True/False)
15324	Stock clearance
15502	Create points (True/False)
15513	Use custom drill parameters (True/False)
15514	Custom drill cycle
15515	Custom drill cycle
15516	Custom drill cycle
15517	Custom drill cycle
15518	Custom drill cycle
15519	Custom drill cycle
15520	Custom drill cycle
15521	Custom drill cycle
15522	Custom drill cycle
15223	Custom drill cycle

AUTODRILLPRM

	Note: These parameters do NOT get to the Post, since AutoDrill generates individual drilling toolpath operations.
15278	Tool type: 0=Drill, 1=Tap RH Coarse, 2=Tap RH Fine, 3=Tap LH Coarse, 4=Tap LH Fine, 5=Reamer, 6=Boring Bar, 7=Endmill
15279	Use filter arc (True/False)
15280	No warnings (True/False)
15281	Spot drill (True/False)
15282	Spot maximum depth
15283	Spot diameter
15284	Chamfer type: 0 = none, 1 = add depth to spot cycle, 2 = make new op
15285	Chamfer size
15286	Destination operation group id #
15287	Depth from top of arc (True/False)
15288	Tool library name
15289	Pre drill (True/False)
15290	Minimum pre-drill diameter
15291	Pre-drill diameter increment
15292	Pre drill stock
15293	Pre drill tip comp (True/False)
15294	Pre drill break thru
15295	Pre drill stock flag (True/False)
15296	PRM filename
15297	Tool match tolerance
15298	Tip comp (True/False)
15299	Break thru
15300	5-axis (True/False)
15301	View RB
15302	Group added (True/False)
15303	Use arc views (True/False)
15304	Use default diameter (True/False)
15305	Default diameter
15306	Sel

SDETECT_DRILL_PARAMS

15307	Minimum hole radius
15308	Maximum hole radius
15309	Include blind holes (True/False)
15310	Create arcs using this offset
15311	New geometry color
15312	Limit search to given plane (True/False)

15313	Plane to limit search to if limit by plane = True
15314	Include split cylinders (True/False)
15315	Limit by sweep code
15316	Limit sweep angle 0.0 - 360.0 degrees
15317	Limit sweep step size - controls # of sections tested along



Facing toolpaths

PRM_FACING

12051	Cutting method: 0 = zigzag, 1 = one way (climb), 2 = one way (conventional), 3 = one pass
12052	Move between cuts: 0 = high speed loops, 1 = linear, 2 = rapid
12053	Linearization tolerance
12054	Stepover distance
12055	Stepover distance as % of tool diameter
12056	Along overlap distance
12057	Along overlap as % of tool diameter
12058	Across overlap distance
12059	Across overlap as % of tool diameter
12060	Approach distance
12061	Approach distance as % of tool diameter
12062	Exit distance
12063	Exit distance as % of tool diameter
12064	Determine roughing angle automatically (True/False)
12065	Roughing angle
12066	Change feed rate between cuts (True/False)
12067	Feed rate between cuts
12068	Amount of stock to leave in Z
PRM_CHAIN_SORT	
12711	Select cutting method (new for X3)
12712	Turn on last pass option: Reverse direction of last pass / Even number of passes (new for X3)

Transform operations

PRM_XFORM

15557	Xform type: 8 = mirror, 13 = rotate, 16 = translate (was 10050) (X)
15069	Start of operation range to transform
15070	End of operation range to transform



15331	Don't delete transform source operation if make_ops = True (True/False)
15332	Work offset numbering: 0 = auto increment, 1 = maintain source operations, 2 = assign
15333	Start number work offsets with this number
15334	Increment work offsets by this number
15335	First match work offset in named views and ops (True/False)
15275	Force unique subprogram number for 'clump' option (True/False)
15276	Don't post the source operations (True/False)
15264	Don't skip original instance (True/False)
15000	NCI Grouping: true = group ops, false = separate ops
15001	Subprogram output mode: true = incremental, false = absolute
15002	Look for pre-defined work offset #'s when forming the Tplane (True/False)
15003	Transform options: true = transform geometry and make new ops false = transform toolpath only
15004	Translate NCI coordinates - leave tool plane intact (True/False)
15005	Output subprogram labels (True/False)
15006	Shift tool origin in NCI 1013 data (True/False)
PRM_XFORM_MIRROR	
PRM_XFORM_ROTATE	
PRM_XFORM_TRANSLATE	

PRM_XFORM_MIRROR

15020	Relative to operation. Cplane - tp_mirror_x , tp_mirror_1
15021	Coordinates translated to vw2 (True/False)
15051	Mirror axis — endpoint 1, in world coordinates
15052	Mirror axis endpoint— endpoint 1, in world coordinates
15053	Mirror axis endpoint— endpoint 1, in world coordinates
15054	Mirror axis endpoint— endpoint 2, in world coordinates
15055	Mirror axis endpoint— endpoint 2, in world coordinates
15056	Mirror axis endpoint— endpoint 2, in world coordinates
PRM_XFORM_VIEW	
15057	Reverse cutter compensation (True/False)



15058	Reverse toolpath (True/False)
15059	Method generated (endpoint, midpoint, etc.)
15060	Method generated (endpoint, midpoint, etc.)
15061	T values
15062	T values
15063	T values
15064	T values
15065	Selected entities ID numbers
15066	Selected entities ID numbers
15067	<i>Selected entities database pointers (removed for X3)</i>
15068	<i>Selected entities database pointers (removed for X3)</i>
PRM_XFORM_ROTATE	
15020	Rotation point: 1 = C view origin, 2 = point
15021	Coordinates translated to view 2 (True/False)
15042	Number of steps
15043	Rotation point in world coordinates (X)
15044	Rotation point in world coordinates (Y)
15045	Rotation point in world coordinates (Z)
15046	Rotation angle (in degrees)
PRM_XFORM_VIEW	
15047	Method generated: endpoint, midpoint, etc.
15048	T values
15049	T values
15050	Selected entities ID number
15067	<i>Selected entities database pointers (removed for X3)</i>
15273	Start angle (in degrees)
PRM_XFORM_TRANSLATE	
15020	Translation direction: 17 = rect, 18 = polar, 19 = between pts, 20 = between views
15021	Coordinates translated to view 2 (True/False)
15022	Number of steps in X
15023	Number of steps in Y
15024	Translate distance in X
15025	Translate distance in Y
15026	Point type: 1 = vector, 3 = from pt, 4 = to pt
15027	Point type: 1 = vector, 3 = from pt, 4 = to pt
15028	Point type: 1 = vector, 3 = from pt, 4 = to pt
15029	Point type: 1 = vector, 3 = from pt, 4 = to pt
15030	Point type: 1 = vector, 3 = from pt, 4 = to pt
15031	Translate direction: 1 = vector, 3 = from pt, 4 = to pt
15032	Polar distance (if polar method used)
15033	Polar angle in degrees (if polar method used)
15274	Zigzag toolpath array (True/False)

15390	Use source view (True/False)
PRM_XFORM_VIEW	Source view data
PRM_XFORM_VIEW02	Destination view data
15034	Method generated: endpoint, midpoint, etc.
15035	Method generated: endpoint, midpoint, etc.
15036	T values
15037	T values
15038	T values
15039	T values
15040	Selected entities ID number
15041	Selected entities ID number
<i>15067</i>	<i>Selected entities database pointers (removed for X3)</i>
<i>15068</i>	<i>Selected entities database pointers (removed for X3)</i>

**PRM_XFORM_VIEW**

15007	View matrix
15008	View matrix
15009	View matrix
15010	View matrix
15011	View matrix
15012	View matrix
15013	View matrix
15014	View matrix
15015	View matrix
15016	View origin
15017	View origin
15018	View origin
15019	View number at time of creation

PRM_XFORM_VIEW002

15391	View matrix
15392	View matrix
15393	View matrix
15394	View matrix
15395	View matrix
15396	View matrix
15397	View matrix
15398	View matrix
15399	View matrix
15400	View origin
15401	View origin
15402	View origin
15403	View number at time of creation



Trimmed toolpaths

PRM_TRIMMED

12288	X - which side to keep
12289	Y - which side to keep
12290	Z - which side to keep
12291	Tool up/down: 0 = keep tool up, 1 = keep tool down
PRM_CHAIN_SORT	(X)

Nesting

PRM_NESTING

15404	Version
15405	Resolution
15406	ResCBox
15407	ResUser
15408	SheetToSheetDist
15409	SheetToPartDist
15410	PartToPartDist
15411	IfFitPartInPart
15412	<i>IfFillAllSheets (removed for X3)</i>
15413	<i>IfAutoPairs (removed for X3)</i>
15414	IfNestFillersToNestHeight
15415	IfPreferHoleFilling
15416	IfDeleteChains
15417	IfCreateGroups
15418	IfUseMainColor
15419	IfUseMainLevel
15420	IfCycleColors
15421	IfCycleLevels
15422	ResultColor
15423	ResultLevel
15424	IfRestoreLast
15425	IfSaveScrap
15426	IfAddPartsAsGroup
15427	IfIgnoreHoles
15428	IfInnerHoles
15429	StartingCorner
15430	IfAddLabels

15431	ScanForNotes
15432	DrawUsingColors
15433	LabelHeight
15434	IfAutoOrigins
15435	ScrapName
15436	xfmMethod: 0 = Toolplane, 1 = Coordinate
15437	xfmGroupOutputBy: 0 = operation order, 1 = operation type
15438	xfmWoff: 0 = off, 1 = maintain source operation's #'s, 2 = assign new
15439	XfmWoffStart
15440	XfmWoffInc
15441	xfmWoffMatchExisting (True/False)
15442	xfmWoffCreateNewOps (True/False)
15443	xfmWoffKeepExistingOp (True/False)
15444	xfmCopySourceOps (True/False)
15445	xfmDisablePosting (True/False)
15446	xfmSubPgmOn (True/False)
15447	xfmSubPgmAbs (True/False)
15448	xfmSubPgmUnique (True/False)
15453	ParentOpId
15454	SeparateOpPerSheet (True/False)
15455	WorkOffsetPerSheet (True/False)
15456	WoffStart
15457	WoffInc
15458	sortMode: 0=none, 1=next closest, 2=max vacuum, 3=manual
15459	sortGroupByTool (True/False)
15460	sortGroupByRegion (True/False)
15461	SortRegionOrder
15462	SortRegionX
15463	SortRegionY
15464	SortRegionOverlap
15465	sortStartPt – X
15466	sortStartPt – Y
15467	sortStartPt – X
15468	sortZigZag (True/False)
15469	sortMinToolChg (True/False)
15470	sortGroupBySheet (True/False)
15501	force_re-nest (True/False)
15512	Stop between sheets: 0=no, 1=stop (M00), 2=optional stop (M01)
15547	Sheet fill direction
15548	Attach auto chains
15549	Display group page



15550	Load default sheet
15551	Guillotine cut
15572	Exact nesting mode (0,1,2) (new for X3)
15573	<i>(Reserved for future use)</i> (new for X3)
15574	Each part stored on a different “unused” level (new for X3)
15575	Sort order of chains in source operations for max vac within clusters (new for X3)
15576	Sort order of source operations for max vac within clusters (new for X3)
15578	True if Automatically attach geometry option is selected.
15579	Skip Results dialog after nesting complete.
15592	Onion skin active (y/n) (new for X3)
15593	For Skin all parts less than... option, dimension 1 (new for X3)
15594	For Skin all parts less than... option, dimension 2 (new for X3)
15595	Ignore tabbed parts? (y/n) (new for X3)
15596	Onion skin method: 0=All parts, 1=minimum size (new for X3)
15597	Sort chains—cut smallest parts first (new for X3)
15598	Amount of stock to leave on Z axis (new for X3)
15599	Tool diameter used during skinning (new for X3)
15600	Determine minimum part size by this width along X or Y axis (new for X3)
15605	Corner of sheet to use as the tool origin (new for X3)
15606	Common edge (new for X3)
15607	Create separate block drill operations (new for X3)
15695	Shape is locked (new for X4)
15696	Minimum width for trimming (new for X4)
15697	Trim option is turned on (new for X4)
15698	Combine cuts option is turned on (new for X4)
15699	Trim mode (new for X4)
15700	Group sorting is turned on (new for X4)
15701	Use Name as Label option is turned on (new for X4)



Surface rough toolpaths

PRM_SRF_RGH_PARALLEL

```

    PRM_SRF_COMMON
    PRM_SRF_DIRECTION
  PRM_SRF_GAP_SETTINGS
    PRM_SRF_DIRECTION
  
```

PRM_SRF_DEPTHS		
PRM_SRF_ROUGH_SETTINGS		
10205	Maximum stepover	
10200	Machining angle	
10208	Cut method: 0 = zigzag, 1 = one way	
10223	Prompt for relative start point (True/False)	
12104	Plunge distance	
12105	Retract distance	
12428	Tangent line length (gap setting)	
PRM_SRF_RGH_RADIAL		
PRM_SRF_COMMON		
PRM_SRF_DIRECTION		
PRM_SRF_GAP_SETTINGS		
PRM_SRF_DIRECTION		
PRM_SRF_DEPTHS		
PRM_SRF_ROUGH_SETTINGS		
12103	Maximum angle increment	
10208	Cutting method: 0 = zigzag, 1 = one way	
12106	Start inside (True/False)	
12107	Start angle	
12108	Sweep angle	
12109	Offset distance	
12104	Plunge distance	
12105	Retract distance	
12428	Tangent line length (gap setting)	
PRM_SRF_RGH_PROJECT		
PRM_SRF_COMMON		
PRM_SRF_DIRECTION		
PRM_SRF_GAP_SETTINGS		
PRM_SRF_DIRECTION		
PRM_SRF_DEPTHS		
PRM_SRF_ROUGH_SETTINGS		
12110	Projection type: 0 = NCI, 1 = curves, 2 = points, 3 = blend	
12111	NCI filename	
12112	Add depths (True/False)	
12104	Plunge distance	
12105	Retract distance	
12113	Oper ID # of NCI to project	
12302	Blend stepover	
10208	Cutting method: 0 = zigzag, 1 = one way	
12573	Cutting method: 0 = across, 1 = along (was 12310) (X)	
12428	Tangent line length (gap setting)	



15510 | Force a retract move between cuts (**new for X3**)



PRM_SRF_RGH_FLOWLINE

PRM_SRF_COMMON

PRM_SRF_DIRECTION

PRM_SRF_GAP_SETTINGS

PRM_SRF_DIRECTION

PRM_SRF_DEPTHES

PRM_SRF_ROUGH_SETTINGS

10208

12115

12116

12117

12118

12119

12120

12104

12105

12121

12122

12264

12421

12428

12682

12683

12684

Cut method: 0 = zigzag, 1 = one-way, 2 = spiral

Use along distance (True/False)

Along cut: distance

Use across distance (True/False)

Across cut: distance

Across cut: scallop height

Check flowline motion for gouge (True/False)

Plunge distance

Retract distance

Start point (which corner)

Cut direction (U or V)

Shared edge tolerance: 0.0 = off

True = row only (v8 code), false = grid (v9)

Tangent line length (gap setting)

Number of flow blend passes (**X2**)

Flow blend enabled (True/False) (**X2**)

Percent of tool diameter for rib resolution (**X2**)

PRM_SRF_RGH_CONTOUR

PRM_SRF_COMMON

PRM_SRF_DIRECTION

PRM_SRF_GAP_SETTINGS

PRM_SRF_DIRECTION

PRM_SRF_DEPTHES

10223

10208

10415

12554

12124

12125

12126

12104

12105

12127

Prompt for relative start point (True/False)

Direction of open boundaries: 0 = zigzag, 1 = one way

Direction of closed boundaries: True = climb

Use rest mill (True/False) (was 10123) (**X**)

Rest stepover

Rest overlap

Order cuts bottom to top (True/False)

Plunge distance

Retract distance

Sharp corner smoothing length

12128	How shallow is to be used in contour: 0 = shallow is off, remove cuts, allow partial 1 = shallow is off, remove cuts, disallow partial 2 = shallow is off, add cuts, allow partial 3 = shallow is off, add cuts, disallow partial 10 = shallow is on, remove cuts, allow partial 11 = shallow is on, remove cuts, disallow partial 12 = shallow is on, add cuts, allow partial 13 = shallow is on, add cuts, disallow partial
12129	Minimum stepdown to add cuts to shallow area
12130	Angle to determine shallow area
12131	Smooth stepover length
12132	Rampdown length
12133	Use tangent z arc (True/False)
12134	Restmill cut Z extension length
12135	Offset consecutive closed contours by this
12114	Previous operation ID
12283	Bit 0: 0 = use prev op's recut file, 1 = use prev op's NCI file
12300	Adjust absolute cut depths for drive stock
12301	Allow tangent entry/exit arc outside tool center boundary
12310	Helix: true = use helix, false = straight
12311	Helix radius
12312	Helix Z clearance
12313	Helix Z angle
12314	Output arc moves: true = output arcs, false = lines
12315	Helix tolerance
12316	Helix direction: true = CCW, false = CW
12317	Helix feed: true = feed rate, false = plunge rate
12318	Top of stock is on (True/False)
12428	Tangent line length (gap setting)
15471	Allow burial: true = allow in cut order, false = minimize it
15505	Flat use: 0-flat_use is off (2d), 1-flat_use is off (3d), 2-flat_use is on (2d), 3-flat_use is on (3d)
15506	Stepover for flat step
12431	True=use tool percentage
12432	Percentage of tool used in stepover
12433	True=automatically detect flats
12434	Do spiral
12435	Max XY deviation

**PRM_SRF_RGH_POCKET****PRM_SRF_COMMON****PRM_SRF_DIRECTION**



PRM_SRF_GAP_SETTINGS	
PRM_SRF_DIRECTION	
PRM_SRF_DEPTHs	
PRM_SRF_HSOPTS	
10223	Prompt for relative start point (True/False)
10442	Plunge tool outside tool center boundary (True/False)
12126	Order cuts bottom to top (True/False)
12104	Plunge distance
12105	Retract distance
12136	use quick zigzag (in place of toolpath/zigzag) (True/False)
12131	Smooth stepover length
12133	Use tangent Z arc (True/False)
12257	Top of stock is on (True/False)
12300	Adjust absolute cut depths for drive stock (True/False)
12308	Channel everywhere (for deep Z cuts) (True/False)
12418	Pre-drill and enter at deepest point(s) (True/False)
12428	Tangent line length (gap setting)
12436	Keep full increment
12433	Automatically detect flats (True/False)
PRM_POCKET	(new for X3)

PRM_SRF_RGH_PLUNGE

PRM_SRF_COMMON	
PRM_SRF_DIRECTION	
PRM_SRF_GAP_SETTINGS	
PRM_SRF_EDGE_SETTINGS	
PRM_SRF_DEPTHs	
10205	Maximum stepover
12104	Plunge distance
12105	Retract distance
12113	Operation ID # of NCI to project
12310	Helix: true = use helix, 1 = straight
12311	Helix radius
12312	Helix Z clearance
12313	Helix Z angle
12314	Output arc moves: true = output arcs, false = lines
12315	Helix tolerance
12316	Helix direction: true = CCW, false = CW
12317	Helix feed: true = feed rate, false = plunge rate
12319	Path type: 0 = 2 point grid, 1 = NCI

12318	Top of stock is on (True/False)
12428	Tangent line length (gap seting)
12685	True = use V8-style stepping; False = use V9 and later style (X2)

**PRM_SRF_RGH_RESTMILL****PRM_SRF_COMMON****PRM_SRF_DIRECTION****PRM_SRF_GAP_SETTINGS****PRM_SRF_EDGE_SETTINGS****PRM_SRF_DEPTHES**

10223	Prompt for operation's start point (True/False)
10208	Direction of open boundaries (0 = zigzag, 1 = one-way)
10415	Direction of closed boudaries (True = climb)
12123	Use rest mill (True/False)
12124	Stepover
12125	Overlap
12126	Order cuts bottom to top: true = bottom to top, false = top to bottom
12104	Plunge distance
12105	Retract distance
12127	Sharp corner smoothing length
12128	How shallow is to be used: 0 = shallow is off, remove cuts, allow partial 1 = shallow is off, remove cuts, disallow partial 2 = shallow is off, add cuts, allow partial 3 = shallow is off, add cuts, disallow partial 10 = shallow is on, remove cuts, allow partial 11 = shallow is on, remove cuts, disallow partial 12 = shallow is on, add cuts, allow partial 13 = shallow is on, add cuts, disallow partial
12129	Minimum stepdown to add cuts to shallow area
12130	Angle to determine shallow
12131	Smooth stepover length
12132	Rampdown length
12133	Use tangent z arc (True/False)
12134	Restmill cut extension length
12135	Offset consecutive closed contours by this
12114	Previous operation ID #
12283	Rest code: bit 0: 0 = use previous operation's recut file, 1 = use previous operation's NCI file bit 1: 0 = use ONE prev operation, 1 = use ALL prev operations bit 2: 0 = use previous operation, 1 = use rough tool

12300	Adjust absolute cut depths for drive stock (True/False)
12301	Allow tangent entry/exit arc outside the tool containment boundary (True/False)
12415	<i>Rough diameter (removed for X3)</i>
12565	<i>Rough corner radius (was 10302) (X) (removed for X3)</i>
12310	Helix: true = helix, false = straight
12311	Helix radius
12312	Helix Z clearance
12313	Helix Z angle
12314	Output arc moves: true = output arc, false = lines
12315	Helix tolerance
12316	Direction: true = CCW, false = CW
12317	Entry feed rate: true = feed rate, false = Plunge rate
12318	Top of stock is on (True/False)
12425	Use rest overlap, (True/False)
12426	Remaining stock resolution
12428	Tangent line length (gap setting)
15471	Gouge check: true = allow burial in cut order, false = minimize it
12431	Use tool percentage (True/False)
12432	Percentage of tool diameter for stepover
12433	Automatically detect flat (True/False)



Surface finish toolpaths

PRM_SRF_FIN_PARALLEL

PRM_SRF_COMMON	
PRM_SRF_DIRECTION	
PRM_SRF_GAP_SETTINGS	
PRM_SRF_EDGE_SETTINGS	
PRM_SRF_LIMITS	
10205	Maximum stepover
10200	Machining angle
10208	Cut method: 0 = zigzag, 1 = one way
10223	Prompt for relative start point (True/False)
12104	Plunge distance
12105	Retract distance
12428	Tangent line length (gap setting)

PRM_SRF_FIN_RADIAL

PRM_SRF_COMMON
PRM_SRF_DIRECTION



PRM_SRF_GAP_SETTINGS	
PRM_SRF_EDGE_SETTINGS	
PRM_SRF_LIMITS	
12103	Maximum angle increment
10208	Cut method: 0 = zigzag, 1 = one way
12106	Start inside (True/False)
12107	Start angle
12108	Sweep angle
12109	Offset distance
12104	Plunge distance
12105	Retract distance
12428	Tangent line length (gap setting)

PRM_SRF_FIN_PROJECT

PRM_SRF_COMMON	
PRM_SRF_DIRECTION	
PRM_SRF_GAP_SETTINGS	
PRM_SRF_EDGE_SETTINGS	
PRM_SRF_LIMITS	
12110	Projection type: 0 = NCI, 1 = curves, 2 = points, 3 = two curve blend
12111	NCI filename
12112	Add depths (True/False)
12104	Plunge distance
12105	Retract distance
12113	NCI to project
12428	Tangent line length (gap setting)
15510	Force retract (True/False) (X)

PRM_SRF_FIN_FLOWLINE

PRM_SRF_COMMON	
PRM_SRF_DIRECTION	
PRM_SRF_GAP_SETTINGS	
PRM_SRF_EDGE_SETTINGS	
PRM_SRF_LIMITS	
10208	Cut_method: 0 = zigzag, 1 = one way, 2 = spiral
12115	Use along distance (True/False)
12116	Along cut: distance
12117	Use across distance (True/False)
12118	Across cut: distance
12119	Across cut: scallop height
12120	Check flowline motion for gouge (True/False)
12104	Plunge distance



12105	Retract distance
12121	Start point (which corner)
12122	Cut direction (U or V)
12264	Shared edge tolerance: 0.0 = off
12421	True = row only (v8 code), false = grid (v9)
12428	Tangent line length (gap setting)
12686	Number of flow blend passes (X2)
12687	Flow blend enabled (True/False) (X2)
12688	Percent of tool diameter for rib resolution (X2)

PRM_SRF_FIN_CONTOUR

PRM_SRF_COMMON	
PRM_SRF_DIRECTION	
PRM_SRF_GAP_SETTINGS	
PRM_SRF_EDGE_SETTINGS	
PRM_SRF_DEPTHES	
10223	Prompt for relative start point (True/False)
10208	Direction of open boundaries: 0 = zigzag, 1 = one way
10415	Direction of closed boundaries: True = climb
12123	Use rest mill (True/False)
12124	Rest stepover
12125	Rest overlap
12126	Order cuts bottom to top (True/False)
12104	Plunge distance
12105	Retract distance
12127	Sharp corner smoothing length
12128	How shallow is to be used in contour: 0 = shallow is off, remove cuts, allow partial 1 = shallow is off, remove cuts, disallow partial 2 = shallow is off, add cuts, allow partial 3 = shallow is off, add cuts, disallow partial 10 = shallow is on, remove cuts, allow partial 11 = shallow is on, remove cuts, disallow partial 12 = shallow is on, add cuts, allow partial 13 = shallow is on, add cuts, disallow partial
12129	Minimum stepdown to add cuts to shallow area:
12130	Angle to determine shallow area
12131	Smooth stepover length
12132	Rampdown length
12133	Use tangent Z arc (True/False)
12134	Restmill cut extension length
12135	Offset consecutive closed contours by this value
12114	Previous operation ID #
12283	Bit 0: 0 = use prev op's recut file, 1 = use prev op's NCI file

12300	Adjust absolute cut depths for drive stock (True/False)
12301	Allow tangent entry/exit arc outside tool containment boundary (True/False)
12310	Helix: true = use helix, false = straight
12311	Helix radius
12312	Helix Z clearance
12313	Helix Z angle
12314	Output arc moves: true = output arcs, false = lines
12315	Helix tolerance
12316	Helix direction: true = CCW, false = CW
12317	Helix feed: true = feed rate, false = plunge rate
12318	Top of stock is on (True/False)
12428	Tangent line length (gap setting)
15471	Allow burial: true = allow burial in opt cut order, false = minimize it
15505	Flat use: 0-flat_use is off (2d), 1-flat_use is off (3d), 2-flat_use is on (2d), 3-flat_use is on (3d)
15506	Stepover for flat step
12431	True=use tool percentage
12432	Percentage of tool used in stepover
12433	True=automatically detect flats
12434	Do spiral
12435	Max XY deviation

**PRM_SRF_FIN_PENCIL**

PRM_SRF_COMMON
PRM_SRF_DIRECTION
PRM_SRF_GAP_SETTINGS
PRM_SRF_EDGE_SETTINGS
PRM_SRF_LIMITS

10415	Machining direction: true = climb, false = conventional cut
10223	Prompt for relative start point (True/False)
12104	Plunge distance
12105	Retract distance
10200	Machining angle (bias angle)
12263	Ignore climb(/conventional) flag (True/False)
12424	Number of total passes
12449	Multipass (True/False)
10208	Cutting method: 0=zigzag, 1=oneway
12054	Stepover for offset passes
12428	Tangent line length (gap setting)
12438	Pencil angle

12574 | Overthickness (**new for X3**)**PRM_SRF_FIN_LEFTOVER****PRM_SRF_COMMON****PRM_SRF_DIRECTION****PRM_SRF_GAP_SETTINGS****PRM_SRF_EDGE_SETTINGS****PRM_SRF_LIMITS**

10205

10200

10208

10223

12564

12565

12566

10415

10325

10324

10326

12104

12105

12292

12298

12299

12303

12304

12320

12321

12322

12323

12422

12423

12428

12430

Maximum stepover

Machining angle

Cut method: 0 = zigzag, 1 = one way, 2 = 3D collapse

Prompt for relative start point (True/False)

Roughing tool diameter (was 10301) **(X)**Roughing tool corner radius (was 10302) **(X)**Cut extension (was 10303) **(X)**

Machining direction: true = climb, false = conventional cut

Expand cuts from the inside to the outside (True/False)

Create outermost 3D collapse pass (True/False)

Resolution: percentage of stepover

Plunge distance

Retract distance

Hybrid: true = perpendicular to pencil, false = at machining angle

From slope angle

To slope angle

Collapse resolution: true = automatically calculate resolution percentage, false = use resolution percentage

Skip smoothing of outer boundary (True/False)

Blend Cuts: true = blend Z cuts with XY, false = XY only

Blend extension

Blend angle

Rough tool cut tolerance

Tolerance: true = use rough tolerance, false = set rough tolerance equal to cut tolerance

Rough pencil map: true = skip, false = use it

Tangent line length (gap setting)

Skip internal lines in 3D collapse: (True/False)

PRM_SRF_FIN_STEEP**PRM_SRF_COMMON****PRM_SRF_DIRECTION****PRM_SRF_GAP_SETTINGS**

PRM_SRF_EDGE_SETTINGS	
PRM_SRF_LIMITS	
10205	Maximum stepover
10200	Machining angle
10208	Cut method: 0 = zigzag, 1 = one way
10223	Prompt for relative start point (True/False)
10310	Angle of surface normal (start of range)
10311	Angle of surface normal (end of range)
10312	Cut extension
12104	Plunge distance
12105	Retract distance
12307	Include cuts outside from/to range (True/False)
12428	Tangent line length (gap setting)
PRM_SRF_FIN_SHALLOW	
PRM_SRF_COMMON	
PRM_SRF_DIRECTION	
PRM_SRF_GAP_SETTINGS	
PRM_SRF_EDGE_SETTINGS	
PRM_SRF_LIMITS	
10205	Maximum stepover
10200	Machining angle
10208	Cut method: 0 = zigzag, 1 = one way, 2 = 3D collapse
10223	Prompt for relative start point (True/False)
10320	Angle of surface normal (start of range)
10321	Angle of surface normal (end of range)
10322	Cut extension
10415	Machining direction: true = climb, false = conventional cut
10325	Expand cuts from the inside to the outside (True/False)
10324	Create outermost 3D collapse pass (True/False)
10326	Resolution: percentage of stepover
12104	Plunge distance
12105	Retract distance
12923	Output: true = 5-axis, false = 3-axis
12924	5-axis output: lead/lag angle
12925	5-axis output: lead/lag angle limit
12926	5-axis output: side angle
12927	5-axis output: side angle limit
12303	Collapse resolution: true = automatically calculate resolution percentage, false = use resolution percentage
12428	Tangent line length (gap setting)
12430	Skip internal lines in 3D collapse (True/False)



12137	Optimization type: 0 = extrema, 1 = closest
-------	---

PRM_SRF_FIN_CONSCALOP**PRM_SRF_COMMON****PRM_SRF_DIRECTION****PRM_SRF_GAP_SETTINGS****PRM_SRF_EDGE_SETTINGS****PRM_SRF_LIMITS**

10205

Maximum stepover

10223

Prompt for relative start point (True/False)

10415

Machining direction: true = climb, false = conventional cut

10325

Expand cuts from the inside to the outside (True/False)

10324

Create outermost 3D collapse pass (True/False)

10326

Resolution: percentage of stepover

12104

Plunge distance

12105

Retract distance

12137

Optimization type: 0 = extrema, 1 = closest

10200

Machining angle

12303

Collapse resolution: true = automatically calculate resolution percentage, false = use resolution percentage

12306

Collapse settings: true = hold outermost zone static, false = collapse it

12428

Tangent line length (gap setting)

12430

Skip internal lines in 3D collapse (True/False)

12575

Enable sharp-corner smoothing? (Y/N) (**new for X3**)

12576

Angle tolerance to define which corners are considered sharp. (**new for X3**)

12577

Maximum rounding distance. (**new for X3**)**PRM_SRF_FIN_BLEND (X)****PRM_SRF_COMMON****PRM_SRF_DIRECTION****PRM_SRF_GAP_SETTINGS****PRM_SRF_EDGE_SETTINGS****PRM_SRF_LIMITS**

12110

Projection type: set to 3 (two curve blend)

12104

Plunge distance

12105

Retract distance

12302

Blend stepover

10208	Cutting method: 0 = zigzag, 1 = one way, 2 = spiral
12238	Cutting Method: true = along, false = across
12417	If along, true = do 2D projection, false = do 3D
12428	Tangent line length (gap setting)
15472	Percentage of stepover to use for temporary 'across' cut used to build final along 3D cut
15473	Skip vertical walls (True/False)



Surface common settings

PRM_SRF_COMMON

10226	Respond to check bit on surfaces (True/False)
10227	Stock to leave on check surfaces
10228	Prompt for tool center boundary (True/False)
12410	Comp to tip (True/False)
10204	Cut tolerance
12411	Maximum stepdown

PRM_SRF_DIRECTION

10915	Direction vectors are to be used (True/False) (was 10715) (X)
10909	Plunge angle in XY (was 10709) (X)
10910	Plunge angle in Z (was 10710) (X)
10911	Plunge relative: 0 = to Cplane X-axis, 1 = to cut (was 10711) (X)
10912	Retract angle in XY (was 10712) (X)
10913	Retract angle in Z (was 10713) (X)
10914	Retract relative: 0 = to Cplane X-axis, 1 = to cut (was 10714) (X)

PRM_SRF_GAP_SETTINGS

10255	Retract: true = use gap percentage, false = use gap distance
10259	Maximum short gap (as a distance)
10258	Maximum short gap (as percentage of stepover (or tool diameter))
10260	Gap motion: 0 = direct, 1 = broken, 2 = smooth, 3 = follow surface fixed feed rate, 10 = direct, 11 = broken, 12 = smooth, 13 = follow surface (was 10221) (X)
10256	Check short gap motion for gouge (True/False)
10257	Check long gap motion for gouge (True/False)
10246	Optimize cut order (True/False)



10247	Plunge into previously cut area (True/False)
10248	Follow tool center boundary in gap (True/False)
12414	Tangential arc radius
12556	Tangential arc sweep angle (was 10402) (X)

PRM_SRF_EDGE_SETTINGS

10252	Search for shared edges (obsolete - defaults to False)
10251	Use "solid hidden face" (True/False)
10249	Containment boundary offset distance (set to 0 in v8 operations)
10250	Containment boundary offset option 0 = offset inside 1 = no offset (center) (this is default) 2 = offset outside
10242	Roll tool at edges: 1 = only between surfaces, 2 = over all surfaces, 3 = auto
10254	Sharp corner tolerance: true = use corner percentage, false = use corner distance
10253	Sharp corner tolerance (as distance)
10240	Sharp corner tolerance (as percentage of cut tolerance)

PRM_SRF_DEPTHES

12557	Cut depths: true = incremental, false = absolute (was 10403) (X)
12070	Tip comp: true = tip depths, false = center depths
12444	Maximum storage currently allocated for critical depths (X)
12445	Current count of number of critical depths (X)
12446	Counter to indicate that variable critical depths were changed (dirty flag) (X)
12447	<i>Database list entity pointer</i> (X) (removed in X3)
12448	<i>Pointer to critical depths</i> (X) (removed in X3)
12558	Incremental: adjustment to top cut (was 10404) (X)
12559	Incremental: adjustment to bottom and other cuts (was 10405) (X)
12412	## Absolute: highest cut
14071	Absolute: lowest cut
12072–12101	Critical depths selected by user (Pre-X)

PRM_SRF_ROUGH_SETTINGS

10233	Allow motion in -Z along surface (True/False)
10224	Allow motion in +Z along surface (True/False)
10235	Plunge control: 1 = cut from one side, 2 = cut from both, 0 = allow multiple plunges

PRM_SRF_HSOPTS

12439	Use variable step: True=variable, False=Fixed distance between offset passes
12440	Use tangent ramp: True=tangent ramp, False=loop transition between offset passes
12441	Use tangent ramp angle: True=angle, False=length specification of tangent ramp
12442	Tangent ramp length
12443	Tangent ramp angle

**PRM_SRF_LIMITS**

10243	Use cut depth limits (True/False)
12102	Tip comp: true = tip depths, false = center depths
10244	Depth limit 1
10245	Depth limit 2

High-speed 2D toolpaths

PRM_2D_HMM

12713	2D toolpath style: core mill, peel mill, blend mill, area mill, rest mill (new for X3)
12714	Rounding radius (new for X3)
12715	Rough offset (new for X3)
12716	Extend entry? (new for X3)
12717	Create finish pass (new for X3)
12718	Back feedrate (new for X3)
12719	Stepover (new for X3)
12720	Width of slot (new for X3)

PRM_CONTOUR

12952	Feedrate override (new for X4)
12953	Spindle speed override (new for X4)
12954	1 = Feedrate override on (new for X4)
12955	1 = Spindle speed override on (new for X4)
12956	1 = conventional milling (0 = climb) (new for X4)
12957	Single chain slot for peel mill : 0 = chain is center of slot, 1 = left, 2 = right (new for X4)
12958	1 = Extend exit (new for X4)
12959	Entry extension distance (new for X4)
12960	Exit extension distance (new for X4)
12961	Percentage of stepover to use for a temporary “across” cut. This is used to build the final Along 3D cut. (new for X4)

12962	Cut method: 0 = Zigzag, 1 = One way, 2 = Spiral (new for X4)
12963	Across/along selection: 0 = Across, 1 = Along (new for X4)
12964	If 12963 = Along, 1= Do 2D projection, 0 = Do 3D core mill parameters (new for X4)
12965	1 = use conventional rough cut, 0 = use climb rough cut (new for X4)
12966	1 = Enable adaptive stepdown (new for X4)
12967	1 = Enable profile smoothing (Z constant smooth op) (new for X4)
12968	Maximum Z stepdown distance for core mill (new for X4)
12969	Minimum Z stepdown for use with adaptive step (new for X4)
12970	Maximum step difference between 2 points in adaptive step (new for X4)
12971	Stepover as a % of tool diameter in core mill (new for X4)
12972	Minimum stepover as % of maximum stepover (new for X4)
12973	Maximum stepover for core mill (new for X4)
12974	Minimum stepover for core mill (new for X4)
12975	Maximum radius for smoothing operation (new for X4)
12976	Smoothing tolerance (new for X4)
12977	Tolerance for smoothing op cornering (new for X4)
12978	Length of peel mill microlift (new for X4)
12979	Height of peel mill microlift (new for X4)
12980	1 = Peel mill microlift is enabled (new for X4)
12981	1 = Use feed rate at entry, 0 = Use plunge rate (new for X4)
12982	Entry style: 0 = profile ramp, 1 = helix (new for X4)
12983	Entry motion: 1 = Use 3D arcs (helices), 0 = Linearize them (new for X4)
12984	1 = Use core mill as raw passes, 0 = Use area mill as raw passes (new for X4)
12985	gap size defined by: 0 = distance, 1 = percent of tool diameter (new for X4)
12986	1 = minimize burial (use trochoidal loop), 0 = Don't (new for X4)
12987	1 = Keep trochoidal loop inside machining region, 0 = Let it move in air outside machining region (new for X4)
12988	Radius of helix (for core/area mill) (new for X4)
12989	Z clearance of helix/profile ramp (core/area mill) (new for X4)



12990	Maximum angle of helix/profile ramp (core/area mill) (new for X4)
12991	Radius of S-shaped stepover (new for X4)
12992	Preferred profile span (new for X4)
12993	Skip pockets with span less than this value (new for X4)
12994	Keep tool down within this gap size (actual distance) (new for X4)
12995	Keep tool down within this gap size (percentage of tool diameter) (new for X4)
12996	2D-blend stepover amount (new for X4)
12997	Initial loop size: % of tool diameter (5–100), 0 = not set (new for X4)
12998	Minimum loop size, % of tool diameter (1–100), 0 = not set (new for X4)
12999	Retry loop size: % of previous loop size (5–95), 0 = not set (new for X4)
40001	Expected material engagement adjustment: % of stepover, (1–100), 0 = not set (new for X4)
40002	Adjust feedrate by this % if trochoidal loop doesn't fit, (5–95), 0 = not set (new for X4)
40003	Maximum cutting distance (retract and load a same shape tool) (new for X4)
40004	Maximum cutting time (retract and load a same shape tool) (new for X4)
40005	Dynamic pocket radius (new for X4)
40006	Dynamic pocket radius percentage (new for X4)
40007	Dynamic pocket approach distance (new for X4)
40008	Dynamic pocket open: 1 = open pocketing, 0 = closed pocketing (new for X4)
40009	Dynamic pocket retract style (new for X4)
40010	Sister tool type: 0 = none, 1 = distance, 2 = time (new for X4)



High-speed surface toolpaths

PRM_SRF_HMM **(X)**

12578	Z step size (maximum)
12579	XY or XYZ step size (maximum)
12580	Z depth limit 1
12581	Z depth limit 2
12582	Angle limit 1
12583	Angle limit 2
12584	Minimum stepdown (for adaptive or other non-constant Z step)

12585	Stepdown precision
12586	Minimum difference between Z steps (for adaptive or contour flats type processing)
12587	Tolerance for smoothing operation
12588	Maximum radius in smoothing operation
12589	Curl over radius...for shortest retract route
12590	Curl down radius...for shortest retract route
12591	Reference cutter diameter
12592	Reference cutter corner radius
12593	Cut tolerance (add filter tolerance to get total tolerance)
12594	Stock remaining on check geometry
12595	Tool containment boundary offset amount (for offset inside or outside [not for center])
12596	Minimum stepover
12597	Maximum stepover
12598	Offset tolerance (for smoothing)
12599	Overthickness - increase reference tool by this amount (pencil, usually)
12600	Bitangency angle - definition of a crease
12601	Vertical stepover distance
12602	Horizontal stepover distance
12603	Machining cut angle
12604	Pass extension - extend cut by this amount
12605	Limit raster stepover by this amount (see raster limit style)
12606	Gap size - keep tool down within this gap size (actual distance)
12607	Gap size - keep tool down within this gap size (percentage of tool diameter)
12608	Maximum cutting distance (retract and load a same shape tool)
12609	Maximum cutting time (retract and load a same shape tool)
12610	Helix radius
12611	Helix additional z clearance
12612	Helix max angle
12613	Minimum profile ramp diameter
12614	Entry radius in (vertical)
12615	Entry radius out (vertical)
12616	Transition ramp angle
12617	Stepover expressed as a percentage of tool diameter
12618	Entry radius in (horizontal)
12619	Entry radius out (horizontal)
12620	Maximum entry ramp angle (horizontal)
12621	Link extension (start)
12622	Link shallow angle
12623	Prefillet corner radius



12624	Second tool containment boundary offset amount
12625	Maximum trimming distance
12626	Limiting number of offsets (scallop)
12627	Limiting number of offset (pencil)
12628	Style: 0-Core roughing (pocket, out to in) 1-Area clearance (pocket, in to out) 2-Waterline (Z contour) 3-Constant stepover (scallop) 4-Horizontal (facing) 5-Raster (parallel) 6-Pencil (single and multipass) 7-Flowline 8-Blend 9-Spiral 10-Project 11-Rough rest passes
12629	Zigzag (True/False)
12630	Climb (True/False)
12631	Use approximate start point (True/False)
12632	Optimize cut order (True/False)
12633	Reverse order (bottom up for example) (True/False)
12634	Adaptive stepdown (True/False)
12635	Profile (constant z) smoothing (True/False)
12636	Retract style - 0=Shortest, 1=minimal, 2=full retract
12637	Rest area calculation (True/False)
12638	Top of stock is to be used (True/False)
12639	Tool containment boundary offset direction - 0=inside, 1=center (no offset), 2=outside
12640	Add offset distance to tool radius (True/False)
12641	Use depths (True/False) - True = use z depth limit 1 and 2
12642	Stepover style - 0=3d, 1=2d, (2=future)
12643	Offset limit style - 0-no offsets, 1-limited offsets, 2-unlimited offsets
12644	Raster limit style - 0-disabled, 1-limited, 2-fill in stepover
12645	Gap size type - 0=gap size dist, 1=gap size pct of tool diameter, (2=future)
12646	Sister tool type - 0=none, 1=distance, 2=time
12647	Contact area only (True/False) - False=contact and outermost, True=contact area only
12648	Helix entry style - 0=profile ramp, 1=helix, 2=future
12649	Link trimming style - 0=none, 1=minimal, 2=fully, 3=future
12650	Gap style - 0=tangential ramp, 1=ramp, 2=direct
12651	Pencil offset limit style - 0=no offsets, 1-limited offsets, 2-unlimited offsets
12652	Down up style: 0=any direction, 1=down mill only, 2=up mill only, 3=neither up nor down, 4=future
12653	Prefer reverse (True/False)



12654	Prefillet on (True/False)						
12655	Gouge check holder (True/False)						
12656	Raster gap style -0=smooth, 1=straight, 2=future						
12662	The feedrate to be used when approach/retract moves on the Linking parameters page are output as feedrate moves instead of rapid moves (see parameter 12676).						
12663	Clearance distance used for gouge checking the tool holder.						
12664	Axial offset distance						
12665	The stock to leave amount for wall surfaces.						
12666	The stock to leave amount for floor surfaces.						
12667	The rest roughing stock resolution.						
12668	The amount of Stock adjustment to be applied to the stock model.						
12669	<i>Pointer to holder (removed for X3)</i>						
12670	<i>Pointer to holder entity (removed for X3)</i>						
12671	Number of axial offsets						
12672	The ID number of the previous operation used for rest roughing.						
12673	<i>Total size of the holder (moved for X4)</i>						
12674	<i>Number of segments in the tool holder definition (moved for X4)</i>						
12675	<i>Counter to indicate changes in holder (moved for X4)</i>						
12676	When True, outputs feed rate moves instead of rapids for approach/retract moves on the Linking parameters page (parameter 12662 stores the feedrate).						
12677	When True, outputs arc moves for entry helices.						
12678	When True, use the Expand inside to out cutting method option.						
12679	Sets the stock computation method for rest roughing toolpaths: 0= All previous operations , 1= One previous operation , 2= Roughing tool , 3= CAD file .						
12680	Sets the stock adjustment method:						
	<p>Adjustments to remaining stock:</p> <table> <tr> <td>2</td> <td><input checked="" type="radio"/> Use remaining stock as computed</td> </tr> <tr> <td>1</td> <td><input type="radio"/> Adjust remaining stock to ignore small cusps</td> </tr> <tr> <td>0</td> <td><input type="radio"/> Adjust remaining stock to mill small cusps</td> </tr> </table>	2	<input checked="" type="radio"/> Use remaining stock as computed	1	<input type="radio"/> Adjust remaining stock to ignore small cusps	0	<input type="radio"/> Adjust remaining stock to mill small cusps
2	<input checked="" type="radio"/> Use remaining stock as computed						
1	<input type="radio"/> Adjust remaining stock to ignore small cusps						
0	<input type="radio"/> Adjust remaining stock to mill small cusps						
12689	Minimum stepover, expressed as a percentage of tool diameter (X2)						
12690	Minimum “span” or extent required of a pocket for it to be machined (pockets smaller than this amount are not machined) (X2)						
12691	X coordinate for the center point for radial/spiral toolpaths (X2)						
12692	Y coordinate for the center point for radial/spiral toolpaths (X2)						





	12693	Inner radius for radial/spiral toolpaths (X2)
	12694	Outer radius for radial/spiral toolpaths (X2)
	12695	Starting angle for a radial toolpath (X2)
	12696	Ending angle for a radial toolpath (X2)
	12697	Z-ramp distance for a horizontal entry arc (X2)
	12698	True = use feed rate for helix; False = use plunge rate (X2)
	12699	True = spiral clockwise; False = spiral counterclockwise (X2)
	12700	True = use trochoidal loops to minimize tool burial; False = do not use trochoidal loops (X2)
	12721	Trochoidal motion: initial loop radius (X2)
	12722	Trochoidal motion: minimum loop radius (X2)
	12723	Trochoidal motion: retry loop radius (X2)
	12724	Trochoidal motion: stepover adjustment (X2)
	12725	Trochoidal motion: feedrate adjustment (X2)
	12726	<i>Holder library (moved for X4)</i>
	12727	<i>Holder name (moved for X4)</i>
	12728	Name of default formula file (X2)
	12729	<i>Size of holder library (moved for X4)</i>
	12730	<i>Size of holder name (moved for X4)</i>
	12731	Size of default formula file (X2)
	12732	Scallop toolpaths “Steep/Shallow” option: Use boundaries as drive curves, then collapse (Y/N) (new for X3)
	12733	Keep trochoidal loops inside machining region (Y/N) (new for X3)
	12734	Ignore outer radius when calculating spiral/radial toolpaths (Y/N) (new for X3)
PRM_TP HOLDER		(new for X4)

PRM_TP HOLDER

	12673	Total size of the holder (X2—moved to this group, X4)
	12674	Number of segments in the tool holder definition (X2—moved to this group, X4)
	12675	Counter to indicate changes in holder (X2—moved to this group, X4)
	12726	Holder library (X2—moved to this group, X4)
	12727	Holder name (X2—moved to this group, X4)
	12729	Size of holder library (X2—moved to this group, X4)
	12730	Size of holder name (X2—moved to this group, X4)

Advanced multiaxis toolpaths

PRM_ADV_5AX

15583	Text to display in TP Mgr (new for X3)
15584	Name of adv multiaxis chook (new for X3)
15585	Name of parameter function (new for X3)
15586	Name of tool function (new for X3)
15587	Name of geometry function (new for X3)
15588	(not used) (new for X3)
15589	Name of regen function (new for X3)
15590	(not used) (new for X3)
15591	(not used) (new for X3)
15592	(not used) (new for X3)



Feature-based machining: drill toolpaths

FBM_DRILLPARAMETERS

12737	Solid operation ID (new for X3) (new for X3)
FBM_DRILLPARAMETERS_SETUP	
FBM_DRILLPARAMETERS_HOLEDETECTION	(new for X3)
FBM_DRILLPARAMETERS_DEEPHOLE	(new for X3)
FBM_DRILLPARAMETERS_SPOTDRILLING	(new for X3)
FBM_DRILLPARAMETERS_PREDRILLING	(new for X3)
FBM_PARAMETERS_TOOLS	(new for X3)
FBM_DRILLPARAMETERS_DEPTHS	(new for X3)

FBM_DRILLPARAMETERS_SETUP

12856	Automatic initial hole detection turned on (y/n) (new for X3)
12857	Enable Tool page? (new for X3)
12858	Enable Depths page? (new for X3)
12859	Method for grouping operations—None, Plane, or Tool. (new for X3)
12860	Method for sorting points (new for X3)
12861	Use subprograms? (y/n) (new for X3)
12862	Incremental or absolute subprograms (new for X3)

FBM_DRILLPARAMETERS_HOLEDETECTION

12863	Read hole data from solids created with the SolidWorks® Hole Wizard® (new for X3)
-------	--

SDETECT_DRILL_PARAMS

12864	Path to use with Hole Wizard (new for X3)
12865	Co-axial hole criteria. Determines whether Mastercam treats multiple holes that share a common axis as a single hole, or as multiple holes from different planes. (new for X3)

**SDETECT_DRILL_PARAMS**

15307	Minimum radius of holes to detect (note: users enter this number as a diameter value) (new for X3)
15308	Maximum radius of holes to detect (note: users enter this number as a diameter value) (new for X3)
15309	Include blind holes (y/n) (new for X3)
15310	Arc offset (new for X3)
15311	Color (new for X3)
15312	Limit search for holes to a specific plane (new for X3)
15313	Plane to limit search to (new for X3)
15314	Include split holes (new for X3)
15315	Detect holes by minimum or maximum sweep angle (new for X3)
15316	Sweep angle threshold (new for X3)
15317	Sampling increment (step) along length of hole to determine sweep angle. (new for X3)

FBM_DRILLPARAMETERS_DEEPHOLE

12866	Deep drilling option turned on (y/n) (new for X3)
12867	Deep drilling strategy: <ul style="list-style-type: none"> • Split holes between faces • Drill to maximum and finish with a long tool • Drill to maximum and warn user • Cut entire hole with a long drill. (new for X3)
12868	The maximum hole depth :: diameter ratio for normal drilling. Mastercam applies deep drilling parameters only to holes that exceed this ratio. (new for X3)
12869	Primary face depth percentage (new for X3)
12870	Canned cycle to use for deep drilling (new for X3)

FBM_DRILLPARAMETERS_SPOTDRILLING

12871	Spot drilling option turned on (y/n) (new for X3)
12872	Max percentage of finished hole (new for X3)
12873	Max depth (new for X3)
12874	Allow center drill (new for X3)

12875	Combine spot drill operations that meet or exceed maximum depth (new for X3)
12876	Use selected tool for all spot drill operations (new for X3)



FBM_DRILLPARAMETERS_PREDRILLING

12877	Pre-drilling option turned on (y/n) (new for X3)
12878	Minimum drill diameter (new for X3)
12879	Increment between drill sizes for each set of pre-drill operations (new for X3)
12880	Use Stock to leave option (y/n) (new for X3)
12881	Amount of stock to leave (new for X3)
12882	Use Tip compensation option (y/n) (new for X3)
12883	Use Additional break through option (y/n) (new for X3)
12884	Break through method: Distance , or % of tool diameter (new for X3)
12885	Break through amount (new for X3)

FBM_PARAMETERS_TOOLS

12886	Tool library path (new for X3)
12887	Diameter matching tolerance for selecting drills (new for X3)
12888	Use tools in .MCX file (y/n) (new for X3)
12889	Use tools from tool library (y/n) (new for X3)
12890	Create tools as needed (y/n) (new for X3)
12891	Create only standard sizes (y/n) (new for X3)
12892	Consider flute length when creating new tools (y/n) (new for X3)
12893	Action to take if hole exceeds flute length (new for X3)
12894	Increment to use when creating new tools of different lengths (new for X3)
12895	Tip geometry / hole bottom geometry (new for X3)
12896	Tool tip match tolerance (new for X3)
12897	Allow flat endmills? (y/n) (new for X3)

FBM_DRILLPARAMETERS_DEPTHS

12898	Method for determining clearance (new for X3)
12899	Clearance value (new for X3)
12900	Absolute or incremental clearance (new for X3)
12901	Use clearance only at the start and end of an operation (new for X3)
12902	Retract distance (new for X3)

12903	Apply tip compensation? (y/n) (new for X3)
12904	Apply additional break through amount? (y/n) (new for X3)
12905	Method for computing break through (new for X3)
12906	Amount of break through (new for X3)
12907	Tap/ream depth adjustment method (new for X3)
12908	Amount of tap/ream depth adjustment (new for X3)



Feature-based machining: pocket toolpaths

PRM_FBM_POCKET

	12737	Solid operation ID (new for X3)
		FBM_POCKETPARAMETERS_SETUP
		FBM_POCKETPARAMETERS_POCKETDETECTION
		FBM_POCKETPARAMETERS_FACETL
		FBM_POCKETPARAMETERS_ROUGHTL
		FBM_POCKETPARAMETERS_ROUGHTL
		FBM_POCKETPARAMETERS_FINISHTL
		FBM_POCKETPARAMETERS_FACE
		FBM_POCKETPARAMETERS_ROUGH
		FBM_POCKETPARAMETERS_REST
		FBM_POCKETPARAMETERS_FINISH
		FBM_POCKETPARAMETERS_DEPTHS

FBM_POCKETPARAMETERS_SETUP

12738	Automatic initial feature detection turned on (y/n) (new for X3)
12744	Method for grouping operations—1=Op type, 2=Tool, 3=Plane, or 4=Hole. (new for X3)
12746	Comment (new for X3)

FBM_POCKETPARAMETERS_POCKETDETECTION

12747	Allow through pockets (y/n) (new for X3)
12748	Method for cutting through pockets: 0=leave stock at bottom, 1=break through (new for X3)
12749	Amount of stock to leave at bottom. (new for X3)
12750	Break through distance (new for X3)
12751	Method for selecting level for edge curves (new for X3)
12752	Level on which to place edge curves (new for X3)
12753	Minimum number of unused level on which to place edge curves (new for X3)

12754	Recognize holes greater than this diameter as features (new for X3)
-------	---

**FBM_POCKETPARAMETERS_FACE**

FBM_POCKETPARAMETERS_DCUTS	(new for X3)
12823	Enable facing operations (y/n) (new for X3)
12824	Select climb or conventional (new for X3)
12825	Cutting method: Zigzag, One way, Controlled engagement (new for X3)
12826	Stock to leave in Z (new for X3)
12827	Max stepover (new for X3)
12828	Across overlap distance (new for X3)
12829	Along overlap distance (new for X3)
12830	Approach distance (new for X3)
12831	Exit distance (new for X3)

FBM_POCKETPARAMETERS_ROUGH

FBM_POCKETPARAMETERS_DCUTS001	(new for X3)
12832	Select climb or conventional (new for X3)
12833	Cut method (new for X3)
12834	Stock to leave on floors (new for X3)
12835	Stock to leave on walls (new for X3)
12836	Stepover (new for X3)
12837	Entry method: profile ramp or helix (new for X3)
12838	Profile boundary for ramp (new for X3)
12839	Face approach distance (new for X3)
12840	Face overlap distance (new for X3)
12841	Face exit diatance (new for X3)
12842	Use long tool values when length::diameter ratio is greater than this value (new for X3)
12843	Outside (new for X3)

FBM_POCKETPARAMETERS_REST

FBM_POCKETPARAMETERS_DCUTS002	(new for X3)
12844	Select climb or conventional (new for X3)
12845	Stock to leave on floors (new for X3)
12846	Stock to leave on walls (new for X3)
12847	Stepover (new for X3)
12848	Use long tool values when length::diameter ratio is greater than this value (new for X3)

**FBM_POCKETPARAMETERS_DCUTS**

12812	Depth cuts mode for facing operations (new for X3)
-------	---

FBM_POCKETPARAMETERS_DCUTS001

12813	Depth cuts mode for roughing operations (new for X3)
-------	---

FBM_POCKETPARAMETERS_DCUTS002

12814	Depth cuts mode for restmill operations (new for X3)
-------	---

FBM_POCKETPARAMETERS_FINISH

FBM_POCKETPARAMETERS_LEADIO001	(new for X3)
12850	Select climb or conventional (new for X3)
12851	Stock to leave on floors (new for X3)
12852	Stock to leave on walls (new for X3)
12853	Stepover (new for X3)
12854	Use long tool values when length::diameter ratio is greater than this value (new for X3)
12855	Cutter comp (new for X3)
12910	Outside (new for X3)

FBM_POCKETPARAMETERS_LEADIO

12815	Entry/exit mode: perpendicular or tangent (new for X3)
12816	Line length (new for X3)
12817	Arc radius (new for X3)
12818	Sweep angle (new for X3)

FBM_POCKETPARAMETERS_LEADIO001

12819	Entry/exit mode: perpendicular or tangent (new for X3)
12820	Line length (new for X3)
12821	Arc radius (new for X3)
12822	Sweep angle (new for X3)

FBM_POCKETPARAMETERS_DEPTHS

12807	Linking parameters: clearance (new for X3)
12808	Retract (new for X3)

12809	Feed plane (new for X3)
12810	Incremental or absolute clearance (new for X3)



Feature-based machining: tool parameters

FBM_POCKETPARAMETERS_FACETL

FBM_POCKETPARAMETERS_TL	(new for X3)
12800	Allowed end mill types: flat endmills, bull nose, face mills (new for X3)

FBM_POCKETPARAMETERS_ROUGHTL

FBM_POCKETPARAMETERS_TL001	(new for X3)
-----------------------------------	-----------------------

FBM_POCKETPARAMETERS_FINISHTL

FBM_POCKETPARAMETERS_TL002	(new for X3)
12805	Method for selecting or creating tools to machine internal fillet arcs in the XY axes: Match tool with arc , or Use next smaller tool (new for X3)
12806	Desired tool radius as % of arc size (new for X3)

FBM_POCKETPARAMETERS_TL

	(This set of parameters used for face tools)
12755	Tool #1 from preferred tool list (new for X3)
12756	Tool #2 from preferred tool list (new for X3)
12757	Tool #3 from preferred tool list (new for X3)
12758	Tool #4 from preferred tool list (new for X3)
12759	Tool # from preferred tool list5 (new for X3)
12760	Tool #6 from preferred tool list (new for X3)
12761	Tool #7 from preferred tool list (new for X3)
12762	Tool #8 from preferred tool list (new for X3)
12763	Tool #9 from preferred tool list (new for X3)
12764	Tool #10 from preferred tool list (new for X3)
12765	Number of tools (new for X3)
12766	Minimum diameter for automatic tool selection (new for X3)
12767	Minimum diameter for automatic tool selection (new for X3)

12768	Tool size increment for automatic tool selection (diameter) (new for X3)
12769	Tool size increment for automatic tool selection (% of max diameter) (new for X3)

**FBM_POCKETPARAMETERS_TL001**

	(This set of parameters used for rough/restmill tools)
12770	Tool #1 from preferred tool list (new for X3)
12771	Tool #2 from preferred tool list (new for X3)
12772	Tool #3 from preferred tool list (new for X3)
12773	Tool #4 from preferred tool list (new for X3)
12774	Tool #5 from preferred tool list (new for X3)
12775	Tool #6 from preferred tool list (new for X3)
12776	Tool #7 from preferred tool list (new for X3)
12777	Tool #8 from preferred tool list (new for X3)
12778	Tool #9 from preferred tool list (new for X3)
12779	Tool #10 from preferred tool list (new for X3)
12780	Number of tools (new for X3)
12781	Minimum diameter for automatic tool selection (new for X3)
12782	Minimum diameter for automatic tool selection (new for X3)
12783	Tool size increment for automatic tool selection (diameter) (new for X3)
12784	Tool size increment for automatic tool selection (% of max diameter) (new for X3)

FBM_POCKETPARAMETERS_TL002

	(This set of parameters used for finish tools)
12785	Tool #1 from preferred tool list (new for X3)
12786	Tool #2 from preferred tool list (new for X3)
12787	Tool #3 from preferred tool list (new for X3)
12788	Tool #4 from preferred tool list (new for X3)
12789	Tool #5 from preferred tool list (new for X3)
12790	Tool #6 from preferred tool list (new for X3)
12791	Tool #7 from preferred tool list (new for X3)
12792	Tool #8 from preferred tool list (new for X3)
12793	Tool #9 from preferred tool list (new for X3)
12794	Tool #10 from preferred tool list (new for X3)
12795	Number of tools (new for X3)
12796	Minimum diameter for automatic tool selection (new for X3)

12797	Minimum diameter for automatic tool selection (new for X3)
12798	Tool size increment for automatic tool selection (diameter) (new for X3)
12799	Tool size increment for automatic tool selection (% of max diameter) (new for X3)



Chooks

PRM_C-HOOK

15266	Operation description to display in the Operation Manager
15267	Source C-Hook name (no prefix path). If "" (null string), call as .dll.
15268	C-Hook's function or dll to call when operation's parameters are selected in the Operation Manager
15269	C-Hook's function or dll to call when operation's tool is selected in the Operation Manager
15270	C-Hook's function or dll to call when operation's geometry is selected in the Operation Manager
15271	C-Hook's function or dll to call when operation's NCI is selected in the Operation Manager with the left mouse button
15272	<i>C-Hook's function or dll to call to regenerate operation's NCI section (removed for X3)</i>
15336	C-Hook's function or dll to call when operation's NCI is selected in the Operation Manager with the right mouse button
15337	Filter operation (True/False)
15338	Toolpath edited (True/False)
30000–31999	Range of parameter numbers reserved for use by C-Hook developers. (new for X3)

Multiaxis toolpaths

PRM_CURVE_5AX

PRM_SRF_COMMON
PRM_SRF_DIRECTION
PRM_SRF_GAP_SETTINGS
PRM_SRF_EDGE_SETTINGS
MULTAX_ENTRY_EXIT

12019	OutputFormat (CM5dlg parameters)
12141	CurveType (CM5dlg parameters)



12142	ToolAxis (CM5dlg parameters)
12023	ProjectType (CM5dlg parameters)
12022	TipControl (CM5dlg parameters)
12143	EdgeType (CM5dlg parameters)
12144	Curve following method: true = step increment, false = chordal deviation
12145	Step increment distance
12146	Maximum step distance for chordal deviation
12147	Chordal deviation
12148	Maximum projection distance
12149	Radial offset
12150	Offset sign
12139	Side angle: positive is to the right, negative is to the left
12151	Lead angle
12152	Normal depth
12153	Toolplane axis: true = 5- axis, false = 3-axis
12154	Ma view number
12155	Do all edges (True/False)
12156	Display clipped corners on the screen (True/False)
12157	Minimize corners (True/False)
12158	Gouge check: 0 = infinite, 1 = user defined look ahead distance, 2 = none
12159	User defined look ahead distance
12160	Tip compensation: 0 = tip on curve, 1 = compensate to surface
12024	Tool display and NCI vector length
12025	Fourth axis: 0 = X, 1 = Y
12250	Bit 0 means lines are relative to toolpath direction Bit 1 was used for relative to surface Bit 2 is used for finish all depths Bit 3 is or chain tool axis control
12251	Plane vector for tool axis control
12252	Plane vector for tool axis control
12253	Plane vector for tool axis control

PRM_5AX_LIMIT
PT_GENERATOR

PRM_SRF_FLOW5AX

PRM_SRF_COMMON	
PRM_SRF_DIRECTION	
PRM_SRF_GAP_SETTINGS	
PRM_SRF_EDGE_SETTINGS	
PRM_SRF_LIMITS	
10208	Cut method



12115	Use along distance (True/False)
12116	Along cut: distance
12117	Use across distance (True/False)
12118	Across cut: distance
12119	Across cut: scallop height
12120	Check flowline motion for gouge (True/False)
12138	Positive: top of tool is forward (tip back)
12104	Plunge distance
12105	Retract distance
12139	Side angle: positive is to the right, negative is to the left
12121	Start point (which corner)
12122	Cut direction (U or V)
12264	Shared edge tolerance: 0.0 = off
12421	True = row only (v8 code), false = grid (v9)
12427	Tool display and NCI output length
MULTAX_ENTRY_EXIT	
PRM_5AX_LIMIT	
12019	OutputFormat (CM5dlg parameters)
12373	PatternType (CM5dlg parameters)
12142	ToolAxis (CM5dlg parameters)
12374	Cut type
12025	4th axis: 0 = X, 1 = Y, 2 = Z
12250	specflags : so far only used for chain tool axis control usage (bits 0 & 1)
12251	Plane vector for tool axis control
12252	Plane vector for tool axis control
12253	Plane vector for tool axis control
PT_GENERATOR	
12437	Stock on drive surface
12701	Number of flow blend passes (X2)
12702	True = enable flow blend passes; False = disable flow blend passes (X2)
12703	Rib resolution as percent of tool diameter (X2)
PRM_MINTILT (new for X4)	

PRM_SRF_4AX

PRM_SRF_COMMON

PRM_SRF_DIRECTION



PRM_SRF_GAP_SETTINGS	
PRM_SRF_EDGE_SETTINGS	
PRM_SRF_DEPTHS	
10223	Use center point (True/False)
10208	Direction of open boundaries:(0 = zigzag, 1 = one way)
10415	Direction of closed boundaries (True = climb)
12138	Positive = top of tool is forward (tip back)
12140	Axis damp length
12104	Plunge distance
12105	Retract distance
12139	Side angle: positive is to the right, negative is to the left
12025	4th axis: 0 = X, 1 = Y, 2 = Z
12284	Cut type: true = axial cut, false = rotary cut
12285	Axial cut angular step (max) (radius)
12286	Axial cut angular start (radius)
12287	Axial cut angular sweep (radius)
12427	Tool display and NCI length
MULTAX_ENTRY_EXIT	
PRM_5AX_LIMIT	
12019	OutputFormat (CM5dlg parameters)
12373	PatternType (CM5dlg parameters)
12142	ToolAxis (CM5dlg parameters)
12374	Cut type
12250	specflags : so far only used for chain tool axis control usage (bits 0 and 1)
12251	Plane vector for tool axis control
12252	Plane vector for tool axis control
12253	Plane vector for tool axis control
PT_GENERATOR	

PRM_SWARF_5AX

PRM_SRF_COMMON	
PRM_SRF_DIRECTION	
PRM_SRF_GAP_SETTINGS	
PRM_SRF_EDGE_SETTINGS	
MULTAX_ENTRY_EXIT	
12144	Curve following method: true = step increment, false = chordal deviation
12145	Step increment distance
12146	Maximum step distance for chordal deviation
12147	Chordal deviation
12153	Toolplane axis: true = 5-axis, false = 4-axis



12161	Floor type
12162	Wall type
12163	Distance above low point
12164	(not used)
12165	Use floor (True/False)
12166	No floor (True/False)
12167	Use fans cuts (True/False)
12168	Use swarf fans cuts (True/False)
12169	Stock on walls
12170	Additional clearance on floor
12171	Maximum step along cut
12172	Number of wall passes
12173	Distance off wall per pass
12174	Number of floopasses
12175	Distance off floor per pass
12176	Use floor for normal (True/False)
12177	Floor normal X vector
12178	Floor normal Y vector
12179	Floor normal Z vector
12180	Floor X point
12181	Floor Y point
12182	Floor Z point
12183	Fan feedrate
12184	Use floor gouge protect: true = detect, false = protect
12185	Show toolpath before gouge check (True/False)
12158	Gouge check: 0 = infinite, 1 = user-defined look ahead distance, 2 = none
12159	User defined look ahead distance
12024	Tool display and NCI vector length
12265	Do finish passes at all depths (True/False)
12187	Minimize corners (True/False)
12025	Fourth axis: 0 = X, 1 = Y
12262	Sync option setting: 0 = none, 1 = by Entity, ... 6 = Manual/Density
PRM_5AX_LIMIT	
PT_GENERATOR	
12429	Use zigzag multiple passes (True/False)
15546	Closed Walls : True = enter at start of first wall, False = Enter at middle of first wall
12704	Max angle deviation from 5-axis vector for 4-axis output (X2)
12705	Max angle difference between vectors for 4-axis output (X2)

PRM_MSURF_5AX

PRM_SRF_COMMON	
PRM_SRF_DIRECTION	
PRM_SRF_GAP_SETTINGS	
PRM_SRF_EDGE_SETTINGS	
MULTAX_ENTRY_EXIT	
12019	OutputFormat (CM5dlg parameters)
12373	PatternType (CM5dlg parameters)
12142	ToolAxis (CM5dlg parameters)
12374	Cut type
12022	Tip control
12143	Edge type
PRM_M5_CYL	
PRM_M5_SPH	
PRM_M5_BOX	
12375	Operation type: finish = 0, rough = 1
10208	Cut method: zigzag, one way, spiral
12376	Surface tolerance
12416	Step between passes
12116	Maximum step distance
12377	Iteration count
12378	Depth cut distance
10128	<i>Point generators (removed for X3)</i>
PT_GENERATOR	
12150	Offset sign
12153	True = 5 axis, False = 3 axis
12154	View number
12158	Gouge check: 0=infinite, 1=user defined look ahead distance, 2=none
12159	User defined look ahead distance
12160	Tip compensation, 0=tip on curve, 1=Comp to surface
12024	Tool display and NCI vector length
12025	4 th axis: 0 = X, 1 = Y
12250	bit 0 means lines are relative to toolpath dir bit 1 was used for relative to surf norm (no longer) bit 2 is used for finish all depths (C5_FIN_ALL_BIT) bit 3 is for chain tool axis control usage
12251	Plane vector for tool axis control
12252	Plane vector for tool axis control
12253	Plane vector for tool axis control
12115	Use along distance (True/False)
12117	Use across distance (True/False)
12119	Across cut: scallop height
12120	Check cuts (True/False)



12138	Lead/lag: + top of tool is forward (tip back)
12104	Plunge distance
12105	Retract distance
12139	Side angle: positive is to the right, negative is to the left
12121	Start point (which corner)
12122	Cut direction (U or V)
12264	Shared edge tolerance
PRM_5AX_LIMIT_	
12437	Stock on drive surface
12736	Allow undercuts? (new for X3) (new for X4)
PRM_MINTILT	

PRM_SLICE_5AX (X)

PRM_SRF_COMMON	
PRM_SRF_DIRECTIO N	
PRM_SRF_GAP_SETT INGS	
PRM_SRF_EDGE_SET TINGS	
MULTAX_ENTRY_EXI T	
12019	OutputFormat (CM5dlg parameters)
12450	Slice type
12142	ToolAxis (CM5dlg parameters)
12023	Project type
12022	Tip control
12143	Edge type
12144	True = step incr, False = chord dev
12145	Step increment distance
12146	Maximum step distance for chordal dev
12147	Chordal deviation
12148	Maximum projection distance
12149	Offset radius
12150	Offset sign
12139	Side angle positive is to the right, negative is to the left
12151	Lead angle
12152	Norm depth
12153	True - five axis, False - three axis
12154	View_number
12155	Do all edges (True/False)
12156	Display clipped corners on the screen (True/False)
12157	Minimize corners





12158	Gouge check: 0=infinite, 1=user defined look ahead distance, 2=none
12159	User defined look ahead distance
12160	Tip compensation, 0=tip on curve, 1=Comp to surface
12570	Tool display and NCI vector length
12025	4 th Axis: 0 = X, 1 = Y
12250	bit 0 means lines are relative to toolpath dir bit 1 was used for relative to surf norm (no longer) bit 2 is used for finish all depths (C5_FIN_ALL_BIT) bit 3 is for chain tool axis control usage
12251	Plane vector for tool axis control
12252	Plane vector for tool axis control
12253	Plane vector for tool axis control
PRM_5AX_LIMIT	
PT_GENERATOR	
PRM_PORT_5AX (X)	
PRM_SRF_COMMON	
PRM_SRF_DIRECTION	
PRM_SRF_GAP_SETTINGS	
PRM_SRF_EDGE_SETTINGS	
PRM_SRF_LIMITS	
12250	Cut method
12115	Use along distance (True/False)
12116	Along cut: distance
12117	Use across distance (True/False)
12118	Across cut: distance
12119	Across cut: scallop height
12120	Check cuts (True/False)
12138	Lead/lag: + top of tool is forward (tip back)
12104	Plunge distance
12105	Retract distance
12139	Side angle: + is to the right, - is to the left
12121	Start point (which corner)
12122	Cut direction (U or V)
12264	Shared edge tol (0.0=off)
12421	T-row only (v8 code), F-grid (v9)
12427	Tool display and NCI output length
10127	<i>Entry/exit settings (removed for X3)</i>
MULTAX_ENTRY_EXIT	
PRM_5AX_LIMIT	
12019	Output format
12373	Pattern type
12142	Tool axis
12374	Cut type



12025	4 th axis: 0 = X, 1 = Y, 2 = Z
12250	So far only used for chain tool axis control usage (bits 0 & 1)
12251	Plane vector for tool axis control
12252	Plane vector for tool axis control
12253	Plane vector for tool axis control
PT_GENERATOR	
12437	Stock on drive surface
12551	Port compensation method
12552	Search range for port compensation
PRM_MINTILT	(new for X4)

PRM_CIRCLE_5AX

12910–12930	Future use (new for X4)
12931	Circle5ax output format: 0 = 3-axis, 1 = 4-axis, 2 = 5-axis (new for X4)
12932	Use points and lines or points (new for X4)
12933	Tool axis option (new for X4)
12934	Tip position control (new for X4)
12935	Project type (to plane or surface) (new for X4)
12936	Future use (new for X4)
12397	Circle 5ax output format 4-axis type axis selected (0 = X, 1 = Y, 2 = Z) (new for X4)
12938	Plane vector for circle5ax plane option (new for X4)
12939	Plane vector for circle5ax plane option (new for X4)
12940	Plane vector for circle5ax plane option (new for X4)
12941–12943	Future use (new for X4)
PRM_5AX_LIMIT	(new for X4)
PRM_CIRC MILL	(new for X4)

Multiaxis toolpaths: common settings

MULTAX_ENTRY_EXIT

ENT_EXIT	
ENT_EXIT002	
12266	Curve Tolerance

ENT_EXIT

12267	Approach/retract (True/False)
12268	Approach/retract height
12269	Entry/exit (True/False)



12270	Direction: true = right, false = left
12271	Length
12272	Height
12273	Thickness
12274	Pivot Angle
12948	Length of entry/exit as % of tool diameter (new for X4)
12949	Thickness of entry/exit as % of tool diameter (new for X4)

ENT_EXIT002

12275	Approach/retract (True/False)
12276	Approach/retract height
12277	Entry/exit (True/False)
12278	Direction: true = right, false = left
12279	Length
12280	Height
12281	Thickness
12282	Pivot Angle
12950	Length of entry/exit as % of tool diameter (new for X4)
12951	Thickness of entry/exit as % of tool diameter (new for X4)

PT_GENERATOR

12379	Angle point generator : True=on
12380	Distance point generator : True=on
12381	Chord point generator: True=on
12382	Maximum chordal deviation
12383	Maximum projection distance
12384	Maximum tool axis angle

PRM_M5_CYL

12334	Cylinder axis point 1
12335	Cylinder axis point 1
12336	Cylinder axis point 1
12337	Cylinder axis point 2
12338	Cylinder axis point 2
12339	Cylinder axis point 2
12340	Cylinder minimum radius
12341	Cylinder maximum radius
12342	Cylinder start angle



12343	Cylinder sweep angle
12344	Cylinder equator start angle
12345	Side of surface

PRM_M5_SPH

12346	Sphere center point
12347	Sphere center point
12348	Sphere center point
12349	Sphere axis vector
12350	Sphere axis vector
12351	Sphere axis vector
12352	Sphere minimum radius
12353	Sphere maximum radius
12354	Sphere pole start angle
12355	Sphere pole sweep angle
12356	Sphere equator start angle
12357	Sphere equator sweep angle
12358	Side of surface

PRM_M5_BOX

12359	Box axis point 1
12360	Box axis point 1
12361	Box axis point 1
12362	Box axis point 2
12363	Box axis point 2
12364	Box axis point 2
12365	Box length along axis (X)
12366	Box minimum width (Y)
12367	Box minimum height (Z)
12368	Box start angle
12369	Box sweep angle
12370	Box corner radius on min box
12371	Box Z plane rotation angle
12372	Side of surface

PRM_5AX_LIMIT

MULTAX_LIMIT	X
MULTAX_LIMIT002	Y
MULTAX_LIMIT003	Z
12333	Option

MULTAX_LIMIT

12324	X-axis limit active (True/False)
-------	----------------------------------



12325	X-axis minimum angle (as cosine)
12326	X-axis maximum limit (as cosine)

MULTAX_LIMIT002

12327	Y-axis limit active (True/False)
12328	Y-axis minimum angle (as cosine)
12329	Y-axis maximum limit (as cosine)

MULTAX_LIMIT003

12330	Z-axis limit active (True/False)
12331	Z-axis minimum angle (as cosine)
12332	Z-axis maximum limit (as cosine)

PRM_MINTILT

12944	Minimum Tilt option is enabled (new for X4)
12945	Minimum tilt type (new for X4)
12946	Maximum tilt angle (new for X4)
12947	Tilt application: minimize tilt motion? (new for X4)

Lathe parameters

Lathe roughing toolpaths

PRM_LROUGH

10214	Direction: 0 = ID, 1 = OD, 2 = face, 3 = back
13343	Step amount (was 10200) (X)
10215	Use equal steps (True/False)
10407	Overlap amount (was 10201) (X)
10216	Use overlap (True/False)
10220	Use advanced parameters (True/False)
13344	Cut angle relative to cut direction (was 10204) (X)
10213	True = zigzag, false = one way
10202	Stock to leave in X
10203	Stock to leave in Z
13345	Stepover amount (was 10205) (X)
10221	Plunge move feed rate

PRM_LATHE_EE**PRM_LATHE_PLUNGE001**


13164	Entry amount
13171	Feed rate for plunge: true = use regular feed rate , false = use plunge feed rate
13188	Use minimum angle (True/False)



13189	Minimum overlap angle
13190	Minimum overlap angle absolute (True/False)
13191	Minimum step amount
13192	Do semi-finish pass (True/False)
13193	Number of cuts
13194	Step amount
13143	Stock to leave in X
13144	Stock to leave in Z
PRM_PINCH_PARAMS	(new for X3)


PRM_LATHE_PLUNGE

10122 Start of cut: true = start compensated for tool width, false = start on corner




10123 Maximum incremental plunge angle (in radians)

10124 Plunge cutting selection setting: 0, 1, 2, or 3



10125 Tool width compensation: true = use tool width in compensation calculation



PRM_LATHE_PLUNGE001


(This group of parameters used for lathe rough operations)



10522

Start of cut: true = start compensated for tool width, false = start on corner (was 10222) [\(X\)](#)

Start Of Cut




- Start cut on tool front corner 10222 = 0
- Start cut on tool back corner 10222 = 1

10523

Maximum incremental plunge angle (in radians) (was 10223) [\(X\)](#)


10524

Plunge cutting selection setting: 0, 1, 2, or 3 (was 10224) [\(X\)](#)



10525

Tool width compensation: 1 = use tool width in compensation calculation, 0 = Use plunge clearance angle (was 10225) [\(X\)](#)



PRM_PINCH_PARAMS

13242

True = pinching, False = not pinching **(new for X3)**

13243

Operation to pinch **(new for X3)**

13244

(not used) **(new for X3)**

13245

(not used) **(new for X3)**

Lathe finish toolpaths

PRM_LFINISH

13341 Number of finish cuts (was 10100) [\(X\)](#)

10101 Step amount

10102 Stock to leave in X



	10103	Stock to leave in Z
	13342	Linearization tolerance (was 10104) (X)
PRM_LATHE_EE		
	13020	Contour to finish: true = use chain, false = use associated operation's chain
	13021	Operation that contains profile
	13022	Direction: 0 = ID, 1 = OD, 2 = face, 3 = back
PRM_LATHE_CORNER_BREAK		

PRM_LATHE_CORNER_BREAK

	13176	Break the corners (True/False)
	13177	Break type: true = Radius corners, false = Chamfer corners
	13178	Size of radius
	13179	Maximum angle to put radius on
	13180	Minimum angle to put radius on
	13181	Chamfer height
	13182	Radius on chamfer
	13183	Chamfer angle tolerance
	13184	Feed rate mode: 0 = same as toolpath, 1 = Feed rate, 2 = minimum number of revolutions
	13185	Feed rate
	13186	Feed rate type: R = feed/revolution, M = feed/min., S = surface finish
	13187	Minimum number of revolutions

Lathe entry/exit

PRM_LATHE_EE

PRM_LATHE_EE_VEC	Entry vector
PRM_LATHE_EE_VEC002	Exit vector

PRM_LATHE_EE_VEC

	11001	Lead-in vector angle (cosine)
	11002	Lead-in vector angle (sine)
	13000	Arc
	13001	Arc
	11007	Lead-in arc radius
	13002	Arc
	11008	Lead-in arc sweep (radians)
	13003	Use entry/exit vector (True/False)
	11006	Use entry/exit arc (True/False)

11021	Amount to extend/shorten the first/last move in toolpath
11022	Extend/shorten first/last move in toolpath enabled (True/False)
11003	Entry vector: 1 = rapid, 0 = feed
11023	Entry vector direction mode: 0 = user, 1 = tangent, 2 = perpendicular
11004	Entry vector: feed rate
11005	Entry vector feed rate type: 'R' = feed/rev, 'M' = feed/minute, 'S' = same as toolpath
11025	Entry/exit: 0 = auto, 1 = user defined
11024	Minimum auto entry length
13004	Adjust contour first/last entities (True/False)
13005	Amount to lengthen/shorten contour first/last entity
13006	Use amount to lengthen/shorten contour first/last entity (True/False)
13007	Length of line added to contour first/last entity
13008	Angle of line added to contour first/last entity
13009	Add a line perpendicular to contour first/last entity (True/False)

PRM_LATHE_EE_VEC002

11011	Lead-out vector angle (cosine)
11012	Lead-out vector angle (sine)
13010	Arc
13011	Arc
11017	Lead-out arc radius
13012	Arc
11018	Lead-out arc sweep (radians)
13013	Use entry/exit vector (True/False)
11016	Use entry/exit arc (True/False)
11026	Amount to extend/shorten the first/last move in toolpath
11027	Extend/shorten first/last move in toolpath enabled (True/False)
11013	Retraction vector: 1 = rapid, 0 = feed
11028	Exit vector direction mode: 0 = user, 1 = tangent, 2 = perpendicular
11014	Retraction vector: feed rate
11015	Retraction vector feed rate type: 'R' = feed/rev, 'M' = feed/minute, 'S' = same as toolpath
11030	Use auto entry/exit (True/False)
11029	Minimum auto entry length
13014	Adjust contour first/last entities (True/False)
13015	Amount to lengthen/shorten contour first/last entity
13016	Use amount to lengthen/shorten contour first/last entity (True/False)



13017	Length of line added to contour first/last entity
13018	Angle of line added to contour first/last entity
13019	Add a line perpendicular to contour first/last entity (True/False)



Lathe groove toolpaths

PRM_LGROOVE

13137	Groove definition type: 0 = 1 point, 1 = 2 point, 2 = 3 line, 3 = 2 boundary method (chain)
13363	Spline linearization tolerance (was 10305) (X)
13138	Groove cut direction: 0 = ID, 1 = OD, 2 = face, 3 = back, 4 = angle
10307	Groove angle
13370	Retract moves rate: True = rapid, false = feed (was 10326) (X)
10327	Retract feed rate
10328	Retract feed rate type: R = per rev, M = per minute
13240	Finish backoff
13241	Backoff type: 0 = invalid (pre v9.1), 1 = percent of tool width, 2 = distance
13403	Finish dwell type: 0 = none, 1 = seconds, 2 = revolutions (new for X4)
13404	Finish dwell time (seconds) (new for X4)
13405	Finish dwell (revolutions) (new for X4)
13406	1 = Enable First Plunge Feed Rate option (new for X4)
13407	Feed rate of first cut to depth (new for X4)
13408	Feed rate type of first cut to depth: R = feed/rev, M = feed/minute (note: output is the ASCII code for R or M) (new for X4)
13409	1 = Enable Finish feed rate option (new for X4)
13410	Finish feed rate (new for X4)
13411	Finish feed type: R = feed/rev, M = feed/minute, S=surface finish (micro-in or micron) (note: output is the ASCII code for R/M/S) (new for X4)
13412	1 = Enable Finish spindle speed option (new for X4)
13413	Finish spindle speed (new for X4)
13414	Finish spindle speed mode: 1 = CSS, 0 = RPM (new for X4)
13415	1 = Implement Tool Inspection stop (new for X4)
13416	Tool inspection position: 0 = Home position, 1 = User defined (new for X4)

13417	1 = Enable stop after Each groove (new for X4)
13418	1 = Enable stop after Each depth cut (new for X4)
99999	1 = Enable stop after First plunge (new for X4)
13419	1 = Enable stop after specified Number of plunges (new for X4)
13420	<i>Not implemented (new for X4)</i>
13421	<i>Not implemented (new for X4)</i>
13422	Number of plunges between stops (new for X4)
13423	<i>Not implemented (new for X4)</i>
13424	<i>Not implemented (new for X4)</i>
13425	Finish groove overlap position: 0 = User-selected position, 1 = middle of groove (new for X4)
13426	Overlap distance: used when overlap is in the middle of the groove (new for X4)
13427	1 = Enable tool inspection comment (new for X4)
13428	Text string for tool inspection comment (new for X4)
13429	1 = Enable the Use reference points option on tool inspection retract and approach moves (new for X4)
13430	Type of retract position for tool inspection: 1 = absolute, 0 = incremental (new for X4)
13431	1 = Enable retract move in world X axis (typically this appears in the dialog box as Z) (new for X4)
13432	1 = Enable retract move in world Y axis (typically this appears in the dialog box as X or D). (new for X4)
13433	<i>(not currently used) (new for X4)</i>
13434	World X coordinate of tool inspection coordinates (typically this appears in the dialog box as Z). This could be absolute or incremental (see 13430). (new for X4)
13435	World Y coordinate of tool inspection coordinates (typically this appears in the dialog box as X or D). This is always output as a radius value. This could be absolute or incremental. (see 13430) (new for X4)
13436	<i>(not currently used) (new for X4)</i>
PRM_GROOVE_SHAPE	
PRM_GROOVE_ROUGH	
PRM_GROOVE_FINISH	

PRM_GROOVE_SHAPE

10331	Groove width
10332	Groove height
10333	Taper on wall 1
10334	Taper on wall 2

PRM_LATHE_CORNER**PRM_LATHE_CORNER002**

PRM_LATHE_CORNER003**PRM_LATHE_CORNER004**

13172

Make groove same width as tool (True/False)

**PRM_LATHE_CORNER**

10713	Corner definition: true = corner defined, false = none (square)
10335	Type: 0 = square, 1 = radius, 2 = chamfer, 3 = chamfer with radius
10336	Corner radius or top radius on chamfer
10762	Bottom radius on chamfer
10337	Chamfer angle
10339	Corner chamfer: 0 = width, 1 = height
10338	Chamfer width or height

PRM_LATHE_CORNER001

10713	Corner definition: true = corner defined, false = none (square)
10760	Type: 0 = square, 1 = radius, 2 = chamfer, 3 = chamfer with radius
10761	Corner radius or top radius on chamfer
10762	Bottom radius on chamfer
10714	Chamfer angle
10715	Corner chamfer: 0 = width, 1 = height
10716	Chamfer width or height

PRM_LATHE_CORNER002

13026	Corner definition: true = corner defined, false = none (square)
10340	Type: 0 = square, 1 = radius, 2 = chamfer, 3 = chamfer with radius
10341	Corner radius or top radius on chamfer
13027	Bottom radius on chamfer
10342	Chamfer angle
10344	Corner chamfer: 0 = width, 1 = height
10343	Chamfer width or height

PRM_LATHE_CORNER003

13028	Corner definition: true = corner defined, false = none (square)
10345	Type: 0 = square, 1 = radius, 2 = chamfer, 3 = chamfer with radius
10346	Corner radius or top radius on chamfer
13029	Bottom radius on chamfer
10347	Chamfer angle
10349	Corner chamfer: 0 = width, 1 = height



10348 | Chamfer width or height

PRM_LATHE_CORNER004

13030	Corner definition: true = corner defined, false = none (square)
10350	Type: 0 = square, 1 = radius, 2 = chamfer, 3 = chamfer with radius
10351	Corner radius or top radius on chamfer
13371	Bottom radius on chamfer (was 13031) (X)
10352	Chamfer angle
10354	Corner chamfer: 0 = width, 1 = height
10353	Chamfer width or height

PRM_GROOVE_ROUGH

13356	Do groove rough (True/False) (was 10308) (X)
13127	Finish current groove before roughing next one (True/False)
13357	Cut direction: (X) 0 = positive 1 = negative 2 = bi-directional (center start) 3 = chain direction (was 10309)
13358	Step amount (was 10301) (X)
13128	Number of steps across groove
13129	Rough step: 0 = use number of steps 1 = use step 2 = use percent of tool width
13359	Stock to leave in X (was 10302) (X)
13360	Stock to leave in Z (was 10303) (X)
13361	Stock clearance between cuts (was 10310) (X)
10329	Amount of stock on top of groove
13362	Backoff percent of step (was 10311) (X)
13130	Finish each groove after roughing it (True/False)

PRM_LATHE_PECK001

PRM_GROOVE_DEPTH

PRM_GROOVE_STEP

13131 | Step percent of tool width

PRM_LATHE_PECK

13347	Use peck parameters (True/False) (was 10702) (X)
10744	Peck type: 0= none, 1 = number, 2 = incremental, 3 = decreasing increment
13355	Peck on first plunge only (True/False) (was 10313) (X)
10316	Depth (Pre-X)
10318	Last increment (Pre-X)



13348	Peck amount: 'number of pecks' (was 10315) (X)
13349	Peck increment (was 10704) (X)
13350	Final peck increment (was 10706) (X)
10740	Retract type: 0= none, 1 = absolute, 2 = incremental (was 10319)
10742	Retract amount (absolute)
10741	Retract amount (incremental) (was 10320) (X)
10743	Dwell type: 0= none, 1 = all pecks, 2 = last peck
13351	Dwell value (was 10321) (X)
13023	Dwell units: 0 = seconds, 1 = revolutions

PRM_LATHE_PECK001

13352	Use peck parameters (True/False) (was 10312) (X)
10744	Peck type: 0 = none, 1 = number, 2 = incremental, 3 = decreasing increment
13353	Peck on first plunge only (True/False) (was 10313) (X)
13354	Peck amount: 'number of pecks' (was 10315) (X)
10316	Peck increment
10318	Last peck increment
10319	Retract type: 0 = none, 1 = absolute, 2 = incremental
10742	Peck incremental amount
13364	Peck retract increment (was 10320) (X)
10743	Dwell type: 0 = none, 1 = all pecks, 2 = last peck
13365	Dwell (was 10321) (X)
13023	Dwell units: 0 = seconds, 1 = revolutions

PRM_LATHE_PECK002

10722	Use peck parameters (True/False)
10723	Peck type: 0= none, 1 = number, 2 = incremental, 3 = decreasing increment
13024	Peck on first plunge only (True/False)
10724	Peck number
10725	Peck increment
10726	Peck last increment
10727	Peck retract type : 0= none, 1 = absolute, 2 = incremental
10728	Peck absolute amount
10729	Peck incremental amount
10731	Peck dwell type: 0 = none, 1 = all pecks, 2 = last peck
10732	Peck dwell
13025	Dwell units: 0 = seconds, 1 = revolutions

PRM_GROOVE_DEPTH

13366	Do groove depth cuts (True/False) (was 10322) (X)
13367	Use depth number/increment: 0 = number, 1 = increment (was 10323) (X)
13368	Depth cut increment (was 10325) (X)

13120	Retract to Stock Clearance: true = incremental, false = absolute
13369	Depth cut number (was 10324) (X)
13372	Zigzag between depth cuts (True/False) (was 13121) (X)

**PRM_GROOVE_STEP**

13122	Clean up 'stair steps' between depths (True/False)
13123	Minimum step size to clean up
13124	Radius to arc on with for step removal cut
13125	Sweep angle to arc on with for step removal cut
13126	Arc onto step cleanup pass (True/False)

PRM_GROOVE_FINISH

10360	Do groove finish (True/False)
10361	Start on positive side (True/False)
10364	Number of finish passes
10365	Finish stepover amount
10366	Stock to leave in X
10367	Stock to leave in Z
13132	Tool back offset number
13133	Use back offset number (True/False)
10370	Multiple passes: true = finish each groove completely, false = finish grooves together
10380	Amount to lengthen 1st cut
13134	Amount of overlap between 1st and 2nd cuts

PRM_LATHE_EE

13136	Wall backoff: true = overlap is percent of tool width, false = overlap is length
-------	--

Lathe thread toolpaths

PRM_LTHREAD

10822	Thread name (was 10422) (X)
10823	Allowance name (was 10423) (X)

PRM_THREAD_SHAPE**PRM_THREAD_CUT****PRM_THREAD_SHAPE**

10819	Thread cut type: 0 = ID, 1 = OD, 2 = face/back (was 10419) (X)
10800	Thread lead: thread/inch (mm) setting returns a negative value, inches (mm)/thread setting returns a positive value (was 10400) (X)
10811	Major diameter (was 10411) (X)



10812	Minor diameter (was 10412) (X)
10813	Start position (was 10413) (X)
10814	End position (was 10414) (X)
10815	Taper angle (was 10415) (X)
10816	Cut side of axis: 0 = positive side, 1 = negative side (Negative X is checked) (was 10816) (X)
10830	Use allowance (True/False) (was 10430) (X)
10817	Major allowance (was 10417) (X)
10818	Minor allowance (was 10418) (X)
10824	Allowance tolerance (was 10424) (X)
10805	Lead angle (was 10405) (X)
10840	Included angle (was 10440) (X)
13195	Diameter at small end (True/False)
13380	Allowance is disabled (True/False) (new for X3)

PRM_THREAD_CUT

10809	NC output type: 0 = long hand (G32), 1 = canned (G76), 2 = box (G92) (was 10409) (X)
10801	First cut depth (was 10801) (X)
10802	Last cut depth (was 10402) (X)
10820	Number of starts (was 10420) (X)
10821	Auto compute acceleration clearance (True/False) (was 10421) (X)
10803	Acceleration clearance amount (was 10403) (X)
10831	Units: true = revolutions, false = inches (was 10431) (X)
10832	Clearance above threads between passes (was 10432) (X)
10833	Clearance at to add at end of thread pass (was 10433) (X)
10834	Units: true = revolutions, false = inches (was 10434) (X)
10804	Anticipated pulloff distance (was 10404) (X)
10835	Units: true = revolutions, false = inches (was 10435) (X)
10808	Amount of stock to leave for spring cuts (was 10408) (X)
10807	Number of spring cuts (was 10407) (X)
10810	Feed rate (was 10410) (X)
10837	Number of cuts (was 10437) (X)
10838	Determine cut depths: true = equal depth, false = equal area (was 10438) (X)
10836	Determine cut number: true = number of cuts, false = first cut depth (was 10436) (X)
10839	Tool lead-in angle at start of thread (was 10439) (X)
15554	Multi-start (True/False)
15555	Start closest (True/False)
15556	Start clear last (True/False)

Lathe drill toolpaths

PRM_LDRILL



10500	Drill cycle
10507	First peck increment
10508	Subsequent peck increment
10509	Peck clearance
10510	Retraction distance for chip break
10503	Dwell
10520	Shift value
10117	Drill tip compensation breakthrough amount
10511	Adjust depth per drill tip (True/False)
10519	Drill point in Z
10502	Drill X position
10514	Feed plane (retract value) incremental mode is checked (True/False) (Pre-X)
15071	Custom drill cycle parameters
15072	Custom drill cycle parameters
15073	Custom drill cycle parameters
15074	Custom drill cycle parameters
15075	Custom drill cycle parameters
15076	Custom drill cycle parameters
15077	Custom drill cycle parameters
15078	Custom drill cycle parameters
15079	Custom drill cycle parameters
15080	Custom drill cycle parameters
15081	Use custom parameters is checked (True/False)
13169	Clearance height is incremental from stock (True/False)
13170	Retraction height is incremental from stock (True/False)

Lathe face toolpaths

PRM_LATHE_FACE

10603	Do groove roughing (True/False)
10604	Maximum stepover
10606	Do groove finishing (True/False)
10608	Amount of each cut



10607	Number of finish passes
10609	Stock to leave after rough and finish
10614	Lead-in amount
10612	Retract amount
10613	Retract speed: 0 = linear, 1 = rapid
10601	Ovcut_amount
10615	Cut from Z axis : true = cut away from center line, false = cut toward center line
PRM_LATHE_EE	

Lathe cutoff toolpaths

PRM_LCUTOFF

13346	'X' tangent point (was 10701) (X)
10711	Cut tool to: 0 = front radius, 1 = back radius
10712	Lead in amount
10750	Retract Radius: 0 = none, 1 = absolute, 2 = incremental
10752	Retract amount, absolute
10751	Retract amount, incremental
PRM_LATHE_PECK	
PRM_LATHE_CORNER001	
PRM_LATHE_EE	
10718	Do clearance cut (True/False)
10719	Clearance amount X
10720	Clearance amount Z
10721	Clearance cut lead in amount
PRM_LATHE_PECK001	
13039	Do canned text (True/False)
PRM_LCUTOFF_CANTXT	
PRM_LCUTOFF_CANTXT002	
PRM_LCUTOFF_CANTXT003	
PRM_LCUTOFF_CANTXT004	
PRM_LCUTOFF_CANTXT005	
PRM_LCUTOFF_CANTXT006	
PRM_LCUTOFF_CANTXT007	
PRM_LCUTOFF_CANTXT008	

PRM_LCUTOFF_CANTXT

13031	Radius to output canned text
13040	Canned text values
13041	Canned text values
13042	Canned text values



13043	Canned text values
13044	Canned text values
13045	Canned text values
13046	Canned text values
13047	Canned text values
13048	Canned text values
13049	Canned text values
13261	Additional canned text values (X)
13262	Additional canned text values (X)
13263	Additional canned text values (X)
13264	Additional canned text values (X)
13265	Additional canned text values (X)
13266	Additional canned text values (X)
13267	Additional canned text values (X)
13268	Additional canned text values (X)
13269	Additional canned text values (X)
13270	Additional canned text values (X)

PRM_LCUTOFF_CANTXT002

13032	Radius to output canned text
13050	Canned text values
13051	Canned text values
13052	Canned text values
13053	Canned text values
13054	Canned text values
13055	Canned text values
13056	Canned text values
13057	Canned text values
13058	Canned text values
13059	Canned text values
13271	Additional canned text values (X)
13272	Additional canned text values (X)
13273	Additional canned text values (X)
13274	Additional canned text values (X)
13275	Additional canned text values (X)
13276	Additional canned text values (X)
13277	Additional canned text values (X)
13278	Additional canned text values (X)
13279	Additional canned text values (X)
13280	Additional canned text values (X)

PRM_LCUTOFF_CANTXT003

13033	Radius to output canned text
13060	Canned text values
13061	Canned text values



13062	Canned text values
13063	Canned text values
13064	Canned text values
13065	Canned text values
13066	Canned text values
13067	Canned text values
13068	Canned text values
13069	Canned text values
13281	Additional canned text values (X)
13282	Additional canned text values (X)
13283	Additional canned text values (X)
13284	Additional canned text values (X)
13285	Additional canned text values (X)
13286	Additional canned text values (X)
13287	Additional canned text values (X)
13288	Additional canned text values (X)
13289	Additional canned text values (X)
13290	Additional canned text values (X)

PRM_LCUTOFF_CANTXT004

13034	Radius to output canned text
13070	Canned text values
13071	Canned text values
13072	Canned text values
13073	Canned text values
13074	Canned text values
13075	Canned text values
13076	Canned text values
13077	Canned text values
13078	Canned text values
13079	Canned text values
13291	Additional canned text values (X)
13292	Additional canned text values (X)
13293	Additional canned text values (X)
13294	Additional canned text values (X)
13295	Additional canned text values (X)
13296	Additional canned text values (X)
13297	Additional canned text values (X)
13298	Additional canned text values (X)
13299	Additional canned text values (X)
13300	Additional canned text values (X)

PRM_LCUTOFF_CANTXT005

13035	Radius to output canned text
13080	Canned text values



13081	Canned text values
13082	Canned text values
13083	Canned text values
13084	Canned text values
13085	Canned text values
13086	Canned text values
13087	Canned text values
13088	Canned text values
13089	Canned text values
13301	Additional canned text values (X)
13302	Additional canned text values (X)
13303	Additional canned text values (X)
13304	Additional canned text values (X)
13305	Additional canned text values (X)
13306	Additional canned text values (X)
13307	Additional canned text values (X)
13308	Additional canned text values (X)
13309	Additional canned text values (X)
13310	Additional canned text values (X)

PRM_LCUTOFF_CANTXT006

13036	Radius to output canned text
13090	Canned text values
13091	Canned text values
13092	Canned text values
13093	Canned text values
13094	Canned text values
13095	Canned text values
13096	Canned text values
13097	Canned text values
13098	Canned text values
13099	Canned text values
13311	Additional canned text values (X)
13312	Additional canned text values (X)
13313	Additional canned text values (X)
13314	Additional canned text values (X)
13315	Additional canned text values (X)
13316	Additional canned text values (X)
13317	Additional canned text values (X)
13318	Additional canned text values (X)
13319	Additional canned text values (X)
13320	Additional canned text values (X)

PRM_LCUTOFF_CANTXT007

13037	Radius to output canned text
-------	------------------------------



13100	Canned text values
13101	Canned text values
13102	Canned text values
13103	Canned text values
13104	Canned text values
13105	Canned text values
13106	Canned text values
13107	Canned text values
13108	Canned text values
13109	Canned text values
13321	Additional canned text values (X)
13322	Additional canned text values (X)
13323	Additional canned text values (X)
13324	Additional canned text values (X)
13325	Additional canned text values (X)
13326	Additional canned text values (X)
13327	Additional canned text values (X)
13328	Additional canned text values (X)
13329	Additional canned text values (X)
13330	Additional canned text values (X)

PRM_LCUTOFF_CANTXT008

13038	Radius to output canned text
13110	Canned text values
13111	Canned text values
13112	Canned text values
13113	Canned text values
13114	Canned text values
13115	Canned text values
13116	Canned text values
13117	Canned text values
13118	Canned text values
13119	Canned text values
13331	Additional canned text values (X)
13332	Additional canned text values (X)
13333	Additional canned text values (X)
13334	Additional canned text values (X)
13335	Additional canned text values (X)
13336	Additional canned text values (X)
13337	Additional canned text values (X)
13338	Additional canned text values (X)
13339	Additional canned text values (X)
13340	Additional canned text values (X)

Lathe canned toolpaths



PRM_LCAN_ROUGH

13139	Change to longhand (True/False)
10214	Direction: 0 = OD, 1= ID, 2 = face, 3 = back
13343	Step amount (was 10200) (X)
10202	Stock to leave in X
10203	Stock to leave in Z
13345	Stepover amount (was 10205) (X)

PRM_LATHE_EE

10201	Overlap
13164	Entry Amount

PRM_LATHE_PLUNGE

13239	Plunge cutting: true = profile has an undercut (relief) condition, false = ignore undercut areas
-------	--

PRM_LCAN_FINISH

13121	Operation that contains profile
13141	Not used
13142	Change to longhand (True/False)
13143	Not used
13144	Not used
13145	Linearization tolerance

PRM_LATHE_EE

13203	Unique subprogram number (was 13165) (X)
13239	Plunge cutting: true = profile has an undercut (relief) condition, false = ignore undercut areas

PRM_LCAN_PATTERN

13147	Output longhand (True/False) (Not used)
13148	Change to longhand (True/False)
13341	Number of passes (was 10100) (X)
10101	Stepover
10102	Stock to leave in X
10103	Stock to leave in Z
13149	Pattern offset angle (in radians)
13342	Linearization tolerance (was 10104) (X)

PRM_LATHE_EE

Lathe misc ops

PRM_LSTOCK_XFER

13205	Active spindle for stock transfer
13206	Z coordinate on stock to be transferred



		Previous Z coordinate on stock to be transferred
13207		Use stock BACK face as init Z position (True/False)
13208		Z coordinate on transferred stock
13209		Source chuck reference position before transfer
13210		Source chuck reference position before transfer
13211		Source chuck reference position after transfer
13212		Source chuck reference position after transfer
13213		Destination chuck reference position before transfer
13214		Destination chuck reference position before transfer
13215		Destination chuck pickoff position
13216		Destination chuck pickoff position
13217		Get final (Lathe) X coordinate from stock (True/False)
13218		Move Cplane origin to new stock position (True/False)
13219		Move Tplane origin to new stock position (True/False)
13220		Transfer geometry also (True/False)
13221		Level to store transferred geometry on
13222		Offset from source geometry level for transferred geometry
13223		Use geolevel (as opposed entity level) (True/False)
13224		Blank original geometry (True/False)
13225		Entity with list of transferred entity IDs
13226		Entity with list of original entity IDs
13227		Custom real / integer parameters (new for X4)
PRM_LCUSTOM		
PRM_LSTOCK_FLIP		
13205		Active spindle for stock to flip
13206		Z coordinate on stock before flip
13207		Previous Z coordinate on stock
13209		Z coordinate on stock after flip
13210		Chuck reference position before flip
13211		Chuck reference position before flip
13212		Chuck reference position after flip
13213		Chuck reference position after flip
13219		Move Cplane origin to new stock position (True/False)
13220		Move Tplane origin to new stock position (True/False)
13221		Transfer geometry also during flip (True/False)
13222		Level to store transferred geometry on
13223		Offset from source geometry level for transferred geometry
13224		Use geolevel [param: 13222] (as opposed entity level)
13225		Blank original geometry (True/False)
13226		Entity with list of transferred geometry entity IDs
13227		Entity with list of original geometry entity IDs
PRM_LCUSTOM		

PRM_LBARFEED

13205	Active spindle for stock to barfeed
13206	Z coordinate on stock before barfeed
13207	Previous Z coordinate on stock
13208	Get initial Z position from stock face (True/False)
13209	Z coordinate on stock after barfeed
13210	Chuck reference position before barfeed
13211	Chuck reference position before barfeed
13212	Chuck reference position after barfeed
13213	Chuck reference position after barfeed
13228	Use chuck positions (True/False)
13219	Move Cplane origin to new stock position (True/False)
13220	Move Tplane origin to new stock position (True/False)
13221	Transfer geometry also during barfeed (True/False)
13222	Level to store transferred geometry on
13223	Offset from source geometry level for xfer'd geometry
13224	Use geolevel [param: 13222](as opposed entity level)
13225	Blank original geometry (True/False)
13226	Entity with list of transferred entity id's
13227	Entity with list of original entity id's
13229	Operation type: 0= bar feed, 1 = bar feed with tool as stop, 2 = bar pull
13230	Stock clearance for bar pull
13231	Grip length for bar pull
13232	Use plunge feed rate for approaching stock (True/False)
PRM_LCUSTOM	
13233	Custom real / integer parameters (new for X4)
	Tool X position for stop, bar puller

**PRM_LCUSTOM**

13382	Custom Parameters enabled for lathe misc ops? 1 = Custom Parameters option selected, otherwise 0. (new for X4)
13383–13392	Integer custom parameter values. (new for X4)
13393–13402	Real custom parameter values (new for X4)

PRM_LCHUCK_CLAMP

13205	Active spindle for chuck
13229	Operation type: 0 = clamp, 1 = un-clamp, 2 = reposition
13210	Initial chuck reference position
13211	Initial chuck reference position
13212	Final chuck reference position
13213	Final chuck reference position



PRM_LCUSTOM	Custom real / integer parameters (new for X4)
PRM_LTAILSTOCK	
13234	Operation: true = engage, false = retract
13235	Initial tailstock reference position
13236	Final tailstock reference position
13237	Is initial / final position based on stock position (True/False)
13238	Is initial position based on tailstock minimum point (True/False)
PRM_LCUSTOM	Custom real / integer parameters (new for X4)
PRM_LSTEADYREST	
13235	Initial steadyrest reference position (Z)
13236	Initial steadyrest reference position (Z)
PRM_LCUSTOM	Custom real / integer parameters (new for X4)

Lathe multi-tasking

PRM_PINCH_TURN	
13246	ID of source roughing op (new for X3)
13247	Dwell (seconds) at start of second cut (new for X3)
13248	Turret which takes first cut: 0=upper or 1=lower (new for X3)
13249	Type of dwell at start of second cut: time (see 13247), number of revolutions (see 13278), or distance (see 13279) (new for X3)
13376	0=Pinch turn or 1=Balance turn? (new for X3)
13377	Sync first pass only, or every pass (new for X3)
13378	Number of revolutions for dwell (new for X3)
13379	Distance amount for dwell (new for X3)
13381	Double feed rate? (y/n) (new for X3)

PRM_CUSTOM_OP

13250	0=custom, 1+ = defined by the post
13251	True = reference misc op, False = primary misc op <i>(Removed in X3)</i>
13252	<i>(Removed in X3)</i>
13253	<i>(Removed in X3)</i>
13254	<i>(Removed in X3)</i>
13255	<i>(Removed in X3)</i>
13256	<i>(Removed in X3)</i>
13257	<i>(Removed in X3)</i>
13258	<i>(Removed in X3)</i>

13259	<i>(Removed in X3)</i>
13260	Entity idn of start of event list
13373	Custom op icon name (X2)
13374	True = custom op events cannot be added (X2)



Introduced in X as **PRM_MISC_OP**; renamed to **PRM_CUSTOM_OP** for X2

Wire parameters

Wire toolpaths, common settings

PRM_WIRE_COMMON

14000	Starting pass number
14001	Power setting library entity ID #
14065	Power setting library entity ID #
14049	<i>Pointer to power setting library entity (removed for X3)</i>
14066	<i>Pointer to power setting library entity (removed for X3)</i>
14067	Use miscellaneous integers/reals (True/False)
14068	Multipass miscellaneous integers and reals entity ID #
14069	<i>Pointer to multipass miscellaneous integers/reals entity (removed for X3)</i>
14155	UV extension (was 10311) (X)
14002	UV extension: true = incremental, false = absolute
14131	UV trim plane (was 10106) (X)
14003	UV trim plane: true = incremental, false = absolute
10201	UV height (was 10101) (X)
14004	True = UV height incremental, false = absolute
14129	XY height (was 10102) (X)
14005	XY height: true = incremental, false = absolute
10306	XY trim plane (was 10107) (X)
14006	XY trim plane: true = incremental, false = absolute
14156	XY extension (was 10312) (X)
14007	XY extension: true = incremental, false = absolute
10050	Wire on (True/False)
10051	Power on (True/False)
14126	Flush: 0 = off, 1 = on, 2 = other (was 10022) (X)
14070	Tank: 0 = empty, 1 = fill
11052	Start wirepath at thread position (True = 'Auto start position' is ON)
14128	Linearization tolerance (was 10024) (X)
14008	Thread position (X coordinate)
14009	Thread position (Y coordinate)
14010	Thread position (Z coordinate)



14011	Cut position (X coordinate)
14012	Cut position (Y coordinate)
14013	Cut position (Z coordinate)
14014	Second (UV) thread position (X coordinate) - future
14015	Second (UV) thread position (Y coordinate)- future
14016	Second (UV) thread position (Z coordinate)- future
14017	Second cut position (X coordinate) - future
14018	Second cut position (Y coordinate) - future
14029	Second cut position (Z coordinate) - future
14020	Start position (X coordinate)
14021	Start position (Y coordinate)
14022	Start position (Z coordinate)
14023	Work origin (X coordinate)
14024	Work origin (Y coordinate)
14025	Work origin (Z coordinate)
14080	Use UV thread position (True/False)
14081	UV thread cut flag: 0 = not used, 1 = thread, 2 = cut, 3 = both
14082	Rapid height
14083	Rapid height: true = incremental, false = absolute
14084	Use rapid height (True/False)
14085	Use UV extension (True/False)
10486	Use UV trim plane(True/False)
14087	Use XY trim plane (True/False)
14088	Use XY extension (True/False)
14089	Suppress thread (True/False)
14090	Suppress cut (True/False)
14177	Newly created? (new for X3)
14178	Machine offset (new for X3)
14179	Agie library type (new for X4)
14180	Agie library entity ID (new for X4)
14181	Agie library entity ID (new for X4)
14182	Power library type (new for X4)
14183	Power library entity ID (new for X4)
14184	Power library entity ID (new for X4)
14185	C-Hook assigned to Misc Vals button (new for X4)

PRM_WIRE_COMMON001*(this entire group removed for X3)***PRM_WIRE_COMMON002***(this entire group removed for X3)*

PRM_WIRE_EE

14141	Lead in: N = none, A = arc, L = line (was 10700) (X)
14142	Lead out: N = none, A = arc, L = line (was 10701) (X)
14143	Radius of entry / exit arc (was 10702) (X)
14144	Sweep angle of entry / exit arc (in radians) (was 10703) (X)
14026	Apply the value in max lead out length (even if zero) (True/False)
14145	Maximum lead out length (was 10704) (X)
14146	Overlap amount (can be negative for tabs) (was 10705) (X)
14027	Cut wire before leaving contour (True/False)
14162	Rapid from thread point
14163	Rapid to cut point
14164	Output stop code before tab
14165	Output stop code after tab
14166	Rapid to start position at end of program

**PRM_WIRE_EE002**

14147	Lead in: N = none, A = arc, L = line (was 10707) (X)
14148	Lead out: N = none, A = arc, L = line (was 10708) (X)
14149	Radius of entry arc (was 10709) (X)
14150	Sweep angle of entry arc (in radians) (was 10710) (X)
14028	Apply the value in max lead out length (even if 0) (True/False)
14151	Maximum lead out length (was 10711) (X)
14152	Overlap amount (can be negative for tabs) (was 10712) (X)
14158	Cut wire before leaving contour (True/False) (was 14029) (X)
14167	Rapid from thread point
14168	Rapid to cut point
14169	Output stop code before tab
14170	Output stop code after tab
14171	Rapid to start position at end of program

PRM_WIRE_EE003

14116	Lead in: N = none, A = arc, L = line
14117	Lead out: N = none, A = arc, L = line
14118	Radius of exit arc
14119	Sweep angle of exit arc (in radians)
14120	Apply the value in max lead out length (even if 0) (True/False)
14121	Maximum lead out length
14122	Overlap amount (can be negative for tabs)
14123	Cut wire before leaving contour (True/False)

14172	Rapid from thread point
14173	Rapid to cut point
14174	Output stop code before tab
14175	Output stop code after tab
14176	Rapid to start position at end of program



Wire contour

PRM_WIRE_CONTOUR

PRM_WIRE_COMMON

10071	Infinite look-ahead is enabled (True/False)
14074	Taper active (True/False)
10055	Initial taper angle. Note: Positive or 0
14030	Taper direction: 0 = left, 1 = right
14031	Taper: 0=no cancel, 1=cancel after, 2=apply after
14032	Pass number to apply/cancel taper on
14033	CW corner type : 0 = Conical 1 = Sharp 2 = Constant 3 = Other 4 = Fixed 5 = FishTail
14034	CW corner radius - if corner type fixed
14035	CCW corner type: 0 = Conical 1 = Sharp 2 = Constant 3 = Other 4 = Fixed 5 = FishTail
14036	CCW corner radius - if corner type = fixed
14037	CW UV arc type
14038	CW UV arc radius - if uv arc type = fixed
14039	CCW UV arc type
14040	CCW UV arc radius - if uv arc type = fixed

PRM_WIRE_EE

PRM_WIRE_EE002

14154	Apply max lead length to final skim pass (True/False) (was 10714) (X)
-------	---



14153	Allow program to change cut position with tabs (True/False) (was 10713) (X)
14137	Lead in comes from inside closed contour (True/False) (was 10115) (X)
10300	Skim cut method: 0 = one-way, 1 = reverse (was 10100) (X)
14041	Lead in comes from left of open contour (True/False)
14132	Tab width (was 10108) (X)
14078	Distance from start of chain to thread
14130	Number of rough skim cuts (was 10104) (X)
14133	Number of tab cuts (was 10110) (X)
14134	Number of finish cuts - together (was 10111) (X)
14135	Number of finish cuts - separate (was 10112) (X)
14042	Cut order: 0 = all cuts together, 1 = tabs and finish together 2 = rough, tab and finish separately
14043	Use special entry/exit to prevent part drop out (True/False)
10072	Reset starting power setting number for tab cut (True/False)
14136	Output tab with last rough cut (True/False) (was 10113) (X)
10114	Output tab as: true = glue stop, false = stop point
14044	Output subprogram labels (True/False)
14045	Subprogram output mode: true = incremental, false = absolute
14138	Multiple contours use same subprogram (True/False) (was 10116) (X)
PRM_CHAIN_SORT	
14075	Contour was created as a NoCore finish contour (True/False)
14076	Expand this operation (True/False)
14077	This operation was created by expanding (True/False)
14079	Apply thread distance (old tab_height) (True/False)
14105	Contour type:
	 <p>0 = No taper 1 = Taper IN 2 = Taper OUT 3 = Land UP 4 = Land DOWN</p>
14106	Chain Height position: 0 = XY height 1 = Land height 2 = UV height
14107	Land height (XY extension)
14108	Land height: true = incremental, false = absolute
14109	Generate stop: 0 = always, 1 = first only, 2 = never

14110	Use sub offset (True/False)
14111	Sub offset
PRM_WIRE_TAB	
PRM_WIRE_EE003	
14112	finish passes entry/exit info
14113	'Perform rough cut' option is checked (True/False)
14114	'Tab' cut option is checked (True/False)
	'Skim cuts after tab' option is checked (True/False)

**PRM_WIRE_TAB**

14092	Automatically calculate tab positions (True/False)
14093	Number of tabs (for auto tab)
14094	Tab point: (0 = start, 1 = midpoint, 2 = end) of tab
14095	Use advanced auto tab positioning (True/False)
14096	Use points on chain for start and tab positions (True/False)
14097	Minimum distance from endpoint
14098	Minimum distance between tabs
14099	Minimum distance from sharp corner
14100	Sharp corner angle
14101	X dimension of maximum size shape to tab
14102	Y dimension of maximum size shape to tab
14103	Tab all shapes (True/False)
14104	Overwrite tab edit (True/False)

Wire canned cycles**PRM_WCAN_CYCLE**

PRM_WIRE_COMMON	
10400	Drill cycle
10401	Initial height
10402	Reference height
10403	Absolute height
10404	First peck increment
10405	Other peck increment
10406	Peck clearance
10409	Retract distance (was 10407) (X)
10408	Dwell
15071	Custom drill cycle parameters
15072	Custom drill cycle parameters
15073	Custom drill cycle parameters
15074	Custom drill cycle parameters

15075	Custom drill cycle parameters
15076	Custom drill cycle parameters
15077	Custom drill cycle parameters
15078	Custom drill cycle parameters
15079	Custom drill cycle parameters
15080	Custom drill cycle parameters
15081	Use custom parameters is checked (True/False)



Nocore wirepaths

PRM_WIRE_NOCORE

PRM_WIRE_COMMON	(new for X3)
10053	Auto entry - go from start to thread to pocket start (True/False)
10054	Auto exit - go to cut position afterward (True/False)
PRM_WIRE_EE	
14154	Apply max lead length to final skimpass (True/False) (was 10714) (X)
14153	Allow progr10713am to change cut position with tabs (True/False) (was) (X)
10208	Cutting method: 0 = zigzag, 1 = one way, etc. (was 10200) (X)
10217	Stepover percentage
14046	Roughing step size
14139	Roughing angle (was 10203) (X)
14140	Roughing direction : 0 = CW, 1 = CCW (was 10216) (X)
14047	Finishing enabled (True/False)
10206	Number of finish passes
10207	Finish pass step size
10212	Move to closest boundary point for finish (True/False)
14159	Output finish passes with rough pass (True/False) (was 14078) (X)
10211	Compensation for finish passes
14044	Output subprogram labels (True/False)
14045	Subprogram output mode: true = incremental, false = absolute
14138	Multiple contours use same subprogram (True/False) (was 10116) (X)
PRM_CHAIN_SORT	(X)
14160	Minimize tool burial (True/False) (was 14079) (X)

14161	Create additional finish contour operation (True/False) (was 14080) (X)
14110	Use sub offset (True/False)
14111	Sub offset



Point wirepaths

PRM_WIRE_POINT

[PRM_WIRE_COMMON](#) | [\(new for X3\)](#)

4axis wirepaths

PRM_WIRE_4AXIS

PRM_WIRE_COMMON N	(new for X3)
10071	Infinite look-ahead is enabled (True/False)
14127	4axis step size (if sync = NONE) (was 10023) (X)
10303	Old common trim_plane1
10309	4axis cutting method: 0 = taper, 1 = direct
PRM_WIRE_EE	
PRM_WIRE_EE002	
14154	Apply max lead length to final skim pass (True/False) (was 10714) (X)
14153	Allow program to change cut position with tabs (True/ False) (was 10713) (X)
14137	Lead in comes from inside closed contour (True/False) (was 10115) (X)
10300	Skim cut method: 0 = one-way, 1 = reverse
14041	Lead in comes from left of open contour (True/False)
14157	Tab width (was 10313) (X)
14078	Distance from start of chain to thread
10308	Number of rough skim cuts
14133	Number of tab cuts (was 10314) (X)
14134	Number of finish cuts - together (was 10315) (X)
14135	Number of finish cuts - separate (Unused) (was 10112) (X)
14042	Unused for now in 4-axis
14043	Use special entry/exit to prevent part dropout (True/ False)
10072	Reset starting power setting number for tab cut (True/ False)

14136	Output tab with last rough cut (True/False) (was 10316) (X)
10317	Output tab as: true = glue stop, false = stop point
14048	Sync option setting: 0 = None 1 = By entity 2 = By Branch 3 = By node 4 = By point 5 = Manual 6 = Manual/density
14044	Output subprogram labels (True/False)
14045	Subprogram output mode: true = incremental, false = absolute
14138	Multiple contours use same subprogram (True/False) (was 10116) (X)
14079	Apply thread distance (old tab_height) (True/False)
14109	Generate stop: 0 = always, 1 = first only, 2 = never
14110	Use sub offset (True/False)
14111	Sub offset
PRM_WIRE_TAB	
PRM_WIRE_EE003	
14112	Rough on (True/False)
14113	Tab on (True/False)
14114	Finish on (True/False)



Machine definition parameters



See [Capturing machine definition parameters](#) on page 31 to learn more about capturing the parameter values in your post.

The first section ([Machine definition: visual reference](#)) shows screen captures of all the machine definition dialogs annotated with the parameter numbers. The second section ([Machine definition: list of parameters](#) on page 322) lists all of the parameters by group and number.

Machine definition: visual reference

Most of the fields shown in the following pages use parameters to store their values, but the values for some fields are available as pre-defined variables, or even directly in the NCI G-code. Use the following color key to determine the type of value:

- Red labels indicate parameter numbers
- Blue labels indicate pre-defined variable names
- Green labels indicate NCI G-codes

Some fields are available as both parameters and pre-defined variables. In these cases, you can use whichever method is most convenient. Typically, this will be the pre-defined variable.

Machine Definition Manager

Machine Definition Manager - C:\MCAMX3\CNC_MACHINES\GENERIC FADAL FORMAT_2 4X MILL.MMD

The screenshot shows the Mastercam X4 Machine Definition Manager window. The title bar reads "Machine Definition Manager - C:\MCAMX3\CNC_MACHINES\GENERIC FADAL FORMAT_2 4X MILL.MMD". The menu bar includes File, Edit, View, Insert, Tools, Options, Help, and a Quick Start button.

Control Definition:

- Event based programming is supported
- Control file: C:\MCAMX3\CNC_MACHINES\GENERIC FADAL FORMAT_2 4X MILL.CONTROL (ID 17007)
- Folder: C:\MCAMX3\MILL\POSTS
- Post-processor: GENERIC FADAL FORMAT_2 4X MILL.PST (ID 17008)

Machine Configuration:

The tree view shows the following structure:

- Machine Base
 - Table Group
 - VMC Y Axis
 - VMC X Axis
 - Mill Machine Table
 - VMC A Axis
 - Fixture/Holder
 - Mill Spindle Group
 - VMC Z Axis
 - VMC Tool Spindle
 - Tool Changer Group
 - Automatic Tool Changer

Component File:

C:\MCAMX3\CNC_MAC...\\ALL COMPONENTS.GMD

Component list:

- Automatic Tool Changer
- Drill Block
- Dual Outlet Right Angle Aggregate
- Flex Aggregate
- Four Outlet Right Angle Aggregate
- HMC A Axis
- HMC B Axis
- HMC C Axis
- HMC Tool Spindle
- HMC X Axis
- HMC Y Axis
- HMC Z Axis
- Lathe Chuck
- Lathe Left Sp
- Lathe Lower
- Lathe Lower
- Lathe Lower

Toolbar state: 17014 Toolbar state: 17013 2D Toolpaths



General machine parameters

Op. feed rate limits /axis motion/orientation tab



General Machine Parameters

Coolant commands Tool/material libraries Machine dynamics CPlane/Tplane
Op. feed rate limits, axis motion Axis feed rate limits

Toolpath Feed Rate Limits


	inch	mm
Convert to mm/min. Convert to in./min.		
17054 Minimum feed/min.:	0.0001	in./min. 0.001 mm/min. 17062
17055 Maximum feed/min.:	500.0	in./min. 12500.0 mm/min. 17063
Convert to in./rev. Convert to mm/rev.		
17056 Minimum feed/rev.:	0.0001	in./rev. 0.001 mm/rev. 17064
17057 Maximum feed/rev.:	100.0	in./rev. 1000.0 mm/rev. 17065


Inverse Time Feed Rate Limits


	inch	mm
Convert to min./mm Convert to min./in.		
17058 Minimum inverse feed rate:	1000.0	min. 100.0 min. 17066
17059 Maximum inverse feed rate:	0.001	min. 0.0001 min. 17067


5 Axis Rotary Motion

<input checked="" type="checkbox"/> Break rotary motion as a combined angle 17022
Maximum rotary angle before break is required: <input type="text" value="90.0"/> 17023

Axis feed rate limits tab

CPlane, WCS, HTC/VTL tab

Coolant/Flushing/Options tab

Tool/material libraries tab

Quick Start

Machine dynamics tab

General Machine Parameters

Op. feed rate limits, axis motion Axis feed rate limits

Coolant commands Tool/material libraries Machine dynamics **Machine dynamics** CPlane/Tplane

Feed Rate Smoothing

Recombine segments when feed rate changes less than: 10.0 % **17024**

Look-ahead (% of tool diameter): 50.0 **17025**

Max. feed rate change per block: 20.0 in./min. 500.0 mm/min.
17026 **17027**

Accelerate to smooth feed rates **17028**

Segment length (% of tool diameter): 2.0 **17029**

Cornering

Slow to min. cornering feed rate when direction changes: 45.0 deg. **17030**

17031 Minimum cornering feed rate: 5.0 in./min. 125.0 mm/min.
17032

Cornering acceleration: 0.01 G's **17034**

Cornering Acceleration

Feed rate at test diameter: 117.88264 in./min.

17033 Test diameter: 2.0 inches

17034 Cornering acceleration: 0.01 G's

Component geometry (common)

Solid geometry



Machine Component Manager - Linear Axis

Name: Upper X Axis 17201

Parameters **Geometry** Position/Orientation On Machine


Geometry: Solid entity 17239 17204
Color: 63


Chord tolerance: 0.001 17764


Translucency: Solid 17765


Solid Entity
Solid name: No Solid
Select Entity... 17268 / 17269 / 17270
Set Component Name From Solid
Set Component Color From Solid

✓ ✘ ?


Block geometry

Cylinder geometry

Extruded geometry


Revolved geometry


Position/Orientation tab




Component properties (individual)


Automatic tool changer parameters





Chuck parameters


Chuck geometry (parametric) dialog box


Chuck jaws parameters




Bar stock parameters


Turret parameters


Turret geometry (parametric) dialog box


Gang tool parameters

Tailstock parameters



Tailstock geometry

Tailstock center parameters

Steady rest parameters

Linear axis parameters

Machine Component Manager - Linear Axis

Name: VMC X Axis 17201

Parameters Geometry Position/Orientation On Machine

Machine coordinate: X 17391 17396 Axis label (absolute coordinates): X 17390 Axis label (incremental coordinates): X 17923

Output coordinate as a diameter

Axis Motion

Physical Motion

Programmed axis motion = Physical axis motion

Positive axis direction: (World coordinate system)

17392

Click on desired axis to select.

Tilt Angle...

Travel Limits / Defined Axis Position

17719 17729 17720

Convert to mm. Convert to in. 17721 17730 17722

Defined position: 0.0 in. 1000.0 in.

Minimum limit: -1000.0 in. 17721 17730 17722

Maximum limit: 1000.0 in. 17721 17730 17722

Rapid/Reverse Rate

From Machine 17924

500.0 in./min. Convert to mm/min. 17925 12700.0 mm/min. Convert to in./min.

17924

17925

17721 17730 17722

Tilt Angle (Linear Axis)

Physical Motion

Axis Tilt Angle

17393 Tilt axis about: Y 17394

17395 Tilt angle: 0.0 deg.

17393 17394 17395



Linear axis parameters (programmed motion)

Machine Component Manager - Linear Axis

Name: Lathe Upper Turret X Axis 17201

Parameters Geometry Position/Orientation On Machine

Machine coordinate: X 17391 Axis label (absolute coordinates): X 17390 Axis label (incremental coordinates): X 17923

Output coordinate as a diameter

Axis Motion

Programmed Motion

Programmed axis motion = Physical axis motion

Current Axis Motion Parameters: Physical axis (radio button) Programmed axis (radio button)

Positive axis direction: (World coordinate system)

17950

Click on desired axis to select.

Tilt Angle... (button)

Rapid Traverse Rate

From Machine 17924 0.0 in./min. Convert to mm/min. 17925 0.0 mm/min. Convert to in./min.

Travel Limits / Defined Axis Position

17723 Minimum limit: 0.0 in. 17929 Defined position: 0.0 in. 17724 Maximum limit: 0.0 in.

17725 17930 17726

Tilt Angle (Linear Axis)

Programmed Motion

Axis Tilt Angle

17926 Tilt axis about: X 17927 Z

17928 Tilt angle: 0.0 deg.

Checkmark, X, and question mark buttons



Rotary axis parameters

Machine Component Manager - Rotary Axis

Name: VMC A Axis **17201**

Parameters **Geometry** Position/Orientation On Machine

Machine coordinate: **A** 17398 Axis label (absolute coordinates): **A** 17397 Axis label (incremental coordinates): **A** 17932

World coordinate system
Axis of rotation: **17399 +z**
0 deg. position: **17401 +z**

Direction: **17402**
CCW (counter-clockwise) CW (clockwise)

Center of Rotation:
X: 0.0 **17210**
Y: 0.0 **17211**
Z: 0.0 **17212**

Click on desired axis to select.

Tilt Angle... Defined angle (from 0 deg.): 0.0 **17847** deg.

Travel Limits (from 0 deg.)
17723 Minimum travel limit: -360000.0 deg.
17724 Maximum travel limit: 360000.0 deg.
17406 Minimum reposition angle: -36000.0 deg.
17407 Maximum reposition angle: 36000.0 deg.


Maximum Feed Rate
From Machine
Maximum feed rate: 2000.0 deg./min. **17933**

Break Motion
 Break rotary motion **17411**
 Use chordal deviation **17412**
Maximum rotary move: 6.283185 deg. **17413**


Tilt Angle (Rotary Axis)
Axis Tilt Angle
17403 Tilt axis about: **Y** **17404**
17405 Tilt angle: 0.0 deg.


Fixed/Continuous Positioning
 Axis positions to fixed angles only **17408**
Index increment: 0.0 **17409**
 Axis supports continuous positioning
Continuous Axis Type
 Signed continuous **17410**
 Signed direction, absolute angle (0-360 deg.)
 Shortest direction, absolute angle (0-360 deg.)





Tool spindle parameters


Tool component parameters




Router spindle parameters

Router spindle position

Router piggyback spindle parameters

Router piggyback spindle position

Wire guide parameters



Machine definition: list of parameters

General machine information

CNC_MACHINE_TYPE

- | | |
|-------|--|
| 17001 | Machine type (mill / lathe) |
| 17002 | Is this a VTL? (lathe only) |
| 17003 | Default lathe WCS (None/Top/LatheZ=WorldZ) |

MULTIAIX_MOTION_TYPE

Multi-axis motion control

MACHINE_DYNAMIC_S_TYPE

Machine dynamics information for high-feed machining and operation timing calculations

AXIS_FEEDRATE_TYPE PE004

Global machine axis feedrates

AXIS_FEEDRATE_TYPE PE005

Global machine axis feedrates

17920	Maximum linear feedrate (inch) (New for X3)
17921	Maximum linear feedrate (mm) (New for X3)
17922	Maximum rotary feedrate (New for X3)
17004	Use machine feed/min, feed/rev
17005	Use machine deg/min
17006	<i>Use machine inverse time values (removed for X3)</i>
AXIS_FEEDRATE_TY PE006	Toolpath operation feedrate limits - inch, mm deg/min & inverse time are not used...
AXIS_FEEDRATE_TY PE007	Toolpath operation feedrate limits - inch, mm deg/min & inverse time are not used...
COOLANT_TYPE	Coolant
17007	Control definition file
17008	Post-processor file
17009	Tool library files (inch), doctored
17010	Tool library files (mm), doctored
17011	Material library file (inch, -9999, mm)
17012	Comment to describe the machine
17013	Name of tool bar state to load with machine
17014	Use the toolbar state (True/False)
17015	Entity ID number for the cnc machine entity (this one!)
17016	Entity ID number of related control definition
17017	<i>Entity ID number of machine base component entity (removed for X3)</i>
17018	Entity ID number of 1st component group entity
17019	Entity ID number of 1st machine reference position
17020	Entity ID number of list of axis combination entities
17021	Entity ID number of list of machining modes
17675	Insert catalog file
17676	Insert catalog file
17677	Holder catalog file
17678	Holder catalog file
17703	Maximum wire taper angle (degrees)
General component information	Default construction plane
17814	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces. Each one has its own parameter ID.
17815	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17816	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17817	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.



17818	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17819	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17820	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17821	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17822	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17823	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17824	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17825	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17826	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17827	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17828	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17829	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17830	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17831	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17832	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17833	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17834	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.





17835	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17836	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17837	A segment of the unique identifier for this machine. This is a 192-bit number broken up into 24 pieces, 17814–17837.
17839	True = machine supports RTCP (rotation tool center point) programming
17913	Switch to automatically load tools (new for X3)
17914	Machine version (new for X3)

MACHINE_POSITION

17599	Name: used to identify tool changer and machine reference positions
17600	Data source: USER_DEFINED, etc. vs. MACHINE_REF_POS
17601	Control definition reference return code (G28, etc.) index
AXIS_POSITIONS	User positions for each of the axes
17602	Machine reference position list index
ENT_IDN_TYPE	ent_idns of this and related entities in database

MULTIAX_MOTION_TYPE

17022	Break combined rotary axis motion (True/False)
17023	Maximum combined angle before break is required

AXIS_POSITIONS

AXIS_COORD	X axis motion
AXIS_COORD001	Y axis motion
AXIS_COORD002	Z axis motion
AXIS_COORD003	A axis motion
AXIS_COORD004	B axis motion
AXIS_COORD005	C axis motion

ENT_IDN_TYPE

17253	This entity
17254	Next sibling entity
17255	Previous sibling entity
17256	1 st child entity

ENT_IDN_TYPE001

17257	This entity
17258	Next sibling entity
17259	Previous sibling entity
17260	1 st child entity

ENT_IDN_TYPE002

17261	This entity
17262	Next sibling entity
17263	Previous sibling entity
17264	1 st child entity

**ENT_IDN_TYPE003**

17265	This entity
17266	Next sibling entity
17267	Previous sibling entity
17268	1 st child entity

AXIS_COORD

17603	X coordinate value
17604	Type: ABS_TOOL_COORD, INC_TOOL_COORD, etc.

AXIS_COORD001

17936	Y coordinate value
17937	Type: ABS_TOOL_COORD, INC_TOOL_COORD, etc.

AXIS_COORD002

17938	Z coordinate value
17939	Type: ABS_TOOL_COORD, INC_TOOL_COORD, etc.

AXIS_COORD003

17940	A coordinate value
17941	Type: ABS_TOOL_COORD, INC_TOOL_COORD, etc.

AXIS_COORD004

17942	B coordinate value
17943	Type: ABS_TOOL_COORD, INC_TOOL_COORD, etc.

AXIS_COORD005

17944	C coordinate value
17945	Type: ABS_TOOL_COORD, INC_TOOL_COORD, etc.

GROUP_VIEW

17704	View ID number (X2)
17705	View number (X2)
17706	Lathe Cplane coordinate (X2)
17707	Toolplane view matrix (X2)
17708	Toolplane view matrix (X2)
17709	Toolplane view matrix (X2)
17710	Toolplane view matrix (X2)
17711	Toolplane view matrix (X2)
17712	Toolplane view matrix (X2)
17713	Toolplane view matrix (X2)

17714	Toolplane view matrix (X2)
17715	Toolplane view matrix (X2)
17716	View origin in world (X2)
17717	View origin in world (X2)
17718	View origin in world (X2)



Machine dynamics

MACHINE_DYNAMICS_TYPE

Parameters taken from HighFeed:

17024	Maximum change in feedrate to recombine segments (%)
17025	Look-ahead as a percentage of tool diameter
17026	Maximum feedrate change per block (inch/min)
17027	Maximum feedrate change per block (mm/min)
17029	Segment length as % of tool diameter
17030	Minimum change in direction to slow down to min_corner_fr
17031	Feedrate to slow down to at sharp corners (inch/min)
17032	Feedrate to slow down to at sharp corners (mm/min)
17033	Test diameter
17034	Cornering acceleration

Group dynamic information, NOT from HighFeed

17035	Timing increment for MT sync-list (Future Use)
17036	Machine motion acceleration value (in/min^2)
17037	Machine motion acceleration value (mm/min^2)

Axis feedrate limits

There are 8 groups of parameters. Each group has the same parameters, but each group is applied to a different area. Most of these groups have been removed from Mastercam X3. These are included only for reference for your older posts. Only the last two are still used

Table 1: Parameter groups for axis feedrate limits

Where used	Parameter group name
Linear axis properties (inch)	AXIS_FEEDRATE_TYPE (removed for X3)
Linear axis properties (mm)	AXIS_FEEDRATE_TYPE001 (removed for X3)
Rotary axis properties (inch)	AXIS_FEEDRATE_TYPE002 (removed for X3)
Rotary axis properties (mm)	AXIS_FEEDRATE_TYPE003 (removed for X3)

Table 1: Parameter groups for axis feedrate limits

Where used	Parameter group name
Machine axis feedrate limits (inch)	AXIS_FEEDRATE_TYPE004 (removed for X3)
Machine axis feedrate limits (mm)	AXIS_FEEDRATE_TYPE005 (removed for X3)
Operation feedrate limits (inch)	AXIS_FEEDRATE_TYPE006
Operation feedrate limits (mm)	AXIS_FEEDRATE_TYPE007

**AXIS_FEEDRATE_TYPE**

17642	<i>Minimum feed per minute (entire group removed for X3)</i>
17643	<i>Maximum feed per minute</i>
17644	<i>Minimum feed per revolution</i>
17645	<i>Maximum feed per revolution</i>
17646	<i>Minimum inverse feed rate</i>
17647	<i>Maximum inverse feed rate</i>
17648	<i>Minimum degrees per minute</i>
17649	<i>Maximum degrees per minute</i>

AXIS_FEEDRATE_TYPE001

17650	<i>Minimum feed per minute (entire group removed for X3)</i>
17651	<i>Maximum feed per minute</i>
17652	<i>Minimum feed per revolution</i>
17653	<i>Maximum feed per revolution</i>
17654	<i>Minimum inverse feed rate</i>
17655	<i>Maximum inverse feed rate</i>
17656	<i>Minimum degrees per minute</i>
17657	<i>Maximum degrees per minute</i>

AXIS_FEEDRATE_TYPE002

17658	<i>Minimum feed per minute (entire group removed for X3)</i>
17659	<i>Maximum feed per minute</i>
17660	<i>Minimum feed per revolution</i>
17661	<i>Maximum feed per revolution</i>
17662	<i>Minimum inverse feed rate</i>
17663	<i>Maximum inverse feed rate</i>
17664	<i>Minimum degrees per minute</i>
17665	<i>Maximum degrees per minute</i>

AXIS_FEEDRATE_TYPE003

17666	<i>Minimum feed per minute (entire group removed for X3)</i>
17667	<i>Maximum feed per minute</i>
17668	<i>Minimum feed per revolution</i>
17669	<i>Maximum feed per revolution</i>



17670	<i>Minimum inverse feed rate</i>
17671	<i>Maximum inverse feed rate</i>
17672	<i>Minimum degrees per minute</i>
17673	<i>Maximum degrees per minute</i>

AXIS_FEEDRATE_TYPE004

17038	<i>Minimum feed per minute (entire group removed for X3)</i>
17039	<i>Maximum feed per minute</i>
17040	<i>Minimum feed per revolution</i>
17041	<i>Maximum feed per revolution</i>
17042	<i>Minimum inverse feed rate</i>
17043	<i>Maximum inverse feed rate</i>
17044	<i>Minimum degrees per minute</i>
17045	<i>Maximum degrees per minute</i>

AXIS_FEEDRATE_TYPE005

17046	<i>Minimum feed per minute (entire group removed for X3)</i>
17047	<i>Maximum feed per minute</i>
17048	<i>Minimum feed per revolution</i>
17049	<i>Maximum feed per revolution</i>
17050	<i>Minimum inverse feed rate</i>
17051	<i>Maximum inverse feed rate</i>
17052	<i>Minimum degrees per minute</i>
17053	<i>Maximum degrees per minute</i>

AXIS_FEEDRATE_TYPE006

17054	<i>Minimum feed per minute</i>
17055	<i>Maximum feed per minute</i>
17056	<i>Minimum feed per revolution</i>
17057	<i>Maximum feed per revolution</i>
17058	<i>Minimum inverse feed rate</i>
17059	<i>Maximum inverse feed rate</i>
17060	<i>Minimum degrees per minute</i>
17061	<i>Maximum degrees per minute</i>

AXIS_FEEDRATE_TYPE007

17062	<i>Minimum feed per minute</i>
17063	<i>Maximum feed per minute</i>
17064	<i>Minimum feed per revolution</i>
17065	<i>Maximum feed per revolution</i>
17066	<i>Minimum inverse feed rate</i>
17067	<i>Maximum inverse feed rate</i>
17068	<i>Minimum degrees per minute</i>
17069	<i>Maximum degrees per minute</i>

Axis combination info

AXIS_COMBO



17683	Entity ID of axis combination (New for X3)
17684	ID of first component in axis combo (closest to base) (New for X3)
17685	ID of next component in axis combo. (New for X3)
17686	ID of next component in axis combo. (New for X3)
17687	ID of next component in axis combo. (New for X3)
17688	ID of next component in axis combo. (New for X3)
17689	ID of next component in axis combo. (New for X3)
17690	ID of next component in axis combo. (New for X3)
17691	ID of next component in axis combo. (New for X3)
17692	ID of next component in axis combo. (New for X3)
17693	ID of next component in axis combo. (New for X3)
17694	ID of next component in axis combo. (New for X3)
17695	ID of next component in axis combo. (New for X3)
17696	Axis combination user description (New for X3)

General component information

Component header

19958	Component type (numeric) (New for X3)
19959	Component ID (numeric) (New for X3)
19960	Component type (string) (New for X3)

MACHINE_COMPONENT_TYPE

17201	Component name
17202	Component group id
17203	Type of component (machine base, chuck, turret, etc)
17204	Color to draw component
17205	Minimum linear/rotational travel limits (in(mm)/rad) Deleted in X2
17206	Maximum linear/rotational travel limits (in(mm)/rad) Deleted in X2
17207	Reference point on component in world coordinates
17208	Reference point on component in world coordinates
17209	Reference point on component in world coordinates



17210	Point on component which is actually positioned in the NC program (world coordinates)
17211	Point on component which is actually positioned in the NC program (world coordinates)
17212	Point on component which is actually positioned in the NC program (world coordinates)
17213	Position of reference point with component on machine at initial position in world coordinates
17214	Position of reference point with component on machine at initial position in world coordinates
17215	Position of reference point with component on machine at initial position in world coordinates
17216	Transformation matrix to put component on machine at initial position
17217	Transformation matrix to put component on machine at initial position
17218	Transformation matrix to put component on machine at initial position
17219	Transformation matrix to put component on machine at initial position
17220	Transformation matrix to put component on machine at initial position
17221	Transformation matrix to put component on machine at initial position
17222	Transformation matrix to put component on machine at initial position
17223	Transformation matrix to put component on machine at initial position
17224	Transformation matrix to put component on machine at initial position
17225	Transformation matrix to put component at current NC position = initXform initially
17226	Transformation matrix to put component at current NC position = initXform initially



	17227	Transformation matrix to put component at current NC position = initXform initially
	17228	Transformation matrix to put component at current NC position = initXform initially
	17229	Transformation matrix to put component at current NC position = initXform initially
	17230	Transformation matrix to put component at current NC position = initXform initially
	17231	Transformation matrix to put component at current NC position = initXform initially
	17232	Transformation matrix to put component at current NC position = initXform initially
	17233	Transformation matrix to put component at current NC position = initXform initially
	17234	Current position of anchorPt (world coordinates) = anchorPt at start of program most of the time...
	17235	Current position of anchorPt (world coordinates) = anchorPt at start of program most of the time...
	17236	Current position of anchorPt (world coordinates) = anchorPt at start of program most of the time...
	17764	Chord tolerance for MachineWorks polygons. (X2)
	17765	Transparency setting. (X2)
	17766	String ID for the component. This is unique for each component. Example: 69D20EEB-02E7-11DC-B46A-444553544200 (new for X3)
	17767–17788	<i>A segment of the unique component group identifier. This is a 192-bit number broken up into 24 pieces. (removed for X3)</i>
ENT_IDN_TYPE001		
	17237	Entity id number of owner machine
	17451	Don't show this component in simulation (True/False)
	17238	Component is expanded state in dialogs: bit 0 - MDM dialog bit 1 - axis combination dialog remaining bits -> future expansion (Turret Mgr, etc)

17239	Type of geometry used to define the component SOLID_COMPONENT BLOCK_COMPONENT CYLINDER_COMPONENT EXTRUDED_COMPONENT REVOLVED_COMPONENT STOCK_COMPONENT_TYPE MISC_COMPONENT_TYPE MACHINE_BASE_COMPONENT_TYPE LINEAR_AXIS_COMPONENT_TYPE ROTARY_AXIS_COMPONENT_TYPE RECT_TABLE_COMPONENT_TYPE ROUND_TABLE_COMPONENT_TYPE WIRE_TABLE_COMPONENT_TYPE VISE_JAW_COMPONENT_TYPE VISE_COMPONENT_TYPE CHUCKJAWS_COMPONENT_TYPE CHUCK_COMPONENT_TYPE COLLET_COMPONENT_TYPE GUIDE_BUSHING_COMPONENT_TYPE LATHE_CENTER_COMPONENT_TYPE TAILSTOCK_COMPONENT_TYPE STEADYREST_COMPONENT_TYPE TOOL_COMPONENT_TYPE WIRE_UPPER_GUIDE_COMPONENT_TYPE WIRE_LOWER_GUIDE_COMPONENT_TYPE DRILL_BLOCK_STATION_COMPONENT_TYPE MULTI_HEAD_COMPONENT_TYPE MH_PIGGYBACK_COMPONENT_TYPE ATC_COMPONENT_TYPE TOOL_SPINDLE_COMPONENT_TYPE TURRET_COMPONENT_TYPE MULTI_TOOL_COMPONENT_TYPE	(X3) (X3) (X3) (X3) (X3) (X3) (for future use) (for future use) (X3) (X3) (for future use) (for future use) (for future use) (for future use) (for future use) (for future use) (X3) Renamed from CHUCK_JAW_COMPONENT_TYPE (X2) (X3) (X3) (for future use) (X3) Renamed from TAILSTOCK_CENTER_COMPONENT_TYPE (X2) (X3) (X3) (X3) (X3) (X3) (X3) (X3) (X3) (X3) (X3) (X3) (X3) (X3) (X3)
		(Future Use)



COMPONENT_GROUP_TYPE

17789–17812	<i>A segment of the unique component group identifier. This is a 192-bit number broken up into 24 pieces. (no longer used)</i>
-------------	--

**Solid geometry properties****SOLID_COMPONENT**

17268	Entity ID of solid (new for X3)
17269	Solid geometry file (new for X3)
17270	STL file for solid (new for X3)

SOLID_COMPONENT_01

17271	Entity ID of solid (new for X3)
17272	Solid geometry file (new for X3)
17273	STL file for solid (new for X3)

SOLID_COMPONENT_02

17274	Entity ID of solid (new for X3)
17275	Solid geometry file (new for X3)
17276	STL file for solid (new for X3)

Block geometry properties**BLOCK_COMPONENT**

17277	Length of block (new for X3)
17278	Width of block (new for X3)
17279	Height of block (new for X3)
17280	Base point (X) (new for X3)
17281	Base point (Y) (new for X3)
17282	Base point (Z) (new for X3)

BLOCK_COMPONENT_01

17283	Length (new for X3)
17284	Width (new for X3)
17285	Height (new for X3)
17286	Base point (X) (new for X3)
17287	Base point (Y) (new for X3)
17288	Base point (Z) (new for X3)

BLOCK_COMPONENT_02

17289	Length (new for X3)
17290	Width (new for X3)
17291	Height (new for X3)
17292	Base point (X) (new for X3)

17293	Base point (Y) (new for X3)
17294	Base point (Z) (new for X3)



Cylinder geometry properties

CYLINDER_COMPONENT

17295	Outer radius of cylinder (Note: This is a radius value, but the entry field on the dialog box is a diameter value.) (new for X3)
17296	Length of cylinder (new for X3)
17297	Axis orientation vector (X) (new for X3)
17298	Axis orientation vector (Y) (new for X3)
17299	Axis orientation vector (Z) (new for X3)
17300	Base point (X) (new for X3)
17301	Base point (Y) (new for X3)
17302	Base point (Z) (new for X3)
17841	Inner radius of cylinder (Note: This is a radius value, but the entry field on the dialog box is a diameter value.) (new for X3)

CYLINDER_COMPONENT_01

17303	Outer radius of cylinder (Note: This is a radius value, but the entry field on the dialog box is a diameter value.) (new for X3)
17304	Length of cylinder (new for X3)
17305	Axis orientation vector (X) (new for X3)
17306	Axis orientation vector (Y) (new for X3)
17307	Axis orientation vector (Z) (new for X3)
17308	Base point (X) (new for X3)
17309	Base point (Y) (new for X3)
17310	Base point (Z) (new for X3)
17842	Inner radius of cylinder (Note: This is a radius value, but the entry field on the dialog box is a diameter value.) (new for X3)

CYLINDER_COMPONENT_02

17311	Outer radius of cylinder (Note: This is a radius value, but the entry field on the dialog box is a diameter value.) (new for X3)
17312	Length of cylinder (new for X3)
17313	Axis orientation vector (X) (new for X3)
17314	Axis orientation vector (Y) (new for X3)
17315	Axis orientation vector (Z) (new for X3)
17316	Base point (X) (new for X3)
17317	Base point (Y) (new for X3)
17318	Base point (Z) (new for X3)

17843	Inner radius of cylinder (Note: This is a radius value, but the entry field on the dialog box is a diameter value.) (new for X3)
-------	--

CYLINDER_COMPONENT_03

17319	Outer radius of cylinder (Note: This is a radius value, but the entry field on the dialog box is a diameter value.) (new for X3)
17320	Length of cylinder (new for X3)
17321	Axis orientation vector (X) (new for X3)
17322	Axis orientation vector (Y) (new for X3)
17323	Axis orientation vector (Z) (new for X3)
17324	Base point (X) (new for X3)
17325	Base point (Y) (new for X3)
17326	Base point (Z) (new for X3)
17844	Inner radius of cylinder (Note: This is a radius value, but the entry field on the dialog box is a diameter value.) (new for X3)

CYLINDER_COMPONENT_04

17327	Outer radius of cylinder (Note: This is a radius value, but the entry field on the dialog box is a diameter value.) (new for X3)
17328	Length of cylinder (new for X3)
17329	Axis orientation vector (X) (new for X3)
17330	Axis orientation vector (Y) (new for X3)
17331	Axis orientation vector (Z) (new for X3)
17332	Base point (X) (new for X3)
17333	Base point (Y) (new for X3)
17334	Base point (Z) (new for X3)
17845	Inner radius of cylinder (Note: This is a radius value, but the entry field on the dialog box is a diameter value.) (new for X3)

CYLINDER_COMPONENT_05

17335	Outer radius of cylinder (Note: This is a radius value, but the entry field on the dialog box is a diameter value.) (new for X3)
17336	Length of cylinder (new for X3)
17337	Axis orientation vector (X) (new for X3)
17338	Axis orientation vector (Y) (new for X3)
17339	Axis orientation vector (Z) (new for X3)
17340	Base point (X) (new for X3)
17341	Base point (Y) (new for X3)
17342	Base point (Z) (new for X3)
17846	Inner radius of cylinder (Note: This is a radius value, but the entry field on the dialog box is a diameter value.) (new for X3)



Extruded profile geometry properties



EXTRUDED_COMPONENT

17343	Extrude profile entity ID (new for X3)
17344	Extrude direction vector (X) (new for X3)
17345	Extrude direction vector (Y) (new for X3)
17346	Extrude direction vector (Z) (new for X3)
17347	Extrude distance (new for X3)

EXTRUDED_COMPONENT_01

17349	Extrude profile entity ID (new for X3)
17350	Extrude direction vector (X) (new for X3)
17351	Extrude direction vector (Y) (new for X3)
17352	Extrude direction vector (Z) (new for X3)
17353	Extrude distance (new for X3)

EXTRUDED_COMPONENT_02

17354	Extrude profile entity ID (new for X3)
17355	Extrude direction vector (X) (new for X3)
17356	Extrude direction vector (Y) (new for X3)
17357	Extrude direction vector (Z) (new for X3)
17358	Extrude distance (new for X3)

Revolved profile geometry properties

REVOLVED_COMPONENT

17359	Revolve profile entity ID (new for X3)
17360	Line of revolution, endpoint 1 (X) (new for X3)
17361	Line of revolution, endpoint 1 (Y) (new for X3)
17362	Line of revolution, endpoint 1 (Z) (new for X3)
17363	Line of revolution, endpoint 2 (X) (new for X3)
17364	Line of revolution, endpoint 2 (Y) (new for X3)
17365	Line of revolution, endpoint 2 (Z) (new for X3)

REVOLVED_COMPONENT_01

17366	Revolve profile entity ID (new for X3)
17367	Line of revolution, endpoint 1 (X) (new for X3)
17368	Line of revolution, endpoint 1 (Y) (new for X3)
17369	Line of revolution, endpoint 1 (Z) (new for X3)
17370	Line of revolution, endpoint 2 (X) (new for X3)
17371	Line of revolution, endpoint 2 (Y) (new for X3)
17372	Line of revolution, endpoint 2 (Z) (new for X3)

**REVOLVED_COMPONENT_02**

17373	Revolve profile entity ID (new for X3)
17374	Line of revolution, endpoint 1 (X) (new for X3)
17375	Line of revolution, endpoint 1 (Y) (new for X3)
17376	Line of revolution, endpoint 1 (Z) (new for X3)
17377	Line of revolution, endpoint 2 (X) (new for X3)
17378	Line of revolution, endpoint 2 (Y) (new for X3)
17379	Line of revolution, endpoint 2 (Z) (new for X3)

Stock component

This section describes parameters for cylindrical bar stock.

- Stock margin parameters are output with the machine group parameters, **BARSTOCK_TYPE**.
- Stock geometry parameters for other stock models is output using the standard component geometry parameters: for example, **REVOLVED_COMPONENT**.

STOCK_COMPONENT_TYPE**BARSTOCK_GEO_TYPE****BARSTOCK_GEO_TYPE****TUBE_GEO_TYPE**

17380	Ref position at max Z (new for X3)
17381	Use margins? (new for X3)
17382	Hole in stock? (new for X3)
17383	OD margin (new for X3)
17384	ID margin (new for X3)
17385	Left margin (new for X3)
17386	Right margin (new for X3)

TUBE_GEO_TYPE**CYLINDER_COMPON
ENT**

17387	Inner radius (new for X3)
-------	------------------------------------

TUBE_GEO_TYPE_01**CYLINDER_COMPON
ENT**

17388	Inner radius (new for X3)
-------	------------------------------------

TUBE_GEO_TYPE_02**CYLINDER_COMPON
ENT**

17389

Inner radius (**new for X3**)**Linear axis component****LINEAR_AXIS_COMPONENT_TYPE****AXIS_PARAMS_TYPE****AXIS_PARAMS_TYPE
001**

17390

Parameters for direction of physical axis

Parameters for direction of programmed axis (when different from physical axis direction).

17391

Axis label to be output in the NC program for absolute axis motion.

17391

Axis to drive on the machine. 1, 2, 3, or -1, corresponding to X_AXIS, Y_AXIS, Z_AXIS, MACRO_AXIS.

17923

Axis label to be output in the NC program for incremental axis motion. (**New for X3**)

17924

Rapid traverse rate limit (inch) (**New for X3**)

17925

Rapid traverse rate limit (mm) (**New for X3**)

17396

Axis is output as diameter (X & Y only) (True/False)

17951

1 = the **Define macro-driven axis feed rate** option is selected. This enables the feed rate option for axis motion events (MT only). (**new for X4**)**AXIS_PARAMS_TYPE**

[these parameters are used to describe physical axis motion]

17392

Base axis direction with relation to the WCS: X_AXIS, Y_AXIS, Z_AXIS, NEG_X_AXIS, NEG_Y_AXIS, NEG_Z_AXIS (**new for X3**)

17393

Tilt the machine axis (True/False)

17394

Tilt axis: Axis of rotation for axis out of plane (WCS axis!); X_AXIS,-9999, Y_AXIS, Z_AXIS, NEG_X_AXIS,-9999, NEG_Y_AXIS, NEG_Z_AXIS

17395

Tilt angle: Angle of rotation for tilt,-9999, right hand rule (degrees)

inch travel limits

**TRAVEL_LIMITS_TYP
E****TRAVEL_LIMITS_TYP
E001**

17729

Initial defined axis position (measured along the axis) (inch)

17730

Initial defined axis position (measured along the axis) (mm)

17731

Start-up axis position for simulation

AXIS_PARAMS_TYPE001

	[these parameters are used to describe programmed axis motion, where different from physical]
17950	Base axis direction with relation to the WCS: X_AXIS, Y_AXIS, Z_AXIS, NEG_X_AXIS, NEG_Y_AXIS, NEG_Z_AXIS (new for X3)
17926	Tilt the machine axis (True/False) (new for X3)
17927	Tilt axis: Axis of rotation for axis out of plane (WCS axis!); X_AXIS,-9999, Y_AXIS, Z_AXIS, NEG_X_AXIS,-9999, NEG_Y_AXIS, NEG_Z_AXIS (new for X3)
17928	Tilt angle: Angle of rotation for tilt,-9999, right hand rule (degrees) (new for X3)
TRAVEL_LIMITS_TYPE002	inch travel limits (new for X3)
TRAVEL_LIMITS_TYPE003	mm travel limits (new for X3)
17929	Initial defined axis position (measured along the axis) (inch) (new for X3)
17930	Initial defined axis position (measured along the axis) (mm) (new for X3)
17931	Initial position for simulation (G28) (new for X3)

TRAVEL_LIMITS_TYPE

17719	Minimum travel limit (physical motion) (inch) (New for X3)
17720	Maximum travel limit (physical motion) (inch) (New for X3)

TRAVEL_LIMITS_TYPE001

17721	Minimum travel limit (physical motion) (mm) (New for X3)
17722	Maximum travel limit (physical motion) (mm) (New for X3)

TRAVEL_LIMITS_TYPE002

17723	Minimum travel limit (programmed motion) (inch). Also, rotary axis minimum travel limit. (New for X3)
17724	Maximum travel limit (programmed motion) (inch). Also, rotary axis maximum travel limit. (New for X3)

TRAVEL_LIMITS_TYPE003

17725	Minimum travel limit (programmed motion) (mm) (New for X3)
-------	---

17726	Maximum travel limit (programmed motion) (mm) (New for X3)
-------	--

**TRAVEL_LIMITS_TYPE004**

17727	Tailstock retracted position (New for X3)
17728	Maximum advanced position of tailstock (New for X3)

Rotary axis component**ROTARY_AXIS_COMPONENT_TYPE**

17397	Axis label to be output in the NC program for absolute axis motion.
17398	Axis to drive on the machine. 1, 2, 3, or -1, corresponding to A_AXIS, B_AXIS, C_AXIS, MACRO_AXIS.
17932	Axis label to be output in the NC program for incremental axis motion. (New for X3)
17933	Maximum feed rate (degrees/minute) (New for X3)
17399	Axis of rotation with respect to machine linear axes
17401	Axis '0 deg' vector with relation to machine axes. Lies in plane perpendicular to axis of rotation
17402	TRUE = CW is positive direction for this axis
17403	Tilted (nutated) machine axis (True/False)
17404	Tilt axis: Axis of rotation for axis out of plane (WCS axis!). X_AXIS,-9999, Y_AXIS, Z_AXIS, NEG_X_AXIS,-9999, NEG_Y_AXIS, NEG_Z_AXIS
17405	Angle of rotation for tilted axis,-9999, right hand rule (degrees)
17406	Minimum reposition angle (degrees)
17407	Maximum reposition angle (degrees)
17408	This an indexing axis (True/False)
17409	Index angle (must divide evenly into 360)
17410	Output type: Signed continuous,-9999, signed direction (0-360 deg), shortest direction (0 - 360 deg)
17411	Break rotary moves (True/False)
17412	Use chordal deviation to determine when to break (True/False)
17413	Maximum angular move before breaking
TRAVEL_LIMITS_TYP E002	
17847	Min/max linear travel limits measured along axis direction (X2)
17848	Defined angle position (initial angle position) (New for X3)
	Initial angle position for simulation (G28) (New for X3)

17952	1 = the Define macro-driven axis feed rate option is selected. This enables the feed rate option for axis motion events (MT only). (new for X4)
-------	---



Machine table

(These parameters for future use.)

RECT_TABLE_COMPONENT_TYPE

TSLOT_GEO_TYPE	
17414	Slot spacing (future use) (New for X3)
17415	Axis direction (future use) (New for X3)
17416	Length (future use) (New for X3)
17417	Width (future use) (New for X3)
17418	Height (future use) (New for X3)
17419	Pocket width (future use) (New for X3)
17420	Pocket height (future use) (New for X3)

TSLOT_GEO_TYPE

17421	Key width (future use) (New for X3)
17422	Key height (future use) (New for X3)
17423	Slot width (future use) (New for X3)
17424	Depth (future use) (New for X3)
17425	Length (future use) (New for X3)

Chuck

CHUCK_COMPONENT_TYPE

17446	Minimum useable spindle RPM
17447	Maximum programmable spindle RPM
17674	<i>Jaw position in X (longitudinal) (removed in X3)</i>
17734	Number of jaws (new for X3)
17934	Jaw position, longitudinal (world X axis) (new for X3)

CHUCK_GEO_TYPE

17849	Automatically set jaw position from channel depth (True/False) (new for X3)
-------	---

CHUCK_GEO_TYPE

17441	OD of chuck (new for X3)
17442	ID of chuck (new for X3)
17443	Thickness of chuck (new for X3)
17444	Channel width (new for X3)
17445	Channel depth (new for X3)

Chuck jaws



CHUCKJAWS_COMPONENT_TYPE

17430	[not used] (new for X3)
17840	Grip length (new for X3)
17435	Grip reference point (Z) (new for X3)
17436	Grip reference point (radius) (new for X3)
17437	Clamping method (new for X3)
17438	Active spindle (new for X3)
17439	Get clamp position from stock? (new for X3)
17440	Grip on maximum diameter? (new for X3)
CHUCKJAW_GEO_TYPE	

CHUCKJAW_GEO_TYPE

17426	Jaw width (new for X3)
17427	Width of step (new for X3)
17428	Thickness of chuck jaw (new for X3)
17732	Parametric profile or chained profile? (new for X3)
17733	Entity ID of chain used for profile (new for X3)
17681	Jaw height (new for X3)
17682	Height of jaw step (new for X3)

Collet

COLLET_COMPONENT_TYPE

TUBE_GEO_TYPE	(new for X3)
----------------------	---------------------

Tailstock

TAILSTOCK_COMPONENT_TYPE

TRAVEL_LIMITS_TYPE	E004	(new for X3)
17737	Tailstock advance/retract feed rate (inch)	(new for X3)
17738	Tailstock advance/retract feed rate (mm)	(new for X3)
17739	Is quill programmable?	(new for X3)
TAILSTOCK_GEO_TYPE		

TAILSTOCK_GEO_TYPE

17551	Quill diameter (new for X3)
17736	Quill length
17552	Amount of quill extension (new for X3)
17553	Length of tailstock block (new for X3)

17554	Width of tailstock block (new for X3)
17555	Height of tailstock block (new for X3)
17556	Height at which quill is mounted on block (new for X3)



Lathe center

LATHE_CENTER_COMPONENT_TYPE

LATHE_CENTER_GEO_TYPE

LATHE_CENTER_GEO_TYPE

17735	Position along axis of tailstock center (new for X3)
17448	Diameter
17449	Point angle (new for X3)
17450	Length of center (new for X3)

Steady rest

STEADYREST_COMPONENT_TYPE

17850	Entity ID of chain used for collision avoidance boundary (new for X3)
	STEADYREST_GEO_TYPE

STEADYREST_GEO_TYPE

17559	(future use) (new for X3)
17560	(future use) (new for X3)
17561	(future use) (new for X3)
17562	(future use) (new for X3)
17740	(future use) (new for X3)
17741	(future use) (new for X3)
17742	(future use) (new for X3)

Tool components

TOOL_COMPONENT_TYPE

TOOL_LOCATION_TYPE

17918	Entity ID of tool geometry (new for X3)
17919	Color of tool holder geometry (new for X3)

TOOL_LOCATION_TYPE

17240	(not currently used)
17241	(not currently used)
17242	(not currently used)

17243	(not currently used)
17851	Number of ATC pocket (new for X3)
17852	Number of turret face/index position (new for X3)
17853	Number of gang tool position (new for X3)
17854	(not currently used)
17855	(not currently used)
17252	(not currently used)
17856	(not currently used)
17857	(not currently used)
17858	(not currently used)
17859	(not currently used)
17860	(not currently used)
17861	(not currently used)
17862	(not currently used)
17863	(not currently used)
17864	(not currently used)
17865	(not currently used)
17935	(not currently used)



Wire upper guide

WIRE_UPPER_GUIDE_COMPONENT_TYPE

17568	Thread time (new for X3)
17570	Align with lower guide? (Y/N) (new for X3)
WIRE_GUIDE_GEO_TYPE	

WIRE_GUIDE_GEO_TYPE

17564	Major radius (new for X3)
17565	Minor radius (new for X3)
17566	Included angle (new for X3)
17567	Cylinder height (new for X3)

Wire lower guide

WIRE_LOWER_GUIDE_COMPONENT_TYPE

WIRE_LOWER_GUIDE_GEO_TYPE

WIRE_LOWER_GUIDE_GEO_TYPE

17697	Major radius (new for X3)
17698	Minor radius (new for X3)
17699	Included angle (new for X3)
17700	Cylinder height (new for X3)

Router spindles (main & piggyback)



MULTI_HEAD_COMPONENT_TYPE

17605	Minimum useable spindle RPM
17606	Maximum programmable spindle RPM
17586	Anchor point/position on machine—X offset
17587	Anchor point/position on machine—Y offset
17588	Anchor point/position on machine—Z offset
17592	Bitwise number containing the heads that are used
17593	Work offset number
17594	Entity ID number of first head
17701	View number (new for X3)

MH_PIGGYBACK_COMPONENT_TYPE

17605	Minimum useable spindle RPM
17606	Maximum programmable spindle RPM
17586	Anchor point/position on machine—X offset
17587	Anchor point/position on machine—Y offset
17588	Anchor point/position on machine—Z offset
17593	Work offset number
17702	View number (new for X3)

Automatic toolchanger

ATC_COMPONENT_TYPE

17596	Index method
17597	Tool change time
17598	Max. number of tools in carousel
17866	Time to index between pockets (new for X3)

MACHINE_POSITION

Mill/live tool spindles

TOOL_SPINDLE_COMPONENT_TYPE

17605	Minimum useable spindle RPM
17606	Maximum programmable spindle RPM
17607	<i>Component id number for associated ATC (removed for X3)</i>
17868	User ID string for associated turret or ATC component (new for X3)
17892	Face or index position of associated turret (new for X3)
17893	Tool transform status (new for X3)

Turret



TURRET_COMPONENT_TYPE

17608	Axis of turret rotation - defines CW/CCW direction for auto-station numbering
17609	Defines direction of tools in indexed position - must be perpendicular to rotaryAxis
17610	Time to index between adjacent stations (sec.)
17611	Number of tool stations defined
17612	Index type: CW, CCW, MINIMIZE
POLYGON_GEO_TYP E	Turret parametric geometry definition (new for X3)
17613	Minimum spindle speed (RPM) for live tools
17614	Maximum spindle speed (RPM) for live tools
17902	Position indexed at start of program (new for X3)
17903	Slant-bed angle (new for X3)
17904	Gauge length in X (cross tools) (new for X3)
17905	Gauge length in Z (face tools) (new for X3)
17906	Use gauge length in X? (new for X3)
17907	Use gauge length in Z? (new for X3)
17908	Tool location radius—default location for mounting tools. (new for X3)

POLYGON_GEO_TYPE

17630	Width (diameter) of turret across flats (New for X3)
17631	Thickness (New for X3)
17632	Number of faces or index positions (New for X3)
17633	Fillet radius (New for X3)

POLYGON_GEO_TYPE001

17634	Width (diameter) of turret across flats (New for X3)
17635	Thickness (New for X3)
17636	Number of faces or index positions (New for X3)
17637	Fillet radius (New for X3)

Gang tool block (lathe)

GANG_TOOL_COMPONENT_TYPE

17946	Minimum spindle speed (RPM) for live tools (new for X3)
17947	Maximum spindle speed (RPM) for live tools (new for X3)
17948	Slant-bed angle (new for X3)

17949 | Turret index position (**new for X3**)

Coolant type

COOLANT_TYPE

17070	Text description for coolant/flushing option 1
17071	Text description for coolant/flushing option 2
17072	Text description for coolant/flushing option 3
17073	Text description for coolant/flushing option 4
17074	Text description for coolant/flushing option 5
17075	Text description for coolant/flushing option 6
17076	Text description for coolant/flushing option 7
17077	Text description for coolant/flushing option 8
17078	Text description for coolant/flushing option 9
17079	Text description for coolant/flushing option 1
17080	Text description for “coolant enabled” state for coolant option 1
17081	Text description for “coolant enabled” state for coolant option 2
17082	Text description for “coolant enabled” state for coolant option 3
17083	Text description for “coolant enabled” state for coolant option 4
17084	Text description for “coolant enabled” state for coolant option 5
17085	Text description for “coolant enabled” state for coolant option 6
17086	Text description for “coolant enabled” state for coolant option 7
17087	Text description for “coolant enabled” state for coolant option 8
17088	Text description for “coolant enabled” state for coolant option 9
17089	Text description for “coolant enabled” state for coolant option 10
17090	Text description for “coolant disabled” state for coolant option 1
17091	Text description for “coolant disabled” state for coolant option 2
17092	Text description for “coolant disabled” state for coolant option 3
17093	Text description for “coolant disabled” state for coolant option 4
17094	Text description for “coolant disabled” state for coolant option 5
17095	Text description for “coolant disabled” state for coolant option 6

17096	Text description for “coolant disabled” state for coolant option 7
17097	Text description for “coolant disabled” state for coolant option 8
17098	Text description for “coolant disabled” state for coolant option 9
17099	Text description for “coolant disabled” state for coolant option 10
17100	Text to be used for Coolant button label on Toolpath parameters page.
17101	1st ‘coolant off’ command shuts off ALL coolant commands on the machine (True/False)
17102	Use coolant commands in post-processor (provided for backward compatibility) (True/False)
17103	Use event list to activate coolant
17104	(not used in X3)



Control definition parameters



See [Capturing control definition parameters](#) on page 34 to learn more about capturing the parameter values in your post.

The first section ([Control definition: visual reference](#)) shows screen captures of all themachine definition dialogs annotated with the parameter numbers. The second section ([Control definition: list of parameters](#) on page 380) lists all of the parameters by group and number.


Control definition: visual reference

Most of the fields shown in the following pages use parameters to store their values, but the values for some fields are available as pre-defined variables, or even directly in the NCI G-code. Use the following color key to determine the type of value:

- Red labels indicate parameter numbers
- Blue labels indicate pre-defined variable names
- Green labels indicate NCI G-codes

Some fields are available as both parameters and pre-defined variables. In these cases, you can use whichever method is most convenient. Typically, this will be the pre-defined variable.

Overall parameters



Tolerance page

Control definition: NONE

Existing definitions: Control type: Mill Manufacturer: NONE
Post processors: Default setting for control type Description: NONE

Control topics:

- Tolerances
 - Mill
 - Communications
 - Files
 - NC Dialog
 - NC Output
 - Misc. Int/Real Values
 - Work System
 - Tool
 - Linear
 - Arc
 - Rotary
 - Feed
 - Cutter Compensation
 - Machine Cycles
 - Subprograms
 - Operation Defaults
 - Text

	Inch	Metric
NC precision (minimum step value)	18077 <input type="checkbox"/> Truncate mtol\$	0.0001 0.0005 0.00005 0.0001 0.0005 0.0005 0.0001 0.0005 0.0005 0.0001 0.0005 0.0001
Chordal deviation (used in post)	chord_tol\$	0.001 0.01 0.001 0.0001
Deviation of 'vector' endpoints for planar detection (used in post)	vert_tol\$	0.0005 0.0001
General math function tolerance (used in post)	xtol\$	0.0005 0.0001
Minimum distance between arc endpoints	ltol\$	0.01 0.001
Minimum arc length	minarc\$	0.01 0.001
Minimum arc radius	minrad\$	999.9999 9999.999
Maximum arc radius	maxrad\$	0.0005 0.0001
Minimum change in arc plane for helix	helix_tol\$	0.0005 0.0001
Maximum deviation in calculated arc endpoints from machine grid	arc_tol\$	0.5 179.5
Minimum angle tolerance in degrees	atol\$	0.001
Maximum angle tolerance in degrees	max_atol\$	

Names of metric variables are the inch names prefixed with "met_"

Tolerances - Set the tolerances used by the Post Processor. NC precision should match the linear precision of the machine tool.



Communications page

Control definition: NONE

Control type: Mill Manufacturer: NONE

Post processors: Default setting for control type

Control topics:

- Tolerances
- Communications
- Mill
- Files
- NC Dialog
- NC Output
- Misc. Int/Real Values
- Work System
- Tool
- Linear
- Arc
- Rotary
- Feed
- Cutler Compensation
- Machine Cycles
- Subprograms
- Operation Defaults
- Text

Communications: Legacy **18111** DOS communications mode **18118**
 Display to screen **18117**

Format	Port	Parity	Data bits	Stop bits
<input checked="" type="radio"/> ASCII 18113	<input checked="" type="radio"/> COM1 18107	<input checked="" type="radio"/> Even 18112	<input type="radio"/> 6 18108	<input type="radio"/> 1 18109
<input type="radio"/> EIA 18113	<input type="radio"/> COM2 18107	<input type="radio"/> Odd	<input type="radio"/> 7	<input checked="" type="radio"/> 2
<input type="radio"/> BIN	<input type="radio"/> COM3	<input type="radio"/> None	<input type="radio"/> 8	

Handshaking: Software **18110**
Baud rate: 9600 **18106**
EOL delay: 0.0 **18105**


Echo terminal emulation **18116**
 Strip carriage return **18114**
 Strip line feed **18115**

Communication - Set the default communications values. Override these from the posting dialog communications button.


  



Files page



NC Dialog page (Mill–Lathe–Router)



NC Output page

Control definition: C:\MCAMX3\CNC_MACHINES\DEFAULT.CONTROL

Existing definitions: Mill Control type: Mill Manufacturer: Generic Default

Post processors: C:\mcamx3\mill\Posts\MPFAN.PST Description: Generic Default

Control topics:

- Tolerances
- Communications
- Files
- NC Dialog
- NC Output
- Mill
- Misc. Int/Real Values
- Work System
- Tool
- Linear
- Arc
- Rotary
- Feed
- Cutter Compensation
- Machine Cycles
- Subprograms
- Operation Defaults
- Text

Main program default absolute/incremental: **absinc\$**

Absolute Incremental

Comments output to NC file

Output operation comments to NC **1008** Output group name to NC **1053** Maximum characters in NC comment: **18458** [256]

Output machine name to NC **1051** Output group comments to NC **1052**

Sequence numbers

Output sequence numbers: **omitseq\$** Use decimal sequence numbers: **use_dec_seq\$**

Start sequence number: **seqno\$** [100.0] Number of places to right of decimal: **dec_seq_right\$** [0]

Increment sequence number: **seqinc\$** [2.0] Number of places to left of decimal: **dec_seq_left\$** [3]

Maximum sequence number: **seqmax\$** [9999.0]

Reset sequence numbers in subprograms: **sub_seq_type\$**

Spaces and End of Block characters

Spaces between NC addresses: **space\$** [1]

Remove CR/LF at the end of the NC block: **omitcrlf\$**

Alternate EOB characters

First alternate EOB character (ASCII value equivalent): **eob\$** [0]

Second alternate EOB character (ASCII value equivalent): **prv_eob\$** [0]

NC Output - This page provides settings to control how comments and sequence numbers are handled by the post. The 'end of block' characters in your NC output are configured here.

Buttons:



Misc. Int/Real Values page



Control definition: C:\mcamx3\CNC_MACHINES\MPPARAMETER.CONTROL

Existing definitions Control type: Mill/Turn Manufacturer: NONE
Post processors: C:\mcamx3\lathe\posts\mpparameter.pst Description: NONE

Control topics:

- Tolerances
- Communications
- Files
- NC Dialog
- NC Output
- Misc. Int/Real Values
- Lathe
- Mill
- Work System
- Tool
- Linear
- Arc
- Rotary
- Feed
- Cutter Compensation
- Machine Cycles
- Subprograms
- Operation Defaults
- Text

Miscellaneous text and values:		mi1\$ - mi10\$	mr1\$ - mr10\$	
		Integers (1-10)	Reals (1-10)	Inch Metric
1.	Misc. Integer [1]	0	1. Misc. Real [1]	0.0 0.0
2.	Misc. Integer [2]	0	2. Misc. Real [2]	0.0 0.0
3.	Misc. Integer [3]	0	3. Misc. Real [3]	0.0 0.0
4.	Misc. Integer [4]	0	4. Misc. Real [4]	0.0 0.0
5.	Misc. Integer [5]	0	5. Misc. Real [5]	0.0 0.0
6.	Misc. Integer [6]	0	6. Misc. Real [6]	0.0 0.0
7.	Misc. Integer [7]	0	7. Misc. Real [7]	0.0 0.0
8.	Misc. Integer [8]	0	8. Misc. Real [8]	0.0 0.0
9.	Misc. Integer [9]	0	9. Misc. Real [9]	0.0 0.0
10.	Misc. Integer [10]	0	10. Misc. Real [10]	0.0 0.0

Initialize toolpath operation **18721**

From post text settings From default operation Set miscellaneous values on first operation of each type only **18722**

Use separate mill and lathe text and values **18723**

Miscellaneous Integer/Real Lathe - Miscellaneous values are for post customization beyond what is available in the product. Set the default values to be used with any special features in the post.

Work System page

Control definition: C:\MCAMX3\CNC_MACHINES\DEFAULT.CONTROL

Existing definitions Control type: Mill Manufacturer: Generic Default

Post processors: C:\mcamx3\mill\Posts\MPFAN.PST Description: Generic Default

Control topics:

- ? Tolerances
- ? Communications
- ? Files
- ? NC Dialog
- ✓ NC Output
- ✓ Misc. Int/Real Values
- ✓ Work System
 - ✓ Mill
 - ? Tool
 - ? Linear
 - ? Arc
 - ? Rotary
 - ? Feed
 - ? Cutter Compensation
 - ? Machine Cycles
 - ? Subprograms
 - ? Operation Defaults
 - ? Text

Work coordinate selection: Work offsets workcoord\$

Tplane during automatic work offset number creation: None tplanemode\$

Translate NCI coordinates to Machine View with aggregate 18507

Work System - Set the type of work system [post supported]. Define how Mastercam handles work offsets.



Tool page (Mill–Router)

Control definition: C:\MCAMX3\CNC_MACHINES\DEFAULT.CONTROL

Control topics:

- ? Tolerances
- ? Communications
- ? Files
- ? NC Dialog
- ✓ NC Output
- ✓ Misc. Int/Real Values
- ✓ Work System
- ✓ Tool
 - ✓ Mill
- ? Linear
- ? Arc
- ? Rotary
- ? Feed
- ? Cutter Compensation
- ? Machine Cycles
- ? Subprograms
- ? Operation Defaults
- ? Text

Tool offset registers

	Length	Diameter
<input checked="" type="radio"/> Add to tool	0 18510	0 18511
<input type="radio"/> From tool	18508	

Tool number options (post)

<input type="checkbox"/> Use the head number to replace the tool number	18514
<input type="checkbox"/> Use the head number to 'add' for the offset registers	18515
<input type="checkbox"/> Enable staged tool routines	18516 bldnxtool\$

Default 'home' position option **18513**

<input checked="" type="radio"/> Get position from operation default setting
<input type="radio"/> Get position from the tool setting
<input type="radio"/> Get position from the Machine Definition

Mill and Router Tool - Set the default for tool and tool registers numbering. Override these from the Toolpath manager group dialog. Enable the preselection of tool. Your post and machine need to be capable of this.



Tool page (Lathe)



Control definition: C:\MCAMX3\CNC_MACHINES\DEFAULT.CONTROL

Existing definitions Control type: Lathe Manufacturer: Generic Default

Post processors: ? Default setting for control type Description: NONE

Control topics:

- ? Tolerances
- ? Communications
- Files
- ? NC Dialog
- ? NC Output
- ? Misc. Int/Real Values
- ? Work System
- Tool
- Lathe
- Linear
- ? Arc
- ? Feed
- ? Cutter Compensation
- ? Machine Cycles
- Subprograms
- Operation Defaults
- ? Text

Tool offset registers
18508 (18761)

Offset	Back offset	Length	Diameter
0 18509 (18762)	30 18512 (18765)	30 18510 (18763)	30 18511 (18764)
<input checked="" type="radio"/> Add to tool			
<input type="radio"/> From tool			

Tool number options (post)

- Write length register to NCI with lathe toolpaths 18517 (18770)
- Use the station number to replace the tool number 18514 (18767)
- Use the station number to 'add' for the offset registers 18515 (18768)
- Enable staged tool routines 18516 (18769)

Default 'home' position option

- Get position from operation default setting 18513 (18766)
- Get position from the tool setting
- Get position from the Machine Definition

NOTE: parameter numbers in () are for Mill/Turn operations

Lathe Tool - Set the default for tool and tool registers numbering. Override these from the Toolpath manager group dialog.

Linear page (Mill–Router)

Control definition: C:\MCAMX3\CNC_MACHINES\DEFAULT.CONTROL

Existing definitions Control type: Mill Manufacturer: Generic Default
Post processors: Default setting for control type Description: NONE

Control topics:

- Tolerances
- Communications
- Files
- NC Dialog
- NC Output
- Misc. Int/Real Values
- Work System
- Tool
- Linear
- Mill
- Arc
- Rotary
- Feed
- Cutter Compensation
- Machine Cycles
- Subprograms
- Operation Defaults
- Text

Automatically set duplicate dialog items the same

Motion control

Rapid Motion

- Each axis moves at maximum feed rate independently **18518**
- All axes arrive at destination simultaneously
- Linear interpolate at maximum feed rate

XY plane control

- Do not break linear motion
- Break rapid moves - XY then Z for approach, Z then XY for retract
- Break all moves with change in Z

XY\$

XZ plane control

- Do not break linear motion
- Break rapid moves - XZ then Y for approach, Y then XZ for retract
- Break all moves with change in Y

XZ\$

YZ plane control

- Do not break linear motion
- Break rapid moves - YZ then X for approach, X then YZ for retract
- Break all moves with change in X

YZ\$

Corner rounding/Exact stop cutmode\$

- Control cutting mode
- Control exact stop mode
- Control corner rounding mode

Mill and Router Linear - Set the way rapid and linear moves are broken based on the plane and tool direction. Rapids not broken in Mastercam are done in the post. Linear moves are broken in the post.



Linear page (Lathe–Mill/Turn–Wire)

Control definition: C:\MCAMX3\CNC_MACHINES\DEFAULT.CONTROL

The dialog box shows the following settings:

- Control type:** Lathe
- Manufacturer:** Generic Default
- Description:** NONE
- Control topics:**
 - Tolerances
 - Communications
 - Files
 - NC Dialog
 - NC Output
 - Misc. Int/Real Values
 - Work System
 - Tool
 - Linear
 - Lathe** (selected)
 - Arc
 - Feed
 - Cutter Compensation
 - Machine Cycles
 - Subprograms
 - Operation Defaults
 - Text

Rapid Motion

- Each axis moves at maximum feed rate independently **18518 (18771)**
- All axes arrive at destination simultaneously
- Linear interpolate at maximum feed rate

Corner rounding/Exact stop

- Control cutting mode **Icutmode\$**
- Control exact stop mode
- Control corner rounding mode

NOTE: Parameter numbers in () are for mill/turn operations
Rapid motion parameters not available for Wire.

Lathe Linear - Set the machine control corner type.

Buttons:



Arc page (Mill–Router–Wire)

Control definition: C:\MCAMX3\CNC_MACHINES\DEFAULT.CONTROL

Existing definitions Control type: Mill Manufacturer: Generic Default
Post processors: Default setting for control type Description: NONE

Control topics:

- Tolerances
- Communications
- Files
- NC Dialog
- NC Output
- Misc. Int/Real Values
- Work System
- Tool
- Linear
- Arc
- Mill
- Rotary
- Feed
- Cutter Compensation
- Machine Cycles
- Subprograms
- Operation Defaults
- Text

Automatically set duplicate dialog items the same

Support arcs in XY plane **do_xy_arcs\$ 18531**

Support arcs in XZ plane **do_xz_arcs\$ 18532**

Support arcs in YZ plane **do_yz_arcs\$ 18533**

Arc center type

XY plane: arctype\$	Radius 18523
XZ plane: arctypexz\$	Radius 18524
YZ plane: arctypeyz\$	Radius 18525

Helix support

No helix allowed **18529 helix_arcs\$**

Only in XY plane

All planes supported

Arc breaks

XY plane do_full_arc\$ 18534	<input checked="" type="checkbox"/> Allow 360 degree arcs 18526 breakarcs\$
Arc break options: Don't break arcs	
XZ plane do_full_arc_xz\$ 18535	<input checked="" type="checkbox"/> Allow 360 degree arcs 18527 breakarcsxz\$
Arc break options: Don't break arcs	
YZ plane do_full_arc_yz\$ 18536	<input checked="" type="checkbox"/> Allow 360 degree arcs 18528 breakarcsyz\$
Arc break options: Don't break arcs	

Arc error checks

<input checked="" type="checkbox"/> Length of arc 18537	arccheck\$
<input type="checkbox"/> Length of radius 18538	
<input checked="" type="checkbox"/> Parallel axis motion on quadrant 18539	
<input type="checkbox"/> Equilateral triangle 18540	
<input checked="" type="checkbox"/> End point checks	
<input checked="" type="radio"/> Round end point - break arc on failure	
<input type="radio"/> Round end point - arc to generated point on failure	
<input type="radio"/> No rounding - break arc on failure 18530	

Mill and Router Arc - Set the arc support for the machine control.



Arc page (Lathe)

Control definition: C:\MCAMX3\CNC_MACHINES\DEFAULT.CONTROL

Control topics:

- ? Tolerances
- ? Communications
- ? Files
- ? NC Dialog
- ? NC Output
- ? Misc. Int/Real Values
- ? Work System
- ? Tool
- ? Linear
- Arc
- Lathe
- ? Feed
- ? Cutter Compensation
- ? Machine Cycles
- ? Subprograms
- ? Operation Defaults
- ? Text

Control type: Lathe **Manufacturer:** Generic Default

Post processors: Default setting for control type

Description: NONE

Control topics:

Support arcs in XY plane **ldoxyarcs\$**

Arc center type: XY plane: Delta start to center **larctype\$**

Arc breaks:

Allow 360 degree arcs **ldo_full_arc\$**

Arc break options: Don't break arcs **lbreakarcs\$**


Arc error checks: **larccheck\$**

<input checked="" type="checkbox"/> Length of arc	18537 (18790)
<input type="checkbox"/> Length of radius	18538 (18791)
<input checked="" type="checkbox"/> Parallel axis motion on quadrant	18539 (18792)
<input type="checkbox"/> Equilateral triangle	18540 (18793)
<input checked="" type="checkbox"/> End point checks	18541 (18794)
<input checked="" type="radio"/> Round end point - break arc on failure <input type="radio"/> Round end point - arc to generated point on failure <input type="radio"/> No rounding - break arc on failure 18530 (18783)	

Lathe and Wire Arc - Set the arc support for the machine control.



Rotary page (Mill–Router–Lathe)



Feed page (Mill–Router)

Control definition: C:\MCAMX3\CNC_MACHINES\DEFAULT.CONTROL

Existing definitions Control type: Mill Manufacturer: Generic Default
Post processors: Default setting for control type Description: NONE

Control topics:

- Tolerances
- Communications
- Files
- NC Dialog
- NC Output
- Misc. Int/Real Values
- Work System
- Tool
- Linear
- Arc
- Rotary
- Feed
- Mill**
- Cutter Compensation
- Machine Cycles
- Subprograms
- Operation Defaults
- Text

3 axis feed options

Unit/min **feedtype3\$**

Use inverse

Inverse

Feedrate in minutes **inversefeed\$**

Feedrate in seconds

4 axis feed options

Linear

Unit/min **feedtype4\$**

Use inverse

Rotary

Unit/min

Degree/min **rotfeed4\$**

Use inverse

5 axis feed options

Linear

Unit/min **feedtype5\$**

Use inverse

Rotary


Unit/min

Use inverse **rotfeed5\$**


Mill and Router Feed - Set the feed support for the machine control.



Feed page (Lathe)



Feed page (Wire)



Cutter Compensation page

Control definition: C:\MCAMX3\CNC_MACHINES\DEFAULT.CONTROL X

 Existing definitions Control type: Mill Manufacturer: Generic Default
Post processors: Default setting for control type Description: NONE

Control topics:

- Tolerances
- Communications
- Files
- NC Dialog
- NC Output
- Misc. Int/Real Values
- Work System
- Tool
- Linear
- Arc
- Rotary
- Feed
- Cutter Compensation
- Mill
- Machine Cycles
- Subprograms
- Operation Defaults
- Text

Control supports cutter compensation in control **18704**
 Number of look ahead NC blocks for cutter compensation on machine control (read by post only): **18703**

Allow cutter compensation in control to be activated/deactivated on arcs (read by post only) **18705**

Control supports wear compensation (negative offset value) **18706**

Control supports reverse wear compensation **18707**

Start and end cutter compensation above part (read by post only) **18708**

Optimize Toolpath **18821**

Cutter Compensation - Set the cutter compensation for the machine control.



Machine Cycles page (Mill–Router–Lathe)

Control definition: C:\vmcamx3\CNC_MACHINES\MP_PARAMETER.CONTROL



Existing definitions Control type: Router Manufacturer: NONE
Post processors: Default setting for control type Description: NONE

Control topics:

- Tolerances
- Communications
- Files
- NC Dialog
- NC Output
- Misc. Int/Real Values
- Work System
- Tool
- Linear
- Arc
- Rotary
- Feed
- Cutter Compensation
- Machine Cycles
- Router
- Router Drill Cycles
- Subprograms
- Operation Defaults
- Text

Drill cycles

Height return options

Return to the initial height **18555**

Return to the reference height

Long code option

Percent of subsequent peck distance with peck and chip: **18556**

Use lead drill with block drilling **18557 bdrl_use_lead\$ (Router only)**

Rotary conversion cycles (read by post only)

Control supports Polar Interpolation **18558**

Control supports Cylindrical Interpolation **18559**

Control high speed machining (read by post only)

Control supports High Speed Machining **18560**

Machine Cycles General - Set the general machine cycle parameters. These are also used with the long code drill cycles produced from the post.

Drill Cycles page (Mill–Router–Lathe)

Control definition: C:\mcamx3\CNC_MACHINES\PARAMETER.CONTROL

Existing definitions Control type: Router Manufacturer: NONE

Post processors: Default setting for control type Description: NONE

Control topics:

- Tolerances
- Communications
- Files
- NC Dialog
- NC Output
- Misc. Int/Real Values
- Work System
- Tool
- Linear
- Arc
- Rotary
- Feed
- Cutter Compensation
- Machine Cycles
- Router
- Router Drill Cycles
- Subprograms
- Operation Defaults
- Text

Check to enable canned drill cycle:

<input checked="" type="checkbox"/> Simple drill - no peck	usecandrill\$	lusecandrill\$
<input checked="" type="checkbox"/> Peck drill - full retract	usecanpeck\$	lusecanpeck\$
<input checked="" type="checkbox"/> Chip break - incremental retract	usecanchip\$	lusecanchip\$
<input checked="" type="checkbox"/> Tapping - feed in, reverse spindle - feed out	usecantap\$	lusecantap\$
<input checked="" type="checkbox"/> Boring #1 - feed out	usecanbore1\$	lusecanbore1\$
<input checked="" type="checkbox"/> Boring #2 - stop spindle - rapid out	usecanbore2\$	lusecanbore2\$
<input checked="" type="checkbox"/> Misc #1 drill - uses simple drill	usecanmisc1\$	lusecanmisc1\$
<input checked="" type="checkbox"/> Misc #2 drill - uses simple drill	usecanmisc2\$	lusecanmisc2\$

NOTE: Mill/Router variable in first column, Lathe variable in second column

Note: Custom drill cycles do not produce long code drilling

Machine Cycles Drill - Select if a drill cycle is to output as a machine control cycle or long hand code.



Lathe Canned Cycles page (Lathe)

Control definition: C:\vmcamx3\CNC_MACHINES\MPPARAMETER.CONTROL

Existing definitions Control type: Mill/Turn Manufacturer: NONE

Post processors: Default setting for control type Description: NONE

Control topics:

- ? Tolerances
- ? Communications
- ? Files
- ? NC Dialog
- ? NC Output
- ? Misc. Int/Real Values
- ? Work System
- ? Tool
- ? Linear
- ? Arc
- Rotary 18598
- Feed 18582
- Cutter Compensation 18583
- Machine Cycles
 - ✓ General
 - ✗ Lathe Drill Cycles
 - ✗ Mill Drill Cycles
 - ✓ Lathe Canned Cy
- Subprograms
- Operation Defaults
- Text

Canned turning cycles

- Enable canned rough turning 18570
- Enable canned rough pattern repeat 18571
- Enable canned roughing undercuts 18572
- Enable canned finish 18573

Threading

- Enable anticipated pulloff for long hand thread
- Enable canned thread cycles
- Enable canned thread cycle
 - Enable thread equal dept 18586
 - Enable thread equal area 18587
 - Enable thread anticipate 18589
 - Enable thread multiple start 18588
 - Multiple first start close 18815
 - Multiple first start far from 18814
- Enable box thread cycle 18584
 - Enable thread equal dept 18590
 - Enable thread equal area 18591
 - Enable thread anticipated 18593
 - Enable thread multiple start 18592
 - Multiple first start closes 18817
 - Multiple first start far from 18816
- Enable alternating thread cycle 18585
 - Enable thread equal depth 18594
 - Enable thread equal area 18595
 - Enable thread anticipated 18597
 - Enable thread multiple start 18596
 - Multiple first start closest 18819
 - Multiple first start far from 18818

Machine Cycles Lathe - Select the lathe canned cycles and level of support provided by your control. The post must support your selections.



Subprograms page

Control definition: C:\MCMAMX3\CNC_MACHINES\DEFAULT.CONTROL



Existing definitions Control type: Mill Manufacturer: Generic Default
Post processors: Default setting for control type Description: NONE

Control topics:

- ? Tolerances
- ? Communications
- ? Files
- ? NC Dialog
- ? NC Output
- ? Misc. Int/Real Values
- ? Work System
- ? Tool
- ? Linear
- ? Arc
- ? Rotary
- ? Feed
- ? Cutter Compensation
- ? Machine Cycles
- Subprograms
- Mill
- ? Operation Defaults
- ? Text

Control supports subprograms **sub_level\$**

Maximum subprogram nesting levels: **18712** 1

Subprogram type

Subprograms after main program **18713**

Subprograms before main program

Mirror/Rotate routines

Allow mirror coordinate subprogram routines **18716**

Allow rotate coordinate subprogram routines **18717**

Allow nesting of mirror/rotate coordinate subprogram routines **18718**

Maximum mirror/rotate coordinate subprogram routines nesting levels: **18714** 1

Comparison

Ignore work offset numbers when processing subprograms **18719**

Ignore contour flags when processing subprograms **18720**

Subprograms - Set the subprogram options for your machine control.

Start/Leads page (Wire)

Control definition: C:\mcamx\CNC_MACHINES\DEFAULT.CONTROL

Control topics:

- ? Tolerances
- ? Communications
- ? Files
- ? NC Dialog
- ? NC Output
- ? Misc. Int/Real Values
- ? Work System
- ? Linear
- ? Arc
- ? Feed
- ? Cutter Compensation
- Start/Leads**
- Wire**
- ? Cuts
- ? Corner
- ? Reverse Cuts Contour
- ? Reverse Cuts Auxiliary
- ? 4 Axis Paths
- ? Nocore
- ? Subprograms
- ? Operation Defaults
- ? Text

Existing definitions: Control type: Wire Manufacturer: Generic Default
Post processors: C:\mcamx\WIRE\POSTS\MPWFANUC.PST Description: NONE

Wire threading: Manual **18605** Automatic

Leads: Start position is automatically set to thread position **18609** Initialize toolpath operation **18608**
 From post text settings From default operation

Lead in type: Line only **18606** Radius only Line and arc Two lines and arc


Lead out type: Line only **18607** Radius only Line and arc Two lines and arc

Line lead in and exit are required **18610**
 Move to arc center with 'two lines and arc' lead option **18611**
 Flip taper direction on leads with 'two lines and arc' lead option **18612**


Wire Start/Lead - Set wire start and lead.

Buttons:

Cuts page (Wire)



Corner page (Wire)



Corner page (Wire)

Control definition: C:\mcamx\CNC_MACHINES\DEFAULT.CONTROL

Existing definitions: Control type: Wire Manufacturer: Generic Default
Post processors: C:\mcamx\WIRE\POSTS\MPWFANUC.PST Description: NONE

Control topics:

- Tolerances
- Communications
- Files
- NC Dialog
- NC Output
- Misc. Int/Real Values
- Work System
- Linear
- Arc
- Feed
- Cutter Compensation
- Start/Leads
- Cuts
- Corner
- Wire
- Reverse Cuts Contour
- Reverse Cuts Auxiliary
- 4 Axis Paths
- Nocore
- Subprograms
- Operation Defaults
- Text

Select the corner options allowed

<input checked="" type="checkbox"/> Conical (minimum)	18615
<input checked="" type="checkbox"/> Conical (mean)	18616
<input checked="" type="checkbox"/> Conical (maximum)	18617
<input checked="" type="checkbox"/> Constant	18618
<input checked="" type="checkbox"/> Fixed	18619
<input checked="" type="checkbox"/> Sharp	18620
<input checked="" type="checkbox"/> Fish tail	18621
<input type="checkbox"/> Other	18622

Enable line-arc-line tangent conic mode (G60 Fanuc) 18623

Enable dual corner types and upper radius with arcs 18624

Wire Corner - Set wire corner options.



Reverse Cuts Contour page (Wire)

Control definition: C:\mcamx\CNC_MACHINES\DEFAULT.CONTROL

Control type: Wire Manufacturer: Generic Default

Post processors: C:\mcamx\WIRE\POSTS\MPWFANUC.PST Description: NONE

Control topics:

?	Tolerances	Change corner type on:	18625	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
?	Communications	Change UV arc type on:	18626	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
?	Files	Change rapid move on:	18627	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
?	NC Dialog	Change feedrate on:	18628	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
?	NC Output	Change manual entry on:	18629	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
?	Misc. Int/Real Values	Change canned text on:	18630	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
?	Work System	Change wire compensation on:	18631	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
?	Linear	Change condition code on:	18632	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
?	Arc	Change wire offset on:	18633	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
?	Feed	Change wire diameter on:	18634	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
?	Cutter Compensation	Change wire overburn on:	18635	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
✓	Start/Leads	Change dwell on:	18636	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
✓	Cuts	Change contour flags on:	18637	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
✓	Corner	Change stop flags on:	18638	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
✓	Reverse Cuts Contour	Change thread/cut flags on:	18639	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
✓	Wire	Change power settings on:	18640	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
?	Reverse Cuts Auxiliary	Change tank settings on:	18641	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point
?	4 Axis Paths	Change flush settings on:	18642	<input checked="" type="radio"/> Point	<input type="radio"/> Move	<input type="radio"/> Prior Point

Wire Reverse Cuts - Set wire reverse wirepath options.

Reverse Cuts Auxiliary page (Wire)

Control definition: C:\mcamx\CNC_MACHINES\DEFAULT.CONTROL

Control type: Wire Manufacturer: Generic Default

Post processors: C:\mcamx\WIRE\POSTS\MPWFANUC.PST Description: NONE

Control topics:

- Tolerances
- Communications
- Files
- NC Dialog
- NC Output
- Misc. Int/Real Values
- Work System
- Linear
- Arc
- Feed
- Cutter Compensation
- Start/Leads
- Cuts
- Corner
- Reverse Cuts Contour
- Reverse Cuts Auxiliary
- Wire
- 4 Axis Paths
- Nocore
- Subprograms
- Operation Defaults
- Text


Change auxiliary register 1 on: **18643** Point Move Prior Point
 Change auxiliary register 2 on: **18644** Point Move Prior Point
 Change auxiliary register 3 on: **18645** Point Move Prior Point
 Change auxiliary register 4 on: **18646** Point Move Prior Point
 Change auxiliary register 5 on: **18647** Point Move Prior Point
 Change auxiliary register 6 on: **18648** Point Move Prior Point
 Change auxiliary register 7 on: **18649** Point Move Prior Point
 Change auxiliary register 8 on: **18650** Point Move Prior Point
 Change auxiliary register 9 on: **18651** Point Move Prior Point
 Change auxiliary register 10 on: **18652** Point Move Prior Point

Modal 18653
 Modal 18654
 Modal 18655
 Modal 18656
 Modal 18657
 Modal 18658
 Modal 18659
 Modal 18660
 Modal 18661
 Modal 18662


Wire Reverse Cuts - Set wire reverse wirepath options for auxiliary settings.



4-Axis Paths page (Wire)



Nocore page (Wire)



Control definition: list of parameters

General control definition parameters

Control definition header

19990 | Machine group name (**New for X3**)

ENT_IDN_CTRL

18001	Post ID
18002	(not used)
18003	(not used)
18004	(not used)

CONTROL_TYPE**ENT_IDN_CTRL**

18010	Manufacturer
18011	Parent group ID
18012	Start unique post ID
18013	Tolerance entity ID
18014	Communication entity ID
18015	File entity ID
18016	Posts entity ID
18017	NC mill entity ID
18018	NC router entity ID
18019	NC lathe entity ID
18020	NC wire entity ID
18021	NC output entity ID
18022	NC path entity ID
18023	NC cycles entity ID
18024	NC wire path entity ID

**FILE_POSTLIST_CTRL**

18205	Post ID
18206	Valid Status
18207	Start ascii entity id
18208	Start binary entity id
18209	Start text entity id
18210	Post data path and file name

Tolerances page**TOLERANCE_CTRL**

18055	NC Precision – Inch (minimum step value - mtol\$)
18056	NC Precision - Metric (minimum step value - met_mtol\$)
18057	Chordal Deviation – Inch (chord_tol\$)
18058	Chordal Deviation – Metric (met_chord_tol\$)
18059	Deviation of vector endpoints - Inch (vert_tol\$)
18060	Deviation of vector endpoints – Metric (met_vert_tol\$)
18061	General math function tolerance – Inch (xtol\$)
18062	General math function tolerance – Metric (met_xtol\$)
18063	Minimum distance between arc end points – Inch (ltol\$)

18064	Minimum distance between arc end points – Metric (met_ltol\$)
18065	Minimum arc length – Inch (minarc\$)
18066	Minimum arc length – Metric (met_minarc\$)
18067	Minimum arc radius – Inch (minrad\$)
18068	Minimum arc radius – Metric (met_minrad\$)
18069	Maximum arc radius – Inch (maxrad\$)
18070	Maximum arc radius – Metric (met_maxrad\$)
18071	Minimum change in plane for helix – Inch (helix_tol\$)
18072	Minimum change in plane for helix – Metric (met_helix_tol\$)
18073	Maximum deviation in calculated arc end points from machine grid – Inch (arc_tol\$)
18074	Maximum deviation in calculated arc end points from machine grid – Metric (met_arc_tol\$)
18075	Minimum angle tolerance (atol\$)
18076	Maximum angle tolerance (max_atol\$)
18077	Truncate NC Precision: 0 = no, 1 = yes



Communications page

COMMUNICATION_CTRL

18105	End of line delay
18106	Baud rate (Actual value selected, i.e. – 9600)
18107	Port number (1, 2, 3 or 4)
18108	Number of data bits (6, 7 or 8)
18109	Number of stop bits (1 or 2)
18110	Handshaking (0 = None, 1 = Software, 2 = Hardware)
18111	Communications product (0 = Mastercam, 1 = Other, 2=Cimco)
18112	Parity (O = Odd, E = Even, N = None)
18113	Format (A = Ascii, E = EIA, B = BIN)
18114	Strip carriage return (True/False)
18115	Strip line feed (True/False)
18116	Echo terminal emulation (True/False)
18117	Display to screen (True/False)
18118	DOS communications mode (True/False)
18820	External communications (new for X3)

Files page



FILE_CTRL

POST_DLG_SETTING S	
18155	Error message options (0 = All error messages to file, 1 = All error messages to screen, 2 = Only first error message to screen)
18156	Keep error file (0 = On fatal errors, 1 = On fatal and non-fatal errors, 2 = On post errors and messages, 3 = On errors, messages, and prompts, 4 = Always keep log file)
18157	Transform operation options (0 = Transform op parameters only, 1 = Source ops parameters only, 2 = Transform and source parameters) (obsolete for X3)
15158	NC data path
18159	NCI data path
18160	Setup sheet template data path and file name
18161	Post executable data path and file name
18162	Operations library (Inch) data path and file name
18163	Operations library (Metric) data path and file name
18164	Default operations library (Inch) data path and file name
18165	Default operations library (Metric) data path and file name
18166	Chook from Misc. values button data path and file name
18167	Chook from Aux. register button data path and file name (Wire)
18168	Power setting library (Inch) data path and file name (Wire)
18169	Power setting library (Metric) data path and file name (Wire)
18170	NC File extension (sextnc\$)
18171	Write NC operation information (True/False) (obsolete for X3)

Post dialog box defaults

These settings are the default **Post** dialog box settings as saved with the control definition. They are not the settings selected at the time of posting.

POST_DLG_SETTINGS

18750	Create NCI file (True/False)
18751	Overwrite NCI file (0 = ask, 1 = overwrite)
18752	Create NC file (True/False)
18753	Overwrite NC file (0 = ask, 1 = overwrite)
18754	Send to machine (True/False)

18755	Edit NCI file (True/False)
18756	Edit NC file (True/False)
18757	Export oplist (obsolete for X3)
18758	Export prm (obsolete for X3)
18759	Status of the Output Tplanes relative to WCS option. This affects how the NCI 1014 line is written.
18760	Output MCX file descriptor (True/False)



NC Dialog page

NC_DIALOG_MILL_CTRL

18255	Not Used
18256	Set check box for Reference Point button (0 = No, 1 = Yes)
18257	Not Used
18258	Not Used
18259	Not Used
18260	Set check box for Tool Display button (0 = No, 1 = Yes)

NC_DIALOG_ROUTER_CTRL

18305	Not Used
18306	Set check box for Reference Point button (0 = No, 1 = Yes)
18307	Not Used
18308	Not Used
18309	Not Used
18310	Set check box for Tool Display button (0 = No, 1 = Yes)

NC_DIALOG_LATHE_CTRL

18355	Not Used
18356	Not Used
18357	Set check box for Reference Point button (0 = No, 1 = Yes)
18358	Not Used
18359	Not Used
18360	Set check box for Tool Display button (0 = No, 1 = Yes)

NC_DIALOG_WIRE_CTRL

18405	<i>Not Used (removed for X3)</i>
18406	Not Used
18407	Not Used

18408	Not Used
18409	Not Used
18410	Not Used
18411	Not Used



NC Output page

NC_OUTPUT_CTRL

18455	Start sequence number
18456	Increment sequence number
18457	Maximum sequence number
18458	Maximum characters in NC comment
18459	Number of places to the left of decimal
18460	Number of places to the right of decimal
18461	Spaces between NC addresses
18462	First alternate EOB character (ascii value equivalent)
18463	Second alternate EOB character (ascii value equivalent)
18464	Text from Description field in Control Def Mgr.
18465	Main program default absolute/incremental (0 = absolute, 1 = incremental)
18466	Output operation comments to NC (0 = no, 1 = yes)
18467	Output group comments to NC (0 = no, 1 = yes)
18468	Output group name to NC (0 = no, 1 = yes)
18469	Output machine name to NC (0 = no, 1 = yes)
18470	Output sequence numbers (True/False)
18471	Reset sequence numbers in subprograms (True/False)
18472	Use decimal sequence numbers (True/False)
18473	Delete Cr/Lf at end of NC block (True/False)
18474	Use optional EOB characters (True/False)
18475	Ouput debug info (True/False) (Obsolete for X3; always output as 0.)

Work System page

NC_PATH_WORKSYS_CTRL

18505	Work coordinate selection (0 = home position, 1 = local work offset, 2 = other, 3 = work offsets)
18506	Tplane during automatic work offset number creation (0 = all T planes, 1 = only transform T planes)
18507	Translate NCI coordinates to machine view with aggregate (Mill/Router)

Tool page



NC_PATH_TOOL_CTRL

18508	Tool offset registers (0 = add to tool, 1 = from tool)
18509	Add tool amount
18510	Add length amount
18511	Add diameter amount
18512	Add back offset amount
18513	Get Home Position option (0 = from default setting, 1 = from tool setting, 2 = from machine definition)
18514	Use head number to replace tool number (True/False)
18515	Add head number to offset register (True/False)
18516	Enable staged tool routines (True/False)
18517	Write length register to NCI with lathe toolpaths

NC_PATH_TOOL_CTRL002

18761	Tool offset registers (0 = add to tool, 1 = from tool)
18762	Add tool amount
18763	Add length amount
18764	Add diameter amount
18765	Add back offset amount
18766	Get Home Position option (0 = from default setting, 1 = from tool setting, 2 = from machine definition)
18767	Use head number to replace tool number (True/False)
18768	Add head number to offset register (True/False)
18769	Enable staged tool routines (True/False)
18770	Write length register to NCI with lathe toolpaths

Linear page

NC_PATH_LINEAR_CTRL

18518	Rapid motion (0 = each axis moves at max. feed rate independently, 1 = all axes arrive at destination simultaneously, 2 = linear interpolation at maximum feed rate)
18519	XY plane control (0 = do not break linear motion, 1 = break rapid moves – XY then Z for approach, Z then XY for retract, 2 = break all moves with change in Z)
18520	XZ plane control (0 = do not break linear motion, 1 = break rapid moves – XZ then Y for approach, Y then XZ for retract, 2 = break all moves with change in Y)
18521	YZ plane control (0 = do not break linear motion, 1 = break rapid moves – YZ then X for approach, X then YZ for retract, 2 = break all moves with change in X)

18522	Corner rounding/exact stop (0 = control cutting mode, 1 = control exact stop mode, 2 = control corner rounding mode)
-------	--

**NC_PATH_LINEAR_CTRL002**

18771	Rapid motion (0 = each axis moves at max. feed rate independently, 1 = all axes arrive at destination simultaneously, 2 = linear interpolation at maximum feed rate)
18772	XY plane control (0 = do not break linear motion, 1 = break rapid moves – XY then Z for approach, Z then XY for retract, 2 = break all moves with change in Z)
18773	XZ plane control (0 = do not break linear motion, 1 = break rapid moves – XZ then Y for approach, Y then XZ for retract, 2 = break all moves with change in Y)
18774	YZ plane control (0 = do not break linear motion, 1 = break rapid moves – YZ then X for approach, X then YZ for retract, 2 = break all moves with change in X)
18775	Corner rounding/exact stop (0 = control cutting mode, 1 = control exact stop mode, 2 = control corner rounding mode)

Arc page**NC_PATH_ARC_CTRL**

18523	XY plane arc center type (0 = absolute, 1 = delta start to center, 2 = delta center to start, 3 = unsigned incremental, 4 = radius, 5 = signed radius)
18524	XZ plane arc center type (0 = absolute, 1 = delta start to center, 2 = delta center to start, 3 = unsigned incremental, 4 = radius, 5 = signed radius)
18525	YZ plane arc center type (0 = absolute, 1 = delta start to center, 2 = delta center to start, 3 = unsigned incremental, 4 = radius, 5 = signed radius)
18526	XY plane arc break options (0 = don't break, 1 = break at quadrants, 2 = break at 180 degrees)
18527	XZ plane arc break options (0 = don't break, 1 = break at quadrants, 2 = break at 180 degrees)
18528	YZ plane arc break options (0 = don't break, 1 = break at quadrants, 2 = break at 180 degrees)
18529	Helix support (0 = no helix allowed, 1 = only in XY plane, 2 = all planes supported)
18530	Arc end point checks (0= round end point – break arc on failure, 1 = round end point – arc to generated point on failure, 2 = no rounding – break arc on failure)
18531	Support arcs on XY plane (True/False)
18532	Support arcs on XZ plane (True/False)
18533	Support arcs on YZ plane (True/False)

18534	Allow 360 degree arcs on XY plane (True/False)
18535	Allow 360 degree arcs on XZ plane (True/False)
18536	Allow 360 degree arcs on YZ plane (True/False)
18537	Arc error checks – length of arc (True/False)
18538	Arc error checks – length of radius (True/False)
18539	Arc error checks – parallel axis motion on quadrant (True/False)
18540	Arc error checks – equilateral triangle (True/False)
18541	Arc error checks – end point checks (True/False)

**NC_PATH_ARC_CTRL002**

18776	XY plane arc center type (0 = absolute, 1 = delta start to center, 2 = delta center to start, 3 = unsigned incremental, 4 = radius, 5 = signed radius)
18777	XZ plane arc center type (0 = absolute, 1 = delta start to center, 2 = delta center to start, 3 = unsigned incremental, 4 = radius, 5 = signed radius)
18778	YZ plane arc center type (0 = absolute, 1 = delta start to center, 2 = delta center to start, 3 = unsigned incremental, 4 = radius, 5 = signed radius)
18779	XY plane arc break options (0 = don't break, 1 = break at quadrants, 2 = break at 180 degrees)
18780	XZ plane arc break options (0 = don't break, 1 = break at quadrants, 2 = break at 180 degrees)
18781	YZ plane arc break options (0 = don't break, 1 = break at quadrants, 2 = break at 180 degrees)
18782	Helix support (0 = no helix allowed, 1 = only in XY plane, 2 = all planes supported)
18783	Arc end point checks (0= round end point – break arc on failure, 1 = round end point – arc to generated point on failure, 2 = no rounding – break arc on failure)
18784	Support arcs on XY plane (True/False)
18785	Support arcs on XZ plane (True/False)
18786	Support arcs on YZ plane (True/False)
18787	Allow 360 degree arcs on XY plane (True/False)
18788	Allow 360 degree arcs on XZ plane (True/False)
18789	Allow 360 degree arcs on YZ plane (True/False)
18790	Arc error checks – length of arc (True/False)
18791	Arc error checks – length of radius (True/False)
18792	Arc error checks – parallel axis motion on quadrant (True/False)
18793	Arc error checks – equilateral triangle (True/False)
18794	Arc error checks – end point checks (True/False)

Rotary page

NC_PATH_ROTARY_CTRL

18542	Break rapid rotary moves (True/False)
18543	Attempt to adjust machine to bi-stable position



Feed page

NC_PATH_FEED_CTRL

18544	Three axis feed options (0 = unit/min., 1 = use inverse)
18545	Four axis linear feed options (0 = unit/min., 1 = use inverse)
18546	Four axis rotary feed options (0 = unit/min., 1 = degree/min., 2 = use inverse)
18547	Five axis linear feed options (0 = unit/min., 1 = use inverse)
18548	Five axis rotary feed options (0 = unit/min., 1 = use inverse)
18549	Inverse feed (0 = feed rate in minutes, 1 = feed rate in seconds)
18700	Convert rapid to maximum feed rate (True/False)
18701	Adjust feed rate on arc moves (True/False)
18702	Use feed rate in NC output (True/False) (Wire Only)

NC_PATH_FEED_CTRL002

18795	Three axis feed options (0 = unit/min., 1 = use inverse)
18796	Four axis linear feed options (0 = unit/min., 1 = use inverse)
18797	Four axis rotary feed options (0 = unit/min., 1 = degree/min., 2 = use inverse)
18798	Five axis linear feed options (0 = unit/min., 1 = use inverse)
18799	Five axis rotary feed options (0 = unit/min., 1 = use inverse)
18800	Inverse feed (0 = feed rate in minutes, 1 = feed rate in seconds)
18801	Convert rapid to maximum feed rate (True/False)
18802	Adjust feed rate on arc moves (True/False)
18803	Use feed rate in NC output (True/False) (Wire Only)

Cutter Compensation page

NC_PATH_COMP_CTRL

18703	Number of look ahead blocks for control comp
18704	Control supports cutter compensation in control

18705	Allow cutter comp in control to be activated/deactivated on arcs (True/False)
18706	Control supports wear compensation (True/False)
18707	Control supports reverse wear compensation (True/False)
18708	Start and end cutter compensation above part
18709	<i>Compensate the first and last point in cutter comp. in control simulation (True/False) (removed for X3)</i>
18710	<i>Display the first and last entities in cutter comp. in control simulation (True/False) (removed for X3)</i>
18711	<i>Display a warning when cutter compensation in control simulation finds an error (True/False) (removed for X3)</i>
18821	Optimize toolpaths (true/false) (New for X3)



Subprograms page

NC_PATH_SUBS_CTRL

18712	Maximum subprogram nesting levels
18713	Subprogram location (0 = after main program, 1 = before main program)
18714	Maximum mirror/rotate coordinate subprogram routines nesting levels
18715	Control supports subprograms (True/False)
18716	Allow mirror coordinate subprogram routines (True/False)
18717	Allow rotate coordinate subprogram routines (True/False)
18718	Allow nesting of mirror/rotate coordinate subprogram routines (True/False)
18719	Ignore work offset numbers when processing subprograms
18720	Ignore contour flags when processing subprograms

Misc. Int/Real Values page

NC_PATH_CTRL

NC_PATH_WORKSYS_CTRL
NC_PATH_TOOL_CTRL
NC_PATH_TOOL_CTRL002
NC_PATH_LINEAR_CTRL
NC_PATH_LINEAR_CTRL002
NC_PATH_ARC_CTRL
NC_PATH_ARC_CTRL002
NC_PATH_ROTARY_CTRL

NC_PATH_FEED_CTRL	
NC_PATH_FEED_CTRL002	
NC_PATH_COMP_CTRL	
NC_PATH_SUBS_CTRL	
18721	Initialize tool path operation (0 = from these settings, 1 = from default operation)
18722	Set miscellaneous values on first operation of each type only
18723	Use separate mill and lathe text and values (Mill/Turn control)



Machine Cycles page

CYCLES_2CTRL

NC_GEN_CYCLES_CTRL	
NC_DRILL_CYCLES_CTRL	
NC_DRILL_CYCLES_CTRL002	
NC_LATHE_CYCLES_CTRL	

NC_GEN_CYCLES_CTRL

18555	Height return options (0 = return to initial height, 1 = return to reference height)
18556	Percent drill depth decline with peck and chip
18557	Use lead drill with block drilling (True/False) (Router)
18558	Control supports polar interpolation (True/False)
18559	Control supports cylindrical interpolation (True/False)
18560	Control supports high speed machining (True/False)
18561	Use separate mill and lathe text and values (Mill/Turn)

Drill cycles page

NC_DRILL_CYCLES_CTRL

18562	Simple drill – no peck (True/False)
18563	Peck drill – full retract (True/False)
18564	Chip break – incremental retract (True/False)
18565	Tapping – feed in, reverse spindle – feed out (True/False)
18566	Boring #1 – feed out (True/False)
18567	Boring #2 – stop spindle – rapid out (True/False)
18568	Misc. #1 drill – uses simple drill (True/False)
18569	Misc. #2 drill – uses simple drill (True/False)

NC_DRILL_CYCLES_CTRL002

18804	Simple drill – no peck (True/False)
18805	Peck drill – full retract (True/False)
18806	Chip break – incremental retract (True/False)
18807	Tapping – feed in, reverse spindle – feed out (True/False)
18808	Boring #1 – feed out (True/False)
18809	Boring #2 – stop spindle – rapid out (True/False)
18810	Misc. #1 drill – uses simple drill (True/False)
18811	Misc. #2 drill – uses simple drill (True/False)

Lathe Canned Cycles page**NC_LATHE_CYCLES_CTRL**

18570	Enable canned rough turning (True/False)
18571	Enable canned rough pattern repeat (True/False)
18572	Enable canned roughing undercuts (True/False)
18573	Enable canned finish (True/False)
18574	Enable canned groove cycle (True/False)
18575	Enable canned groove wall taper (True/False)
18576	Enable canned groove radius on corners (True/False)
18577	Enable canned groove radius on chamfers (True/False)
18578	Enable canned groove rough pecking (True/False)
18579	Enable canned groove rough depth cuts (True/False)
18580	Enable canned groove chamfer on corners (True/False)
18581	Enable canned groove dwell (True/False)
18582	Enable canned thread cycles (True/False)
18583	Enable canned thread cycle (True/False)
18584	Enable box thread cycle (True/False)
18585	Enable alternating thread cycle (True/False)
18586	Enable thread equal depth cuts (True/False)
18587	Enable thread equal area (True/False)
18588	Enable thread multiple starts (True/False)
18589	Enable thread anticipated pull off (True/False)
18590	Enable thread equal depth cuts - Box (True/False)
18591	Enable thread equal area - Box (True/False)
18592	Enable thread multiple starts - Box (True/False)
18593	Enable thread anticipated pull off - Box (True/False)
18594	Enable thread equal depth cuts - Alternating (True/False)
18595	Enable thread equal area - Alternating (True/False)
18596	Enable thread multiple starts - Alternating (True/False)

18597	Enable thread anticipated pull off - Alternating (True/False)
18598	Enable anticipated pull off for long hand thread (True/False)
18812	NOT USED - First start far from part with multiple threading
18813	NOT USED First start closest to part with multiple threading
18814	Enable first start far from part with multiple threading
18815	Enable first start closest to part with multiple threading
18816	Enable first start far from part with multiple threading
18817	Enable first start closest to part with multiple threading
18818	Enable first start far from part with multiple threading
18819	Enable first start closest to part with multiple threading



Start/Leads page (Wire)

WIRE_NC_PATH_CTRL

[NC_WIRE_LEADS_CTRL](#)
[NC_WIRE_CUTS_CTRL](#)
[NC_WIRE_CORNER_CTRL](#)
[NC_WIRE_REVERSE_CTRL](#)
[NC_WIRE_AUX_REV_CTRL](#)
[NC_WIRE_TAPER_CTRL](#)
[NC_WIRE_NOCORE_CTRL](#)

NC_WIRE_LEADS_CTRL

18605	Wire threading (0 = manual, 1 = automatic)
18606	Lead in type (0 = line only, 1 = radius only, 2 = line and arc, 3 = two lines and arc)
18607	Lead out type (0 = line only, 1 = radius only, 2 = line and arc, 3 = two lines and arc)
18608	Initialize toolpath operation (0 = from these settings, 1 = from default operation)
18609	Start position is automatically set to thread position (True/False)
18610	Line lead in and exit are required (True/False)
18611	Move to arc center with 'two lines and arc' lead option (True/False)
18612	Flip taper direction on leads with 'two lines and arc' lead option (True/False)

Cuts page (Wire)

NC_WIRE_CUTS_CTRL

18613	Reset pass number on tab cuts (True/False)
18614	Lock the UV height above the XY height (True/False)



Corner page (Wire)

NC_WIRE_CORNER_CTRL

18615	Conical – minimum (True/False)
18616	Conical – mean (True/False)
18617	Conical – maximum (True/False)
18618	Constant (True/False)
18619	Fixed (True/False)
18620	Sharp (True/False)
18621	Fish Tail (True/False)
18622	Other (True/False)
18623	Enable line-arc-line tangent conic mode (True/False)
18624	Enable dual corner types and upper radius with arcs (True/False)

Reverse Cuts Contour page (Wire)

NC_WIRE_REVERSE_CTRL

18625	Change corner type on (0 = point, 1 = move, 2 = prior point)
18626	Change UV arc type on (0 = point, 1 = move, 2 = prior point)
18627	Change rapid move on (0 = point, 1 = move, 2 = prior point)
18628	Change feed rate on (0 = point, 1 = move, 2 = prior point)
18629	Change manual entry on (0 = point, 1 = move, 2 = prior point)
18630	Change canned text on (0 = point, 1 = move, 2 = prior point)
18631	Change wire compensation on (0 = point, 1 = move, 2 = prior point)
18632	Change condition code on (0 = point, 1 = move, 2 = prior point)
18633	Change wire offset on (0 = point, 1 = move, 2 = prior point)
18634	Change wire diameter on (0 = point, 1 = move, 2 = prior point)

18635	Change wire over burn on (0 = point, 1 = move, 2 = prior point)
18636	Change dwell on (0 = point, 1 = move, 2 = prior point)
18637	Change contour flags on (0 = point, 1 = move, 2 = prior point)
18638	Change stop flags on (0 = point, 1 = move, 2 = prior point)
18639	Change thread/cut flags on (0 = point, 1 = move, 2 = prior point)
18640	Change power settings on (0 = point, 1 = move, 2 = prior point)
18641	Change tank settings on (0 = point, 1 = move, 2 = prior point)
18642	Change flush settings on (0 = point, 1 = move, 2 = prior point)



Reverse Cuts Auxiliary page (Wire)

NC_WIRE_AUX_REV_CTRL

18643	Change auxiliary register 1 on (0 = point, 1 = move, 2 = prior point)
18644	Change auxiliary register 2 on (0 = point, 1 = move, 2 = prior point)
18645	Change auxiliary register 3 on (0 = point, 1 = move, 2 = prior point)
18646	Change auxiliary register 4 on (0 = point, 1 = move, 2 = prior point)
18647	Change auxiliary register 5 on (0 = point, 1 = move, 2 = prior point)
18648	Change auxiliary register 6 on (0 = point, 1 = move, 2 = prior point)
18649	Change auxiliary register 7 on (0 = point, 1 = move, 2 = prior point)
18650	Change auxiliary register 8 on (0 = point, 1 = move, 2 = prior point)
18651	Change auxiliary register 9 on (0 = point, 1 = move, 2 = prior point)
18652	Change auxiliary register 10 on (0 = point, 1 = move, 2 = prior point)
18653	Change auxiliary register 1 on - modal (True/False)
18654	Change auxiliary register 2 on - modal (True/False)
18655	Change auxiliary register 3 on - modal (True/False)
18656	Change auxiliary register 4 on - modal (True/False)
18657	Change auxiliary register 5 on - modal (True/False)
18658	Change auxiliary register 6 on - modal (True/False)
18659	Change auxiliary register 7 on - modal (True/False)
18660	Change auxiliary register 8 on - modal (True/False)

18661	Change auxiliary register 9 on - modal (True/False)
18662	Change auxiliary register 10 on - modal (True/False)



4-axis Paths page (Wire)

NC_WIRE_TAPER_CTRL

18663	Direct and Taper wire paths maximum angle
18664	Direct and Taper wire paths maximum step size - inch
18665	Direct and Taper wire paths maximum step size – metric
18666	Control supports Direct wire paths (True/False)
18667	Control supports Taper wire paths (True/False)

Nocore page (Wire)

NC_WIRE_NOCORE_CTRL

18668	Percentage of wire diameter to be used for lead
18669	With 'Add finish contour operation' option, create finish operation after each pocket (True/False)
18670	Perpendicular leads with rough passes (True/False)

Machine group parameters



See [Capturing machine group parameters](#) on page 35 to learn more about capturing the parameter values in your post.

The first section ([Machine group properties: visual reference](#)) shows screen captures of all the machine definition dialogs annotated with the parameter numbers. The second section ([Machine group properties: list of parameters](#) on page 402) lists all of the parameters by group and number.


Machine group properties: visual reference

Most of the fields shown in the following pages use parameters to store their values, but the values for some fields are available as pre-defined variables, or even directly in the NCI G-code. Use the following color key to determine the type of value:

- Red labels indicate parameter numbers
- Blue labels indicate pre-defined variable names
- Green labels indicate NCI G-codes


Some fields are available as both parameters and pre-defined variables. In these cases, you can use whichever method is most convenient. Typically, this will be the pre-defined variable.

Files tab (Machine Group Properties)




The comments at the bottom of the tab are available directly from the NCI file, rather than parameters. The number in green lists the NCI Gcode where the comment will be output.

Tool Settings tab (Machine Group Properties)




Mastercam Wire uses an abbreviated version of this tab—**Program Settings**—as shown below.




Stock Setup tab—Mill/Router (Machine Group Properties)

Stock models are now stored in the machine definition as machine definition components. This means that in addition to the machine group parameters noted here, you can also access the machine definition component parameters. These will generally prove to be more robust and flexible. As a best practice, you should use the machine definition parameters instead of the legacy machine group parameters.






Stock Setup tab—Lathe (Machine Group Properties)

Stock models—as well as chuck jaws, tailstock centers, and steady rests—are now stored in the machine definition as machine definition components. This means that in addition to the machine group parameters noted here, you can also access the machine definition component parameters. These will generally prove to be more robust and flexible. As a best practice, you should use the machine definition parameters instead of the legacy machine group parameters.



Safety Zone tab (Machine Group Properties)



Machine group properties: list of parameters

General machine group parameters

Machine group header

19970 | Machine group name (**New for X3**)

OP_GROUP_INFO

19246 | Name and path of defaults file

GROUP_PG1

Files tab

GROUP_PG2

Tool settings tab

GROUP_PG3

Stock setup tab

GROUP_PG4 | Safety zone tab



GROUP_LIST

19247	Group number, 0 = deleted, > 0 = alive
19248	Machine group name
19249	Parent group number
19250	Number of grp_ent's pointed to by *e
19251	(Removed in X3)

ATTRIBUTES

19252	Group attributes (not yet used)
19253	True = don't display in groups dialog
19254	Temp marker used in sorting in merging
19255	OpMgr expanded flag
19256	Type of group
19257	Group's color
19258	Group's level
19259	True - use entitys' color & level
19260	File position of group

OP_GROUP_INFO

19261	PRODUCT_MILL, PRODUCT_LATHE, PRODUCT_ROUTER or PRODUCT_WIRE
19262	(Removed in X3)
19263	(Removed in X3)
19264	(Removed in X3)

ATTRIBUTES

19026	Width (not currently used)
19027	Style (not currently used)
19028	Pen (not currently used)
19029	PSTYLE (not currently used)

Files page

GROUP_PG1

19104	(removed for X3)
19105	Name and path of machine definition
19106	Path of NCI file
19107	Not used
19108	Project Manager folder flag0
19352–19514	Project Manager folder flags
19109	(removed for X3)

	19110	(removed for X3)
	GROUP_VIEW	Cplane view and origin info (new for X3)
	GROUP_VIEW002	Tplane view and origin info (new for X3)
	GROUP_VIEW003	Gview view and origin info (new for X3)
	GROUP_VIEW004	WCS view and origin info (new for X3)
	GROUP_VIEW005	This group's stock view and origin information
	GROUP_VIEW006	This group's safety zone view and origin information
	19111	General group comments
	19112	This group's machine entity ID number
	19352–19514	Project Manager folder flags
	19515	If >0, the Toolpath Manager insert arrow is positioned after this operation; if <0, it is positioned after this group. (X2)
	GROUP_PG1_ADVANCED_DEFAULTS	
	19112	This group's machine entity ID number



GROUP_VIEW

19294	View ID# (new for X3)
19295	View number (new for X3)
19516	Coordinate display (new for X3)
19296	Toolplane view matrix (new for X3)
19297	Toolplane view matrix (new for X3)
19298	Toolplane view matrix (new for X3)
19299	Toolplane view matrix (new for X3)
19300	Toolplane view matrix (new for X3)
19301	Toolplane view matrix (new for X3)
19302	Toolplane view matrix (new for X3)
19303	Toolplane view matrix (new for X3)
19304	Toolplane view matrix (new for X3)
19305	View origin in world (new for X3)
19306	View origin in world (new for X3)
19307	View origin in world (new for X3)

GROUP_VIEW002

19294	View ID# (new for X3)
19295	View number (new for X3)
19516	Coordinate display (new for X3)
19296	Toolplane view matrix (new for X3)
19297	Toolplane view matrix (new for X3)
19298	Toolplane view matrix (new for X3)
19299	Toolplane view matrix (new for X3)



19300	Toolplane view matrix (new for X3)
19301	Toolplane view matrix (new for X3)
19302	Toolplane view matrix (new for X3)
19303	Toolplane view matrix (new for X3)
19304	Toolplane view matrix (new for X3)
19305	View origin in world (new for X3)
19306	View origin in world (new for X3)
19307	View origin in world (new for X3)

GROUP_VIEW003

19294	View ID# (new for X3)
19295	View number (new for X3)
19516	Coordinate display (new for X3)
19296	Toolplane view matrix (new for X3)
19297	Toolplane view matrix (new for X3)
19298	Toolplane view matrix (new for X3)
19299	Toolplane view matrix (new for X3)
19300	Toolplane view matrix (new for X3)
19301	Toolplane view matrix (new for X3)
19302	Toolplane view matrix (new for X3)
19303	Toolplane view matrix (new for X3)
19304	Toolplane view matrix (new for X3)
19305	View origin in world (new for X3)
19306	View origin in world (new for X3)
19307	View origin in world (new for X3)

GROUP_VIEW004

19294	View ID# (new for X3)
19295	View number (new for X3)
19516	Coordinate display (new for X3)
19296	Toolplane view matrix (new for X3)
19297	Toolplane view matrix (new for X3)
19298	Toolplane view matrix (new for X3)
19299	Toolplane view matrix (new for X3)
19300	Toolplane view matrix (new for X3)
19301	Toolplane view matrix (new for X3)
19302	Toolplane view matrix (new for X3)
19303	Toolplane view matrix (new for X3)
19304	Toolplane view matrix (new for X3)
19305	View origin in world (new for X3)
19306	View origin in world (new for X3)

19307 | View origin in world (**new for X3**)**GROUP_VIEW005**

19266	View ID#
19267	View number
19520	Coordinate display (new for X3)
19268	Toolplane view matrix
19269	Toolplane view matrix
19270	Toolplane view matrix
19271	Toolplane view matrix
19272	Toolplane view matrix
19273	Toolplane view matrix
19274	Toolplane view matrix
19275	Toolplane view matrix
19276	Toolplane view matrix
19277	View origin in world
19278	View origin in world
19279	View origin in world

GROUP_VIEW006

19280	View ID#
19281	View number
19521	Coordinate display (new for X3)
19282	Toolplane view matrix
19283	Toolplane view matrix
19284	Toolplane view matrix
19285	Toolplane view matrix
19286	Toolplane view matrix
19287	Toolplane view matrix
19288	Toolplane view matrix
19289	Toolplane view matrix
19290	Toolplane view matrix
19291	View origin in world
19292	View origin in world
19293	View origin in world

Tool settings page**GROUP_PG2**

19113 | Program number



19114	Where this group's ops get their feeds and speeds from (0 = from tool, 1 = from material, 2 = from defaults, 3=user-defined)
19115	User-defined default feed rate
19116	True if this machine is to have its speed adjusted on an arc move; False if not
19117	User-defined default spindle speed.
19118	True if the tools created in this group are to be given sequential tool numbers; False if not
19119	True if the user is to be warned whenever they could be creating duplicate tool numbers; False if not
19120	True if operations are to get step, peck, and coolant values from tools; False if not
19121	True if the user wants the tool library searched when they enter a tool number; False if not
19122	Send tool to clear position to go home (lathe only)
19123	This group's material filename and path
19350	User-defined default plunge rate
19351	User-defined default retract rate

GROUP_PG1_ADVANCED_DEFAULTS

19099	Enable options to override defaults with modal values
19100	Override default clearance height with modal value
19101	Override default retract height with modal value
19102	Override default feed plane with modal value
19103	Override defaults with named views

Stock setup tab

Stock models—as well as chuck jaws, tailstock centers, and steady rests—are now stored in the machine definition as machine definition components. This means that in addition to the machine group parameters noted here, you can also access the machine definition component parameters. These will generally prove to be more robust and flexible. As a best practice, you should use the machine definition parameters instead of the legacy machine group parameters.

GROUP_PG3

19124	Fit stock in screen (Y/N)
19125	Stock size. X dimension if block, diameter if cylinder.
19126	Stock size. Y dimension if block, length if cylinder.
19127	Stock size. Z dimension if block, not used if cylinder.
19128	Stock origin (X). See parameter 19212 to identify which corner of stock model this is.
19129	Stock origin (Y). See parameter 19212 to identify which corner of stock model this is.
19130	Stock origin (Z). See parameter 19212 to identify which corner of stock model this is.

19131	Show stock: True=always show stock in gview
19132	Draw stock as a translucent solid instead of wireframe (True/False)
19133	Stock shape: 0=rect, 1=cyl, 2=solid, 3=stl file
19134	Solid entity id number
19135	Stock cylinder axis: 0=X, 1=Y, 2=Z
19136	Center stock on axis (True/False)
19137	STL filename
19138	Line style to display stock with
19139	Color of stock when displayed
19140	3D lines for stock definition: line 1, endpoint 1, X
19141	3D lines for stock definition: line 1, endpoint 1, Y
19142	3D lines for stock definition: line 1, endpoint 1, Z
19143	3D lines for stock definition: line 1, endpoint 2, X
19144	3D lines for stock definition: line 1, endpoint 2, Y
19145	3D lines for stock definition: line 1, endpoint 2, Z
19146	3D lines for stock definition: line 2, endpoint 1, X
19147	3D lines for stock definition: line 2, endpoint 1, Y
19148	3D lines for stock definition: line 2, endpoint 1, Z
19149	3D lines for stock definition: line 2, endpoint 2, X
19150	3D lines for stock definition: line 2, endpoint 2, Y
19151	3D lines for stock definition: line 2, endpoint 2, Z
19152	3D lines for stock definition: line 3, endpoint 1, X
19153	3D lines for stock definition: line 3, endpoint 1, Y
19154	3D lines for stock definition: line 3, endpoint 1, Z
19155	3D lines for stock definition: line 3, endpoint 2, X
19156	3D lines for stock definition: line 3, endpoint 2, Y
19157	3D lines for stock definition: line 3, endpoint 2, Z
19158	3D lines for stock definition: line 4, endpoint 1, X
19159	3D lines for stock definition: line 4, endpoint 1, Y
19160	3D lines for stock definition: line 4, endpoint 1, Z
19161	3D lines for stock definition: line 4, endpoint 2, X
19162	3D lines for stock definition: line 4, endpoint 2, Y
19163	3D lines for stock definition: line 4, endpoint 2, Z
19164	3D lines for stock definition: line 5, endpoint 1, X
19165	3D lines for stock definition: line 5, endpoint 1, Y
19166	3D lines for stock definition: line 5, endpoint 1, Z
19167	3D lines for stock definition: line 5, endpoint 2, X
19168	3D lines for stock definition: line 5, endpoint 2, Y
19169	3D lines for stock definition: line 5, endpoint 2, Z
19170	3D lines for stock definition: line 6, endpoint 1, X
19171	3D lines for stock definition: line 6, endpoint 1, Y
19172	3D lines for stock definition: line 6, endpoint 1, Z
19173	3D lines for stock definition: line 6, endpoint 2, X



19174	3D lines for stock definition: line 6, endpoint 2, Y
19175	3D lines for stock definition: line 6, endpoint 2, Z
19176	3D lines for stock definition: line 7, endpoint 1, X
19177	3D lines for stock definition: line 7, endpoint 1, Y
19178	3D lines for stock definition: line 7, endpoint 1, Z
19179	3D lines for stock definition: line 7, endpoint 2, X
19180	3D lines for stock definition: line 7, endpoint 2, Y
19181	3D lines for stock definition: line 7, endpoint 2, Z
19182	3D lines for stock definition: line 8, endpoint 1, X
19183	3D lines for stock definition: line 8, endpoint 1, Y
19184	3D lines for stock definition: line 8, endpoint 1, Z
19185	3D lines for stock definition: line 8, endpoint 2, X
19186	3D lines for stock definition: line 8, endpoint 2, Y
19187	3D lines for stock definition: line 8, endpoint 2, Z
19188	3D lines for stock definition: line 9, endpoint 1, X
19189	3D lines for stock definition: line 9, endpoint 1, Y
19190	3D lines for stock definition: line 9, endpoint 1, Z
19191	3D lines for stock definition: line 9, endpoint 2, X
19192	3D lines for stock definition: line 9, endpoint 2, Y
19193	3D lines for stock definition: line 9, endpoint 2, Z
19194	3D lines for stock definition: line 10, endpoint 1, X
19195	3D lines for stock definition: line 10, endpoint 1, Y
19196	3D lines for stock definition: line 10, endpoint 1, Z
19197	3D lines for stock definition: line 10, endpoint 2, X
19198	3D lines for stock definition: line 10, endpoint 2, Y
19199	3D lines for stock definition: line 10, endpoint 2, Z
19200	3D lines for stock definition: line 11, endpoint 1, X
19201	3D lines for stock definition: line 11, endpoint 1, Y
19202	3D lines for stock definition: line 11, endpoint 1, Z
19203	3D lines for stock definition: line 11, endpoint 2, X
19204	3D lines for stock definition: line 11, endpoint 2, Y
19205	3D lines for stock definition: line 11, endpoint 2, Z
19206	3D lines for stock definition: line 12, endpoint 1, X
19207	3D lines for stock definition: line 12, endpoint 1, Y
19208	3D lines for stock definition: line 12, endpoint 1, Z
19209	3D lines for stock definition: line 12, endpoint 2, X
19210	3D lines for stock definition: line 12, endpoint 2, Y
19211	3D lines for stock definition: line 12, endpoint 2, Z
A_3D	3D arc #1 for stock definition
A_3D002	3D arc #2 for stock definition
19212	Origin corner: 0=center, 1-8 = one of the stock corners
19213	Boundary avoidance clearance for lathe tools
19214	Entry/exit vector clearance for lathe tools
19526	Use machine tree option (New for X3)



19215	<i>Default active spindle (left/right) (removed for X3)</i>
19216	<i>Default turret to load tools into (top/bottom) (removed for X3)</i>
19217	Entity ID's for left stock boundaries
19218	Entity ID's for left stock boundaries
19219	Entity ID's for right stock boundaries
19220	Entity ID's for right stock boundaries
19221	Entity ID's for left chuck boundaries
19222	Entity ID's for left chuck boundaries
19223	Entity ID's for right chuck boundaries
19224	Entity ID's for right chuck boundaries
19225	Entity ID's for tailstock boundaries
19226	Entity ID's for tailstock boundaries
19227	Entity ID's for steadyrest boundaries
19228	Entity ID's for steadyrest boundaries
19229	Show stock boundaries (True/False)
19230	Show chuck boundaries (True/False)
19231	Show tailstock boundaries (True/False)
19232	Show steadyrest boundaries (True/False)
19233	Fill lathe stock/chuck/tailstock boundaries with color (True/False)
BARSTOCK_TYPE	Stock definition parameters
BARSTOCK_TYPE002	Stock definition parameters
CHUCK_TYPE	<i>(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE, in addition to general component parameter groups).</i>
CHUCK_TYPE002	<i>(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE, in addition to general component parameter groups).</i>
TAILSTOCK_TYPE	<i>(Obsolete for X3—use machine definition component parameters. See TAILSTOCK_COMPONENT_TYPE and LATHE_CENTER_COMPONENT_TYPE, in addition to general component parameter groups).</i>
STEADYREST_TYPE	<i>(Obsolete for X3—use machine definition component parameters. See STEADYREST_COMPONENT_TYPE, in addition to general component parameter groups).</i>

**A_3D**

19000	X position of end point 1
19001	Y position of end point 1
19002	Z position of end point 1
19003	X position of end point 2
19004	Y position of end point 2
19005	Z position of end point 2



19006	X position of center point
19007	Y position of center point
19008	Z position of center point
19009	Radius
19010	Start angle
19011	Sweep angle
19012	View

A_3D002

19013	X position of end point 1
19014	Y position of end point 1
19015	Z position of end point 1
19016	X position of end point 2
19017	Y position of end point 2
19018	Z position of end point 2
19019	X position of center point
19020	Y position of center point
19021	Z position of center point
19022	Radius
19023	Start angle
19024	Sweep angle
19025	View

Lathe peripheral boundaries

BARSTOCK_TYPE

19030	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19031	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19032	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19033	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19034	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19035	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19036	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19037	Margins on OD, ID min & max Z
19038	Margins on OD, ID min & max Z
19039	Margins on OD, ID min & max Z
19040	Margins on OD, ID min & max Z

BARSTOCK_TYPE002

19041	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19042	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19043	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19044	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19045	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19046	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19047	(Obsolete for X3—use CYLINDER_COMPONENT parameters for bar stock)
19048	Margins on OD, ID min & max Z
19049	Margins on OD, ID min & max Z
19050	Margins on OD, ID min & max Z
19051	Margins on OD, ID min & max Z

**CHUCK_TYPE**

19052	(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE , in addition to general component parameter groups).
19053	(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE , in addition to general component parameter groups).
19054	(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE , in addition to general component parameter groups).
19055	(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE , in addition to general component parameter groups).
19056	(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE , in addition to general component parameter groups).
19057	(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE , in addition to general component parameter groups).
19058	(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE , in addition to general component parameter groups).



Quick Start

19059	(Obsolete for X3—use machine definition component parameters. See <i>CHUCK_COMPONENT_TYPE</i> and <i>CHUCKJAWS_COMPONENT_TYPE</i> , in addition to general component parameter groups).
19060	(Obsolete for X3—use machine definition component parameters. See <i>CHUCK_COMPONENT_TYPE</i> and <i>CHUCKJAWS_COMPONENT_TYPE</i> , in addition to general component parameter groups).
19061	(Obsolete for X3—use machine definition component parameters. See <i>CHUCK_COMPONENT_TYPE</i> and <i>CHUCKJAWS_COMPONENT_TYPE</i> , in addition to general component parameter groups).
19522	(Obsolete for X3—use machine definition component parameters. See <i>CHUCK_COMPONENT_TYPE</i> and <i>CHUCKJAWS_COMPONENT_TYPE</i> , in addition to general component parameter groups).
19523	(Obsolete for X3—use machine definition component parameters. See <i>CHUCK_COMPONENT_TYPE</i> and <i>CHUCKJAWS_COMPONENT_TYPE</i> , in addition to general component parameter groups).

CHUCK_TYPE002

19062	(Obsolete for X3—use machine definition component parameters. See <i>CHUCK_COMPONENT_TYPE</i> and <i>CHUCKJAWS_COMPONENT_TYPE</i> , in addition to general component parameter groups).
19063	(Obsolete for X3—use machine definition component parameters. See <i>CHUCK_COMPONENT_TYPE</i> and <i>CHUCKJAWS_COMPONENT_TYPE</i> , in addition to general component parameter groups).
19064	(Obsolete for X3—use machine definition component parameters. See <i>CHUCK_COMPONENT_TYPE</i> and <i>CHUCKJAWS_COMPONENT_TYPE</i> , in addition to general component parameter groups).
19065	(Obsolete for X3—use machine definition component parameters. See <i>CHUCK_COMPONENT_TYPE</i> and <i>CHUCKJAWS_COMPONENT_TYPE</i> , in addition to general component parameter groups).
19066	(Obsolete for X3—use machine definition component parameters. See <i>CHUCK_COMPONENT_TYPE</i> and <i>CHUCKJAWS_COMPONENT_TYPE</i> , in addition to general component parameter groups).
19077	(Obsolete for X3—use machine definition component parameters. See <i>CHUCK_COMPONENT_TYPE</i> and <i>CHUCKJAWS_COMPONENT_TYPE</i> , in addition to general component parameter groups).
19078	(Obsolete for X3—use machine definition component parameters. See <i>CHUCK_COMPONENT_TYPE</i> and <i>CHUCKJAWS_COMPONENT_TYPE</i> , in addition to general component parameter groups).

19079	(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE , in addition to general component parameter groups).
19080	(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE , in addition to general component parameter groups).
19081	(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE , in addition to general component parameter groups).
19524	(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE , in addition to general component parameter groups).
19525	(Obsolete for X3—use machine definition component parameters. See CHUCK_COMPONENT_TYPE and CHUCKJAWS_COMPONENT_TYPE , in addition to general component parameter groups).

**TAILSTOCK_TYPE**

19082	(Obsolete for X3—use machine definition component parameters. See TAILSTOCK_COMPONENT_TYPE and LATHE_CENTER_COMPONENT_TYPE , in addition to general component parameter groups).
19083	(Obsolete for X3—use machine definition component parameters. See TAILSTOCK_COMPONENT_TYPE and LATHE_CENTER_COMPONENT_TYPE , in addition to general component parameter groups).
19084	(Obsolete for X3—use machine definition component parameters. See TAILSTOCK_COMPONENT_TYPE and LATHE_CENTER_COMPONENT_TYPE , in addition to general component parameter groups).
19085	(Obsolete for X3—use machine definition component parameters. See TAILSTOCK_COMPONENT_TYPE and LATHE_CENTER_COMPONENT_TYPE , in addition to general component parameter groups).
19086	(Obsolete for X3—use machine definition component parameters. See TAILSTOCK_COMPONENT_TYPE and LATHE_CENTER_COMPONENT_TYPE , in addition to general component parameter groups).
19087	(Obsolete for X3—use machine definition component parameters. See TAILSTOCK_COMPONENT_TYPE and LATHE_CENTER_COMPONENT_TYPE , in addition to general component parameter groups).
19088	(Obsolete for X3—use machine definition component parameters. See TAILSTOCK_COMPONENT_TYPE and LATHE_CENTER_COMPONENT_TYPE , in addition to general component parameter groups).



19089	(Obsolete for X3—use machine definition component parameters. See TAILSTOCK_COMPONENT_TYPE and LATHE_CENTER_COMPONENT_TYPE , in addition to general component parameter groups).
19090	(Obsolete for X3—use machine definition component parameters. See TAILSTOCK_COMPONENT_TYPE and LATHE_CENTER_COMPONENT_TYPE , in addition to general component parameter groups).
19091	(Obsolete for X3—use machine definition component parameters. See TAILSTOCK_COMPONENT_TYPE and LATHE_CENTER_COMPONENT_TYPE , in addition to general component parameter groups).

STEADYREST_TYPE

19092	(Obsolete for X3—use machine definition component parameters. See STEADYREST_COMPONENT_TYPE , in addition to general component parameter groups).
19093	(Obsolete for X3—use machine definition component parameters. See STEADYREST_COMPONENT_TYPE , in addition to general component parameter groups).
19094	(Obsolete for X3—use machine definition component parameters. See STEADYREST_COMPONENT_TYPE , in addition to general component parameter groups).
19095	(Obsolete for X3—use machine definition component parameters. See STEADYREST_COMPONENT_TYPE , in addition to general component parameter groups).
19096	(Obsolete for X3—use machine definition component parameters. See STEADYREST_COMPONENT_TYPE , in addition to general component parameter groups).
19097	(Obsolete for X3—use machine definition component parameters. See STEADYREST_COMPONENT_TYPE , in addition to general component parameter groups).
19098	(Obsolete for X3—use machine definition component parameters. See STEADYREST_COMPONENT_TYPE , in addition to general component parameter groups).

Safety zone tab

GROUP_PG4

19234	Safezone on (True/False)
19235	Type: SAFEZONE_RECT, SAFEZONE_SPH, SAFEZONE_CYL
19236	X, Y and Z dimensions of rectangle
19237	X, Y and Z dimensions of rectangle
19238	X, Y and Z dimensions of rectangle
19239	Spherical radius
19240	Cylindrical X axis length
19241	Cylindrical radius

19242	Cylinder axis: X, Y or Z
19243	Display
19244	Fit screen
19245	Extend Z



Agie interface

PRM_AGIE_GROUP_INFO

19527	Piece details: Name (new for X4)
19528	Piece details: Material (new for X4)
19529	Piece details: Quality target (new for X4)
19530	Piece details: Wire (new for X4)
19531	Piece details: Strategy (new for X4)
19532	Piece reference position, C coordinate (new for X4)
19533	Edge position (X) (new for X4)
19534	Edge position (Y) (new for X4)
19535	Edge position (Z) (new for X4)
19536	Security level (new for X4)



cnc software, inc.

671 Old Post Road
Tolland, CT 06084 USA
www.mastercam.com

Printed in the USA
Mastercam X4 NCI & Parameter Reference