



Tool holder clamping mechanism**Clamping direction**

View direction on front of tool disk

Clamp direction „rights“ / clockwise (Clamping force of the setbolts upon toolholders acting right-handed to the tool disk.)



Clamp direction „left“ / anti-clockwise (Clamping force of the setbolts upon toolholder acting left-handed to the tool disk.)

